

HEAT CONTROLLER, INC.

**Installation, Operation and  
Maintenance Manual**


**HC Series  
1/2 to 5 Tons  
Commercial Water Source  
Heat Pumps**

HEAT CONTROLLER, INC.

1900 Wellworth Ave., Jackson, Michigan 49203 • Ph. 517-787-2100 • Fax 517-787-9341 • [www.heatcontroller.com](http://www.heatcontroller.com)

**THE QUALITY LEADER IN CONDITIONING AIR**

# MODEL NOMENCLATURE—COMMERCIAL



**NOTE: Above model nomenclature is a general reference. Consult individual specification catalogs for detailed information.**

## Table of Contents

Model Nomenclature	1	Electrical - Low Voltage Wiring	18
Storage	3	Low Water Temperature Cutout Selection	18
Pre-Installation	3	Water Valve Wiring	19
Physical Data	4	Thermostat Wiring	20
Dimensional Data	5	Electrical Wiring Schematics	21
Horizontal Unit Installation	7	CXM Controls	22
Field Conversion of Air Discharge	9	Unit Start-Up and Operating Conditions	24
Condensate Piping Installation	10	Piping System Cleaning & Flushing	24
Duct System Installation	10	Unit and System Checkout Procedure	25
Vertical Unit Location	11	Unit Start-Up Procedure	26
Piping Installation	13	Coax Pressure Drop Table	27
Water Loop Application	14	Operating Pressures	28
Water Quality Standards	15	Preventive Maintenance	29
Electrical - Line Voltage	16	Functional & Performance Troubleshooting	30
Power Wiring	17	Refrigerant Circuit Diagram	32

## Safety

Warnings, cautions and notices appear throughout this manual. Read these items carefully before attempting any installation, service or troubleshooting of the equipment.

**DANGER:** Indicates an immediate hazardous situation, which if not avoided will result in death or serious injury. DANGER labels on unit access panels must be observed.

**WARNING:** Indicates a potentially hazardous situation, which if not avoided could result in death or serious injury.

### ⚠ WARNING! ⚠

**WARNING!** Verify refrigerant type before proceeding. Units are shipped with R-22 refrigerant.

### ⚠ WARNING! ⚠

**WARNING!** To avoid the release of refrigerant into the atmosphere, the refrigerant circuit of this unit must be serviced only by technicians who meet local, state, and federal proficiency requirements.

**CAUTION:** Indicates a potentially hazardous situation or an unsafe practice, which if not avoided could result in minor or moderate injury or product or property damage.

**NOTICE:** Notification of installation, operation or maintenance information, which is important, but which is not hazard-related.

### ⚠ WARNING! ⚠

**WARNING!** All refrigerant discharged from this unit must be recovered **WITHOUT EXCEPTION**. Technicians must follow industry accepted guidelines and all local, state, and federal statutes for the recovery and disposal of refrigerants. If a compressor is removed from this unit, refrigerant circuit oil will remain in the compressor. To avoid leakage of compressor oil, refrigerant lines of the compressor must be sealed after it is removed.

### ⚠ CAUTION! ⚠

**CAUTION!** To avoid equipment damage, **DO NOT** use these units as a source of heating or cooling during the construction process. The mechanical components and filters will quickly become clogged with construction dirt and debris, which may cause system damage.

## GENERAL INFORMATION

### Inspection

Upon receipt of the equipment, carefully check the shipment against the bill of lading. Make sure all units have been received. Inspect the packaging of each unit, and inspect each unit for damage. Insure that the carrier makes proper notation of any shortages or damage on all copies of the freight bill and completes a common carrier inspection report. Concealed damage not discovered during unloading must be reported to the carrier within 15 days of receipt of shipment. If not filed within 15 days, the freight company can deny the claim without recourse. Note: It is the responsibility of the purchaser to file all necessary claims with the carrier. Notify Heat Controller, Inc. of all damage within fifteen (15) days of shipment.

### Storage

Equipment should be stored in its original packaging in a clean, dry area. Store units in an upright position at all times. Stack units a maximum of 3 units high.

### Unit Protection

Cover units on the job site with either the original packaging or an equivalent protective covering. Cap the open ends of pipes stored on the job site. In areas where painting, plastering, and/or spraying has not been completed, all due precautions must be taken to avoid physical damage to the units and contamination by foreign material. Physical damage and contamination may prevent proper start-up and may result in costly equipment clean-up.

Examine all pipes, fittings, and valves before installing any of the system components. Remove any dirt or debris found in or on these components.

### Pre-Installation

Installation, Operation, and Maintenance instructions are provided with each unit. Horizontal equipment is designed for installation above false ceiling or in a ceiling plenum. Other unit configurations are typically installed in a mechanical room. The installation site chosen should include adequate service clearance around the unit. Before unit start-up, read all manuals and become familiar with the unit and its operation. Thoroughly check the system before operation.

### Prepare units for installation as follows:

1. Compare the electrical data on the unit nameplate with ordering and shipping information to verify that the correct unit has been shipped.
2. Keep the cabinet covered with the original packaging until installation is complete and all plastering, painting, etc. is finished.
3. Verify refrigerant tubing is free of kinks or dents and that it does not touch other unit components.
4. Inspect all electrical connections. Connections must be clean and tight at the terminals.
5. Remove any blower support packaging.

6. REMOVE COMPRESSOR SUPPORT PLATE 1/4" SHIPPING BOLTS (2 on each side) TO MAXIMIZE VIBRATION AND SOUND ATTENUATION.
7. Some airflow patterns are field convertible (horizontal units only). Locate the airflow conversion section of this IOM.
8. Locate and verify any hanger or other accessory kit located in the compressor section or blower section.

### ⚠ CAUTION! ⚠

**CAUTION!** All three phase scroll compressors must have direction of rotation verified at start-up. Verification is achieved by checking compressor Amp draw. Amp draw will be substantially lower compared to nameplate values. Additionally, reverse rotation results in an elevated sound level compared to correct rotation. Reverse rotation will result in compressor internal overload trip within several minutes. Verify compressor type before proceeding.

### ⚠ CAUTION! ⚠

**CAUTION!** DO NOT store or install units in corrosive environments or in locations subject to temperature or humidity extremes (e.g., attics, garages, rooftops, etc.). Corrosive conditions and high temperature or humidity can significantly reduce performance, reliability, and service life. Always move units in an upright position. Tilting units on their sides may cause equipment damage.

### ⚠ CAUTION! ⚠

**CAUTION! CUT HAZARD** - Failure to follow this caution may result in personal injury. Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing heat pumps.

**NOTICE!** Failure to remove shipping bolts from compressor base will cause excessive noise.

# UNIT PHYSICAL DATA

## HC Series


Model	H 006	H/V 009	H/V 012	H/V 018	H/V 024	H/V 030	H/V 036	H/V 042	H/V 048	H/V 060
Compressor (1 each)	Rotary			Recip						Scroll
Factory Refrigerant Charge Vertical - (oz) [kg]	-	14 [4.0]	14 [4.0]	26 [7.4]	38 [1.08]	37 [1.05]	42 [1.19]	51 [1.45]	66 [1.87]	74 [2.10]
Factory Refrigerant Charge Horizontal - (oz) [kg]	14 [4.0]	14 [4.0]	14 [4.0]	25 [7.1]	38 [1.08]	37 [1.05]	41 [1.16]	51 [1.45]	66 [1.87]	74 [2.10]
<b>Fan Motor &amp; Blower</b>										
Fan Motor Type/Speeds	PSC/3	PSC/3	PSC/3	PSC/3	PSC/3	PSC/3	PSC/3	PSC/3	PSC/3	PSC/3
Fan Motor (hp) [Watts]	1/25 [30]	1/10 [75]	1/10 [75]	1/6 [124]	1/4 [187]	3/4 [560]	1/2 [373]	3/4 [560]	3/4 [560]	1 [746]
Blower Wheel Size (Dia x W) (in) [mm]	5 x 5 [127 x 127]	5 x 5 [127 x 127]	6 x 5 [152 x 127]	8 x 7 [203 x 178]	9 x 7 [229 x 178]	9 x 7 [229 x 178]	9 x 8 [229 x 203]	9 x 8 [229 x 203]	10 x 10 [254 x 254]	11 x 10 [279 x 254]
<b>Water Connection Size</b>										
IPT (in)	1/2	1/2	1/2	1/2	3/4	3/4	3/4	3/4	1	1
<b>Horizontal</b>										
Air Coil Dimensions (H x W) - (in) [mm]	10 x 15 [254 x 381]	10 x 15 [254 x 381]	10 x 15 [254 x 381]	16 x 22 [406 x 559]	16 x 22 [406 x 559]	16 x 22 [406 x 559]	20 x 25 [508 x 635]	20 x 25 [508 x 635]	20 x 35 [508 x 889]	20 x 35 [508 x 889]
Filter Standard - 1" [25.4mm] Throwaway, qty (in) [mm]	10 x 18 [254 x 457]	10 x 18 [254 x 457]	10 x 18 [254 x 457]	16 x 25 [406 x 635]	16 x 25 [406 x 635]	16 x 25 [406 x 635]	1 - 20 x 28 or 2 - 20 x 14 [1 - 508 x 711or] [2 - 508 x 356]	1 - 20 x 28 or 2 - 20 x 14 [1 - 508 x 711or] [2 - 508 x 356]	1 - 20 x 24 & 1 - 20 x 14 [1 - 508 x 610 &] [1 - 508 x 356]	1 - 20 x 24 & 1 - 20 x 14 [1 - 508 x 610 &] [1 - 508 x 356]
<b>Vertical</b>										
Air Coil Dimensions (H x W) - (in) [mm]	-	10 x 15 [254 x 381]	10 x 15 [254 x 381]	20 x 17.25 [508 x 438]	20 x 17.25 [508 x 438]	20 x 17.25 [508 x 438]	24 x 21.75 [610 x 552]	24 x 21.75 [610 x 552]	24 x 28.25 [610 x 718]	24 x 28.25 [610 x 718]
Filter Standard - 1" [25.4mm] Throwaway, qty (in) [mm]	-	10 x 18 [254 x 457]	10 x 18 [254 x 457]	20 x 20 [508 x 508]	20 x 20 [508 x 508]	20 x 20 [508 x 508]	24 x 24 [610 x 610]	24 x 24 [610 x 610]	1 - 14 x 24 & 1 - 18 x 24 [1 - 356 x 610 &] [1 - 457 x 610]	1 - 14 x 24 & 1 - 18 x 24 [1 - 356 x 610 &] [1 - 457 x 610]
Weight - Operating (lbs) [kg]	103 [47]	105 [48]	114 [52]	181 [82]	189 [86]	197 [89]	203 [92]	218 [99]	263 [119]	278 [126]
Weight - Packaged (lbs) [kg]	113 [51]	115 [52]	124 [56]	186 [84]	194 [88]	202 [92]	209 [95]	224 [102]	270 [122]	285 [129]

Notes:  
All units have grommet compressor mountings, and 1/2" [12.2mm] & 3/4" [19.1mm] electrical knockouts.

# Horizontal Dimensional Data

Horizontal Model		Overall Cabinet			Water Connections				Water IPT Size	Electrical Knockouts			Discharge Connections duct flange (± 0.10 in, ± 2.54mm)					Return Connection using return air opening			
		A	B	C	1 - In		2 - Out			H	J	K	L	M	N	O	P	Q	R	S	T
		Width	Depth	Height	D	E	F	G		1/2" cond Low Voltage	1/2" cond Low Voltage	3/4" cond Power Supply	Supply Height	Supply Depth	Supply Depth	Supply Depth	Return Depth	Return Height	Return Height	Return Height	
006-012	in.	19.1	34.1	11.0	9.6	0.8	1.8	0.8	1/2"	8.1	5.1	2.1	0.8	8.9	6.7	5.2	1.3	16.1	9.8	1.1	0.6
	cm.	48.5	86.6	27.9	24.4	2.0	4.4	2.0	1/2"	20.6	13.0	5.4	1.9	22.7	17.0	13.3	3.3	41.0	25.0	2.7	1.5
018	in.	20.1	43.1	17.1	15.3	2.4	1.9	2.1	1/2"	12.1	9.1	6.1	2.6	13.3	9.9	4.1	1.3	23.0	15.0	1.1	1.0
	cm.	51.1	109.5	43.4	38.9	6.1	4.9	5.3	1/2"	30.8	23.2	15.6	6.6	33.8	25.1	10.5	3.3	58.4	38.1	2.8	2.5
024-030	in.	20.1	43.1	17.1	15.3	2.4	1.9	2.1	3/4"	12.1	9.1	6.1	2.6	13.3	9.9	4.1	1.3	23.0	15.0	1.1	1.0
	cm.	51.1	109.5	43.4	38.9	6.1	4.9	5.3	3/4"	30.8	23.2	15.6	6.6	33.8	25.1	10.5	3.3	58.4	38.1	2.8	2.5
036-042	in.	20.1	47.1	21.1	18.8	2.2	4.7	1.2	3/4"	16.1	13.1	10.1	2.5	16.1	11.0	3.0	2.5	25.9	19.0	1.1	1.0
	cm.	51.1	119.6	53.6	47.6	5.5	11.9	3.0	3/4"	41.0	33.3	25.7	6.3	40.9	27.9	7.7	6.4	65.8	48.3	2.8	2.5
048	in.	24.1	54.1	21.1	19.4	5.9	4.3	2.3	3/4"	16.1	13.1	10.1	3.7	16.1	13.7	4.1	1.3	35.9	19.0	1.1	1.0
	cm.	61.2	137.4	53.6	49.2	14.9	11.0	5.8	3/4"	41.0	33.3	25.7	9.5	41.0	34.8	10.3	3.2	91.2	48.3	2.8	2.5
060	in.	24.1	54.1	21.1	19.4	5.9	4.3	2.3	1"	16.1	13.1	10.1	1.7	18.1	13.7	4.1	1.3	35.9	19.0	1.1	1.0
	cm.	61.2	137.4	53.6	49.2	14.9	11.0	5.8	1"	41.0	33.3	25.7	4.4	46.0	34.8	10.3	3.2	91.2	48.3	2.8	2.5

Condensate is 3/4" IPT copper.  
 Horizontal unit shipped with filter bracket only. This bracket should be removed for return duct connection.  
 Hanger bracket is factory installed




# Vertical Upflow Dimensional Data

Vertical Upflow Model	Overall Cabinet			Water Connections						Water IPT Size	Electrical Knockouts			Discharge Connection duct flange installed (±0.10 in, ±2.54mm)					Return Connection using return air opening				
				1		2		3			J	K	L	M	N	O	P	Q	R	S	T	U	
	A	B	C	D	E	F	G	H	I	1/2" cond	1/2" cond	3/4" cond	Supply Width	Supply Depth	Return Depth	Return Depth	Return Height	Return Height					
	Width	Depth	Height	In		Out		Condensate		Low Voltage	Low Voltage	Power Supply											
009-012	in.	19.1	19.1	22.0	1.4	2.8	9.4	2.8	6.1	2.3	1/2"	2.9	5.9	8.9	8.9	5.1	9.0	9.0	5.5	2.1	16.2	9.9	0.7
	cm.	48.5	48.5	55.9	3.6	7.1	24.0	7.1	15.6	5.9		7.3	14.9	22.5	22.7	12.9	22.9	22.9	14.0	5.3	41.1	25.1	1.9
018	in.	21.5	21.5	39.0	1.8	3.8	15.2	3.6	8.1	2.3	1/2"	4.1	7.1	10.1	6.4	3.8	14.0	14.0	5.3	2.3	18.3	20.2	0.7
	cm.	54.6	54.6	99.1	4.5	9.7	38.6	9.1	20.6	5.8		10.5	18.1	25.7	16.1	9.5	35.6	35.6	13.6	5.8	46.5	51.3	1.9
024-030	in.	21.5	21.5	39.0	1.8	3.8	15.2	3.6	8.1	2.3	3/4"	4.1	7.1	10.1	6.4	3.8	14.0	14.0	5.3	2.3	18.3	20.2	0.7
	cm.	54.6	54.6	99.1	4.5	9.7	38.6	9.1	20.6	5.8		10.5	18.1	25.7	16.1	9.5	35.6	35.6	13.6	5.8	46.5	51.3	1.9
036 & 042	in.	21.5	26.0	44.0	2.0	3.7	16.2	2.6	10.4	2.3	3/4"	4.1	7.1	10.1	6.4	3.8	14.0	14.0	5.1	2.3	22.8	24.2	0.7
	cm.	54.6	66.0	111.8	5.1	9.4	41.1	6.6	26.4	5.8		10.5	18.1	25.7	16.1	9.5	35.6	35.6	13.1	5.8	57.9	61.4	1.9
048-060	in.	24.0	32.5	46.0	1.8	5.9	16.7	2.3	10.1	2.3	1"	4.1	7.1	10.1	6.9	7.3	16.0	18.0	5.1	2.3	29.3	24.2	0.7
	cm.	61.0	82.6	116.8	4.5	14.9	42.4	5.8	25.7	5.8		10.5	18.1	25.7	17.4	18.4	40.6	45.7	13.1	5.8	74.4	61.4	1.9

Condensate is 3/4" IPT  
 Filter bracket extending from unit 2.5" [6.4 cm]. This bracket should be removed when connecting return duct.  
 Discharge flange field installed

- Notes:
1. Front & Side access is preferred for service access.
  2. While clear access to all removable panels is not required, installer should take care to comply with all building codes and allow adequate clearance for future field service.



\* Note: Shaded areas are recommended service areas, not required.

# HORIZONTAL INSTALLATION

## Horizontal Unit Location

Units are not designed for outdoor installation. Locate the unit in an INDOOR area that allows enough space for service personnel to perform typical maintenance or repairs without removing unit from the ceiling. Horizontal units are typically installed above a false ceiling or in a ceiling plenum. Never install units in areas subject to freezing or where humidity levels could cause cabinet condensation (such as unconditioned spaces subject to 100% outside air). Consideration should be given to access for easy removal of the filter and access panels. Provide sufficient room to make water, electrical, and duct connection(s).

If the unit is located in a confined space, such as a closet, provisions must be made for return air to freely enter the space by means of a louvered door, etc. Any access panel screws that would be difficult to remove after the unit is installed should be removed prior to setting the unit. Refer to Figure 3 for an illustration of a typical installation. Refer to unit submittal data or engineering design guide for dimensional data.

Conform to the following guidelines when selecting unit location:

1. Provide a hinged access door in concealed-spline or plaster ceilings. Provide removable ceiling tiles in T-bar or lay-in ceilings. Refer to horizontal unit dimensions for specific series and model in unit submittal data. Size the access opening to accommodate the service technician during the removal or replacement of the compressor and the removal or installation of the unit itself.
2. Provide access to hanger brackets, water valves and fittings. Provide screwdriver clearance to access panels, discharge collars and all electrical connections.
3. DO NOT obstruct the space beneath the unit with piping, electrical cables and other items that prohibit future removal of components or the unit itself.
4. Use a manual portable jack/lift to lift and support the weight of the unit during installation and servicing.

The installation of water source heat pump units and all associated components, parts and accessories which make up the installation shall be in accordance with the regulations of ALL authorities having jurisdiction and MUST conform to all applicable codes. It is the responsibility of the installing contractor to determine and comply with ALL applicable codes and regulations.

## Mounting Horizontal Units


Horizontal units have hanger kits pre-installed from the factory as shown in figure 1. Figure 3 shows a typical horizontal unit installation.

Horizontal heat pumps are typically suspended above a ceiling or within a soffit using field supplied, threaded rods sized to support the weight of the unit.


Use four (4) field supplied threaded rods and factory provided vibration isolators to suspend the unit. Hang the unit clear of the floor slab above and support the unit by the mounting bracket assemblies only. DO NOT attach the unit flush with the floor slab above.

Pitch the unit toward the drain as shown in Figure 2 to improve the condensate drainage. On small units (less than 2.5 tons/8.8kW) ensure that unit pitch does not cause condensate leaks inside the cabinet.

**Figure 1: Hanger Bracket**




**Figure 2: Horizontal Unit Pitch**





## HORIZONTAL INSTALLATION

Figure 3: Typical Horizontal Unit Installation



### Air Coil

To obtain maximum performance, the air coil should be cleaned before start-up. A 10% solution of dishwasher detergent and water is recommended for both sides of the coil. A thorough water rinse should follow. **UV based anti-bacterial systems will damage e-coated air coils.**

### NOTICE! Installation Note - Ducted Return:

Many horizontal WSHPs are installed in a return air ceiling plenum application (above ceiling). Vertical WSHPs are commonly installed in a mechanical room with free return (e.g. louvered door). Therefore, filter rails are the industry standard and are included on HC Series commercial heat pumps for the purposes of holding the filter only. For ducted return applications, the filter rail must be removed and replaced with a duct flange or filter rack. Canvas or flexible connectors should also be used to minimize vibration between the unit and ductwork.

# FIELD CONVERSION OF AIR DISCHARGE

## Overview

Horizontal units can be field converted between side (straight) and back (end) discharge using the instructions below.

**Note: It is not possible to field convert return air between left or right return models due to the necessity of refrigeration copper piping changes.**

## Preparation

It is best to field convert the unit on the ground before hanging. If the unit is already hung it should be taken down for the field conversion.

## Side to Back Discharge Conversion

1. Place unit in well lit area. Remove the screws as shown in Figure 4 to free top panel and discharge panel.
2. Lift out the access panel and set aside. Lift and rotate the discharge panel to the other position as shown, being careful with the blower wiring.
3. Check blower wire routing and connections for tension or contact with sheet metal edges. Reroute if necessary.
4. Check refrigerant tubing for contact with other components.
5. Reinstall top panel and screws noting that the location for some screws will have changed.
6. Manually spin the fan wheel to insure that the wheel is not rubbing or obstructed.
7. Replace access panels.

## Back to Side Discharge Conversion

If the discharge is changed from back to side, use above instruction noting that illustrations will be reversed.

## Left vs. Right Return

It is not possible to field convert return air between left or right return models due to the necessity of refrigeration copper piping changes. However, the conversion process of side to back or back to side discharge for either right or left return configuration is the same. In some cases, it may be possible to rotate the entire unit 180 degrees if the return air connection needs to be on the opposite side. Note that rotating the unit will move the piping to the other end of the unit.

Figure 4: Left Return Side to Back





Figure 5: Right Return Side to Back



## HORIZONTAL INSTALLATION

### Condensate Piping – Horizontal Units

Units are typically installed directly above each other on successive floors with condensate drains located near the units. Attach the unit condensate drain connection to the building condensate drain with a flexible, non-pressure-rated 3/4 inch [19mm] ID plastic hose. Insure that the hose is without kinks to maintain unobstructed flow of condensate from the unit to the drain. Verify that condensate line is pitched towards the drain 1/4" per foot (10mm per 46cm) of run.

Pitch the unit toward the drain as shown in Figure 2 to improve the condensate drainage. On small units (less than 2.5 tons/8.8 kW), insure that unit pitch does not cause condensate leaks inside the cabinet.


The horizontal run of a condensate hose is usually too short to cause drainage problems. However, the horizontal run of the condensate line should be pitched at least 1 inch for every 10 feet [10mm per 116cm] of run in the direction of flow to insure that the connection will not slip off due to excessive weight or piping expansion/contraction. Avoid low points and non-pitched piping since dirt collects in low or level areas and may cause stoppage and overflow.

Install condensate trap at each unit with the top of the trap positioned below the unit condensate drain connection as shown in Figure 6. Design the depth of the trap (water-seal) based upon the amount of ESP capability of the blower (where 2 inches [51mm] of ESP capability requires 2 inches [51mm] of trap depth). As a general rule, 1-1/2 inch [38mm] trap depth is the minimum.

Each unit must be installed with its own individual trap and connection to the condensate line (main) or riser. Provide a means to flush or blow out the condensate line. DO NOT install units with a common trap and/or vent.

Always vent the condensate line when dirt or air can collect in the line or a long horizontal drain line is required. Also vent when large units are working against higher external static pressure than other units connected to the same condensate main since this may cause poor drainage for all units on the line. WHEN A VENT IS INSTALLED IN THE DRAIN LINE, IT MUST BE LOCATED AFTER THE TRAP IN THE DIRECTION OF THE CONDENSATE FLOW.

**Figure 6: Horizontal Condensate Connection**



### ⚠ CAUTION! ⚠

**CAUTION!** Ensure condensate line is pitched toward drain 1/4" per foot [10mm per 46cm] of run.

## DUCT SYSTEM INSTALLATION

### Duct System Installation

The duct system should be sized to handle the design airflow quietly. Refer to Figure 3 for horizontal duct system details or figure 8 for vertical duct system details. A flexible connector is recommended for both discharge and return air duct connections on metal duct systems to eliminate the transfer of vibration to the duct system. To maximize sound attenuation of the unit blower, the supply and return plenums should include internal fiberglass duct liner or be constructed from ductboard for the first few feet. Application of the unit to uninsulated ductwork in an unconditioned space is not recommended, as the unit's performance will be adversely affected.

At least one 90° elbow should be included in the supply duct to reduce air noise. If air noise or excessive air flow is a problem, the blower speed can be changed. For airflow charts, consult submittal data for the series and model of the specific unit.

If the unit is connected to existing ductwork, a previous check should have been made to insure that the ductwork has the capacity to handle the airflow required for the unit. If ducting is too small, as in the replacement of a heating only system, larger ductwork should be installed. All existing ductwork should be checked for leaks and repaired as necessary.

# VERTICAL INSTALLATION

## Vertical Unit Location

Units are not designed for outdoor installation. Locate the unit in an INDOOR area that allows enough space for service personnel to perform typical maintenance or repairs without removing unit from the mechanical room/closet. Vertical units are typically installed in a mechanical room or closet. Never install units in areas subject to freezing or where humidity levels could cause cabinet condensation (such as unconditioned spaces subject to 100% outside air). Consideration should be given to access for easy removal of the filter and access panels. Provide sufficient room to make water, electrical, and duct connection(s).

If the unit is located in a confined space, such as a closet, provisions must be made for return air to freely enter the space by means of a louvered door, etc. Any access panel screws that would be difficult to remove after the unit is installed should be removed prior to setting the unit. Refer to Figures 7 and 8 for typical installation illustrations. Refer to unit submittal data or engineering design guide for dimensional data.

1. Install the unit on a piece of rubber, neoprene or other mounting pad material for sound isolation. The pad should be at least 3/8" [10mm] to 1/2" [13mm] in thickness. Extend the pad beyond all four edges of the unit.
2. Provide adequate clearance for filter replacement and drain pan cleaning. Do not block filter access with piping, conduit or other materials. Refer to unit submittal data or engineering design guide for dimensional data.
3. Provide access for fan and fan motor maintenance and for servicing the compressor and coils without removing the unit.
4. Provide an unobstructed path to the unit within the closet or mechanical room. Space should be sufficient to allow removal of the unit, if necessary.
5. In limited side access installations, pre-removal of the control box side mounting screws will allow control box removal for future servicing.
6. Provide access to water valves and fittings and screwdriver access to the unit side panels, discharge collar and all electrical connections.

Figure 7: Vertical Unit Mounting





Figure 8: Typical Vertical Unit Installation Using Ducted Return Air



Rev 3/27/00


# VERTICAL INSTALLATION

## Sound Attenuation for Vertical Units

Sound attenuation is achieved by enclosing the unit within a small mechanical room or a closet. Additional measures for sound control include the following:

1. Mount the unit so that the return air inlet is 90° to the return air grille. Refer to Figure 9. Install a sound baffle as illustrated to reduce line-of-sight sound transmitted through return air grilles.
2. Mount the unit on a rubber or neoprene isolation pad to minimize vibration transmission to the building structure.


**Figure 9: Vertical Sound Attenuation**




## Condensate Piping – Vertical Units

Vertical units utilize a condensate hose inside the cabinet as a trapping loop; therefore an external trap is not necessary. Figure 10a shows typical condensate connections. Figure 10b illustrates the internal trap for a typical vertical heat pump. Each unit must be installed with its own individual vent and a means to flush or blow out the condensate drain line. Do not install units with a common trap and/or vent.

**Figure 10a: Vertical Condensate Drain**



**Figure 10b: Vertical Internal Condensate Trap**



## PIPING INSTALLATION

### Installation of Supply and Return Piping

Follow these piping guidelines.

1. Install a drain valve at the base of each supply and return riser to facilitate system flushing.
2. Install shut-off / balancing valves and unions at each unit to permit unit removal for servicing.
3. Place strainers at the inlet of each system circulating pump.
4. Select the proper hose length to allow slack between connection points. Hoses may vary in length by +2% to -4% under pressure.
5. Refer to Table 1. Do not exceed the minimum bend radius for the hose selected. Exceeding the minimum bend radius may cause the hose to collapse, which reduces water flow rate. Install an angle adapter to avoid sharp bends in the hose when the radius falls below the required minimum.

Insulation is not required on loop water piping except where the piping runs through unheated areas, outside the building or when the loop water temperature is below the minimum expected dew point of the pipe ambient conditions. Insulation is required if loop water temperature drops below the dew point (insulation is required for ground loop applications in most climates).

Pipe joint compound is not necessary when Teflon® thread tape is pre-applied to hose assemblies or when flared-end connections are used. If pipe joint compound is preferred, use compound only in small amounts on the external pipe threads of the fitting adapters. Prevent sealant from reaching the flared surfaces of the joint.

Note: When anti-freeze is used in the loop, insure that it is compatible with the Teflon tape or pipe joint compound that is applied.

Maximum allowable torque for brass fittings is 30 ft-lbs [41 N-m]. If a torque wrench is not available, tighten finger-tight plus one quarter turn. Tighten steel fittings as necessary.

Optional pressure-rated hose assemblies designed specifically for use with Heat Controller units are available. Similar hoses can be obtained from alternate suppliers. Supply and return hoses are fitted with swivel-joint fittings at one end to prevent kinking during installation.

Refer to Figure 11 for an illustration of a typical supply/return hose kit. Adapters secure hose assemblies to the unit and risers. Install hose assemblies properly and check regularly to avoid system failure and reduced service life.

A backup wrench is required when tightening water connections to prevent water line damage.

### ⚠ CAUTION! ⚠

**CAUTION!** Corrosive system water requires corrosion resistant fittings and hoses, and may require water treatment.

**Table 1: Metal Hose Minimum Bend Radii**

Hose Diameter	Minimum Bend Radii
1/2" [12.7mm]	2-1/2" [6.4cm]
3/4" [19.1mm]	4" [10.2cm]
1" [25.4mm]	5-1/2" [14cm]
1-1/4" [31.8mm]	6-3/4" [17.1cm]

### ⚠ CAUTION! ⚠


**CAUTION!** Do not bend or kink supply lines or hoses.

**NOTICE!** Do not allow hoses to rest against structural building components. Compressor vibration may be transmitted through the hoses to the structure, causing unnecessary noise complaints.

### ⚠ CAUTION! ⚠

**CAUTION!** Piping must comply with all applicable codes.

**Figure 11: Supply/Return Hose Kit**



# WATER-LOOP HEAT PUMP APPLICATIONS

## Commercial Water Loop Applications

Commercial systems typically include a number of units connected to a common piping system. Any unit plumbing maintenance work can introduce air into the piping system; therefore air elimination equipment is a major portion of the mechanical room plumbing. In piping systems expected to utilize water temperatures below 50°F [10°C], 1/2" (13mm) closed cell insulation is required on all piping surfaces to eliminate condensation (extended range units required). Metal to plastic threaded joints should never be used due to their tendency to leak over time. A backup wrench must be used for HC series equipment fittings.


Teflon tape thread sealant is recommended to minimize internal fouling of the heat exchanger. Do not over tighten connections and route piping so as not to interfere with service or maintenance access. Hose kits are available from Heat Controller in different configurations as shown in Figure 12 for connection between the unit and the piping system. Piping may include shut off valves, P/T plugs for performance measurement, high pressure stainless steel braided hose, "Y" type strainer with blow down valve, and/or "J" type swivel connection. Balancing valves and an external low pressure drop solenoid valve

for use in variable speed pumping systems may also be included in the external piping.

The piping system should be flushed to remove dirt, piping chips, and other foreign material prior to operation (see "Piping System Cleaning and Flushing Procedures" in this manual). The flow rate is usually set between 2.25 and 3.5 gpm per ton [2.9 and 4.5 l/m per kW] of cooling capacity. Heat Controller recommends 3 gpm per ton [3.9 l/m per kW] for most applications of water loop heat pumps. To insure proper maintenance and servicing, P/T ports are imperative for temperature and flow verification, as well as performance checks.

Water loop heat pump (cooling tower/boiler) systems typically utilize a common loop, maintained between 60 - 90°F [16 - 32°C]. The use of a closed circuit evaporative cooling tower with a secondary heat exchanger between the tower and the water loop is recommended. If an open type cooling tower is used continuously, chemical treatment and filtering will be necessary.

Figure 12: Typical Water-Loop Application



# WATER QUALITY STANDARDS

**Table 3: Water Quality Standards**

<i>Water Quality Parameter</i>	<i>HX Material</i>	<i>Closed Recirculating</i>	<i>Open Loop and Recirculating Well</i>		
<b>Scaling Potential - Primary Measurement</b>					
Above the given limits, scaling is likely to occur. Scaling indexes should be calculated using the limits below.					
pH/Calcium Hardness Method	All	-	<b>pH &lt; 7.5 and Ca Hardness &lt;100ppm</b>		
<b>Index Limits for Probable Scaling Situations - (Operation outside these limits is not recommended)</b>					
Scaling indexes should be calculated at 150°F for direct use and HWG applications, and at 90°F for indirect HX use. A monitoring plan should be implemented.					
Ryznar Stability Index	All	-	<b>6.0 - 7.5</b> If >7.5 minimize steel pipe use.		
Langelier Saturation Index	All	-	<b>-0.5 to +0.5</b> If <-0.5 minimize steel pipe use. Based upon 150 °F HWG and Direct well, 85°F Indirect Well HX		
<b>Iron Fouling</b>					
Iron Fe <sup>2+</sup> (Ferrous) (Bacterial Iron potential)	All	-	<b>&lt;0.2 ppm (Ferrous)</b> If Fe <sup>2+</sup> (ferrous)>0.2 ppm with pH 6 - 8, O <sub>2</sub> <5 ppm check for iron bacteria		
Iron Fouling	All	-	<b>&lt;0.5 ppm of Oxygen</b> Above this level deposition will occur.		
<b>Corrosion Prevention</b>					
pH	All	<b>6 - 8.5</b> Monitor/treat as needed	<b>6 - 8.5</b> Minimize steel pipe below 7 and no open tanks with pH <8		
Hydrogen Sulfide (H <sub>2</sub> S)	All	-	<b>&lt;0.5 ppm</b> At H <sub>2</sub> S>0.2 ppm, avoid use of copper and copper nickel piping or HX's. Rotten egg smell appears at 0.5 ppm level. Copper alloy (bronze or brass) cast components are OK to <0.5 ppm.		
Ammonia ion as hydroxide, chloride, nitrate and sulfate compounds	All	-	<b>&lt;0.5 ppm</b>		
Maximum Chloride Levels			Maximum Allowable at maximum water temperature.		
			50°F (10°C)	75°F (24°C)	100°F (38°C)
	Copper	-	<20ppm	NR	NR
	CuproNickel	-	<150 ppm	NR	NR
	304 SS	-	<400 ppm	<250 ppm	<150 ppm
	316 SS	-	<1000 ppm	<550 ppm	< 375 ppm
	Titanium	-	>1000 ppm	>550 ppm	>375 ppm
<b>Erosion and Clogging</b>					
Particulate Size and Erosion	All	<10 ppm of particles and a maximum velocity of 6 fps. Filtered for maximum 800 micron size.	<10 ppm (<1 ppm "sandfree" for reinjection) of particles and a maximum velocity of 6 fps. Filtered for maximum 800 micron size. Any particulate that is not removed can potentially clog components.		

**Notes:**

- Closed Recirculating system is identified by a closed pressurized piping system. Recirculating open wells should observe the open recirculating design considerations.
- NR - Application not recommended.
- "-" No design Maximum.



## ELECTRICAL - LINE VOLTAGE

### ⚠ WARNING! ⚠

**WARNING!** To avoid possible injury or death due to electrical shock, open the power supply disconnect switch and secure it in an open position during installation.

### ⚠ CAUTION! ⚠

**CAUTION!** Use only copper conductors for field installed electrical wiring. Unit terminals are not designed to accept other types of conductors.

### Electrical - Line Voltage

All field installed wiring, including electrical ground, must comply with the National Electrical Code as well as all applicable local codes. Refer to the unit electrical data for fuse sizes. Consult wiring diagram for field connections that must be made by the installing (or electrical) contractor. All final electrical connections must be made with a length of flexible conduit to minimize vibration and sound transmission to the building.

### General Line Voltage Wiring

Be sure the available power is the same voltage and phase shown on the unit serial plate. Line and low voltage wiring must be done in accordance with local codes or the National Electric Code, whichever is applicable.

## ELECTRICAL - LINE VOLTAGE

**Table 4: Series Electrical Data**

Model	Volt Code	Rated Voltage	Voltage Min/Max	Compressor			Fan Motor FLA	Standard Unit		
				Qty	RLA	LRA		Total Unit FLA	Min Circ Amp	Max Fuse/ HACR
				H006	1	208-230/60/1	197/254	1	2.9	17.7
	8	265/60/1	239/292	1	2.5	15.0	0.35	2.8	3.5	15
V/H009	1	208-230/60/1	197/254	1	3.9	22.2	0.80	4.7	5.7	15
	8	265/60/1	239/292	1	3.3	18.8	0.70	4.0	4.8	15
V/H012	1	208-230/60/1	197/254	1	5.3	27.9	0.80	6.1	7.5	15
	8	265/60/1	239/292	1	4.2	22.2	0.70	4.9	6.0	15
V/H018	1	208-230/60/1	197/254	1	8.6	49.0	1.00	9.6	11.7	20
	8	265/60/1	239/292	1	8.1	44.0	0.86	8.9	11.0	15
V/H024	1	208-230/60/1	197/254	1	9.8	56.0	1.50	11.3	13.8	20
	8	265/60/1	239/292	1	9.1	55.0	1.30	10.4	12.7	20
	3	208-230/60/3	197/254	1	6.7	51.0	1.50	8.2	9.9	15
	4	460/60/3	414/506	1	3.5	25.0	0.76	4.2	5.1	15
V/H030	1	208-230/60/1	197/254	1	11.2	61.0	3.00	14.2	16.9	25
	8	265/60/1	239/292	1	10.0	58.0	2.70	12.7	15.2	25
	3	208-230/60/3	197/254	1	6.9	55.0	3.00	9.9	11.7	15
	4	460/60/3	414/506	1	3.6	28.0	1.70	5.3	6.2	15
V/H036	1	208-230/60/1	197/254	1	15.4	82.0	1.80	17.2	21.1	35
	8	265/60/1	239/292	1	14.4	83.0	2.00	16.4	20.0	30
	3	208-230/60/3	197/254	1	9.6	70.0	1.80	11.4	13.8	20
	4	460/60/3	414/506	1	4.9	33.0	1.24	6.1	7.4	15
V/H042	1	208-230/60/1	197/254	1	17.1	105.0	3.00	20.1	24.3	40
	3	208-230/60/3	197/254	1	10.7	85.0	3.00	13.7	16.4	25
	4	460/60/3	414/506	1	5.3	42.0	1.70	7.0	8.3	15
	5	575/60/3	518/633	1	4.3	34.0	1.40	5.7	6.8	15
V/H048**	1	208-230/60/1	197/254	1	18.3	102.0	3.40	21.7	26.3	40
	3	208-230/60/3	197/254	1	12.6	91.0	3.40	16.0	19.2	30
	4	460/60/3	414/506	1	5.7	42.0	1.80	7.5	8.9	15
	5	575/60/3	518/633	1	4.7	39.0	1.40	6.1	7.2	15
V/H060**	1	208-230/60/1	197/254	1	25.6	170.0	4.30	29.9	36.4	60
	3	208-230/60/3	197/254	1	14.7	124.0	4.30	19.0	22.7	35
	4	460/60/3	414/506	1	7.4	59.6	2.50	9.9	11.8	15
	5	575/60/3	518/633	1	5.9	49.4	1.90	7.8	9.3	15

HACR circuit breaker in USA only  
All fuses Class RK-5

## ELECTRICAL - POWER WIRING

### ⚠ WARNING! ⚠

**WARNING!** Disconnect electrical power source to prevent injury or death from electrical shock.

### ⚠ CAUTION! ⚠

**CAUTION!** Use only copper conductors for field installed electrical wiring. Unit terminals are not designed to accept other types of conductors.

#### Electrical - Line Voltage

All field installed wiring, including electrical ground, must comply with the National Electrical Code as well as all applicable local codes. Refer to the unit electrical data for fuse sizes. Consult wiring diagram for field connections that must be made by the installing (or electrical) contractor. All final electrical connections must be made with a length of flexible conduit to minimize vibration and sound transmission to the building.


#### General Line Voltage Wiring

Be sure the available power is the same voltage and phase shown on the unit serial plate. Line and low voltage wiring must be done in accordance with local codes or the National Electric Code, whichever is applicable.

#### Power Connection

Line voltage connection is made by connecting the incoming line voltage wires to the “L” side of the contactor as shown in Figure 16. Consult Table for correct fuse size.

**Figure 16: Series Single Phase Line Voltage Field Wiring. Three phase wiring is similar except that all three power wires are directly connected to the contactor.**



Rev.: 5/17/01 B

#### 208 Volt Operation

All commercial 208-230 Volt units are factory wired for 208 Volt operation. The transformer may be switched to the 230V tap as illustrated on the wiring diagram by switching the red (208V) and the orange (230V) wires at the contactor terminal.


#### Blower Speed Selection –

PSC (Permanent Split Capacitor) blower fan speed can be changed by moving the blue wire on the fan motor terminal block to the desired speed as shown in Figure 17. Most units are shipped on the medium speed tap. Consult submittal data or engineering design guide for specific unit airflow tables. Typical unit design delivers rated airflow at nominal static (0.15 in. w.g. [37Pa]) on medium speed and rated airflow at a higher static (0.4 to 0.5 in. w.g. [100 to 125 Pa]) on high speed for applications where higher static is required. Low speed will deliver approximately 85% of rated airflow at 0.10 in. w.g. [25 Pa]. An optional high static blower is available on some models.

**Special Note for ARI Testing:** To achieve rated airflow for ARI testing purposes on all PSC products, it is necessary to change the fan speed to “HI” speed. When the heat pump has experienced less than 100 operational hours and the coil has not had sufficient time to be “seasoned”, it is necessary to clean the coil with a mild surfactant such as Calgon to remove the oils left by manufacturing processes and enable the condensate to properly “sheet” off of the coil.

# ELECTRICAL - POWER & LOW VOLTAGE WIRING

Figure 17: PSC Motor Speed Selection




## ELECTRICAL - LOW VOLTAGE WIRING

### Thermostat Connections

The thermostat should be wired directly to the CXM board.

Figure 19: Low Voltage Field Wiring



**⚠ CAUTION! ⚠**  
**CAUTION!** - HC Series equipment may not be used when EWT is below 60°F [15°C].

### Low Water Temperature Cutout

The CXM control senses low water temperature utilizing thermistor FP1. Note that the FP1 thermistor is located on the refrigerant line between the coaxial heat exchanger and the cap tube. Therefore, FP1 is sensing refrigerant temperature, not water temperature, which is a better indication of how water flow rate/temperature is affecting the refrigeration circuit.

The factory setting for FP1 is 30°F [-1.1°C] refrigerant temperature. HC series equipment is not rated for extended range applications.

# ELECTRICAL - LOW VOLTAGE WIRING

## Accessory Connections

A terminal paralleling the compressor contactor coil has been provided on the CXM control. Terminal "A" is designed to control accessory devices, such as water valves. Note: This terminal should be used only with 24 Volt signals and not line voltage. Terminal "A" is energized with the compressor contactor. See Figure 21 or the specific unit wiring diagram for details.

## Low Voltage VA Ratings

Component	VA
Typical Blower Relay	6 - 7
Typical Reversing Valve Solenoid	4 - 6
30A Compressor Contactor	6 - 9
Subtotal	16 - 22
+ CXM board (5 - 9 VA)*	21 - 31
Remaing VA for Accessories	19 - 29

\*Standard transformer for CXM board is 50VA.

Figure 22: Slow Closing Valve Wiring (Typical)




Figure 23: Taco ESP Valve Wiring





Figure 21: Accessory Wiring



## Water Solenoid Valves

An external solenoid valve may be used on some installations to shut off flow to the unit when the compressor is not operating. A slow closing valve may be required to help reduce water hammer. Figure 21 shows typical wiring for a 24VAC external solenoid valve. Figures 22 and 23 illustrate typical slow closing water control valve wiring. Slow closing valves take approximately 60 seconds to open (very little water will flow before 45 seconds). Once fully open, an end switch allows the compressor to be energized. Only relay or triac based electronic thermostats should be used with slow closing valves. When wired as shown, the slow closing valve will operate properly with the following notations:

1. The valve will remain open during a unit lockout.
2. The valve will draw approximately 25-35 VA through the "Y" signal of the thermostat.

Note: This valve can overheat the anticipator of an electromechanical thermostat. Therefore, only relay or triac based thermostats should be used.


# ELECTRICAL - THERMOSTAT WIRING

## Thermostat Installation

The thermostat should be located on an interior wall in a larger room, away from supply duct drafts. DO NOT locate the thermostat in areas subject to sunlight, drafts or on external walls. The wire access hole behind the thermostat may in certain cases need to be sealed to prevent erroneous temperature measurement. Position the thermostat back plate against the wall so that it appears level and so the thermostat wires protrude

through the middle of the back plate. Mark the position of the back plate mounting holes and drill holes with a 3/16" (5mm) bit. Install supplied anchors and secure plate to the wall. Thermostat wire must be 18 AWG wire. Wire the appropriate thermostat as shown in Figures 25 to the low voltage terminal strip on the CXM control board. Practically any heat pump thermostat will work with Heat Controller units.

Figure 25: Units With PSC Fan And CXM





# CXM CONTROLS

## CXM Control

For detailed control information, see CXM Electronic Heat Pump Control Application, Operation and Maintenance Guide.

## Field Selectable Inputs

**Test mode:** Test mode allows the service technician to check the operation of the control in a timely manner. By momentarily shorting the test terminals, the CXM control enters a 20 minute test mode period in which all time delays are sped up 15 times. Upon entering test mode, the status LED will flash a code representing the last fault. For diagnostic ease at the thermostat, the alarm relay will also cycle during test mode. The alarm relay will cycle on and off similar to the status LED to indicate a code representing the last fault, at the thermostat. Test mode can be exited by shorting the test terminals for 3 seconds.

**Retry Mode:** If the control is attempting a retry of a fault, the status LED will slow flash (slow flash = one flash every 2 seconds) to indicate the control is in the process of retrying.

## Field Configuration Options

**Note:** In the following field configuration options, jumper wires should be clipped **ONLY** when power is removed from the CXM control.

Air coil low temperature limit setting: Jumper 2 (JW2-FP2 Low Temp) provides field selection of temperature limit setting for FP2 of 30°F or 10°F [-1°F or -12°C] (refrigerant temperature). **Note:** This jumper should only be clipped under extenuating circumstances, as recommended by Heat Controller technical services.

*Not Clipped = 30°F [-1°C]. Clipped = 10°F [-12°C].*

Alarm relay setting: Jumper 1 (JW1-AL2 Dry) provides field selection of the alarm relay terminal AL2 to be jumpered to 24VAC or to be a dry contact (no connection). *Not Clipped = AL2 connected to R. Clipped = AL2 dry contact (no connection).*

## DIP Switches

**Note:** In the following field configuration options, DIP switches should only be changed when power is removed from the CXM control.

DIP switch 1: Unit Performance Sentinel Disable - provides field selection to disable the UPS feature.

*On = Enabled. Off = Disabled.*

DIP switch 2: *On = Always*

DIP switch 3: Not Used.

DIP switch 4: DDC Output at EH2 - provides selection for DDC operation. If set to "DDC Output at EH2," the EH2 terminal will continuously output the last fault code of the controller. If set to "EH2 normal," EH2 will operate as standard electric heat output.

*On = EH2 Normal. Off = DDC Output at EH2.*

DIP switch 5: Factory Setting - Normal position is "On." Do not change selection unless instructed to do so by the factory.

**Table 6: CXM LED And Alarm Relay Operations**

Description of Operation	LED	Alarm Relay
Normal Mode	On	Open
Normal Mode with UPS Warning	On	Cycle (closed 5 sec., Open 25 sec.)
CXM is non-functional	Off	Open
Fault Retry	Slow Flash	Open
Lockout	Fast Flash	Closed
Over/Under Voltage Shutdown	Slow Flash	Open (Closed after 15 minutes)
Test Mode - No fault in memory	Flashing Code 1	Cycling Code 1
Test Mode - HP Fault in memory	Flashing Code 2	Cycling Code 2
Test Mode - LP Fault in memory	Flashing Code 3	Cycling Code 3
Test Mode - FP1 Fault in memory	Flashing Code 4	Cycling Code 4
Test Mode - FP2 Fault in memory	Flashing Code 5	Cycling Code 5
Test Mode - CO Fault in memory	Flashing Code 6	Cycling Code 6
Test Mode - Over/Under shutdown in memory	Flashing Code 7	Cycling Code 7
Test Mode - UPS in memory	Flashing Code 8	Cycling Code 8
Test Mode - Swapped Thermistor	Flashing Code 9	Cycling Code 9

-Slow Flash = 1 flash every 2 seconds

-Fast Flash = 2 flashes every 1 second

-Flash code 2 = 2 quick flashes, 10 second pause, 2 quick flashes, 10 second pause, etc.

-On pulse 1/3 second; off pulse 1/3 second

## CONTROLS - SAFETY FEATURES

### Safety Features – CXM Control

The safety features below are provided to protect the compressor, heat exchangers, wiring and other components from damage caused by operation outside of design conditions.

Anti-short cycle protection: The control features a 5 minute anti-short cycle protection for the compressor.

**Note:** The 5 minute anti-short cycle also occurs at power up.

Random start: The control features a random start upon power up of 5-80 seconds.

Fault Retry: In Fault Retry mode, the Status LED begins slowly flashing to signal that the control is trying to recover from a fault input. The control will stage off the outputs and then "try again" to satisfy the thermostat input call. Once the thermostat input call is satisfied, the control will continue on as if no fault occurred. If 3 consecutive faults occur without satisfying the thermostat input call, the control will go into "lockout" mode. The last fault causing the lockout will be stored in memory and can be viewed by going into test mode on the CXM board. **Note:** FP1/FP2 faults are factory set at only one try.

Lockout: In lockout mode, the status LED will begin fast flashing. The compressor relay is turned off immediately. Lockout mode can be "soft" reset by turning off the thermostat (or satisfying the call). A "soft" reset keeps the fault in memory but resets the control. A "hard" reset (disconnecting power to the control) resets the control and erases fault memory.

Lockout with emergency heat: While in lockout mode, if W becomes active, emergency heat mode will occur.

## SAFETY FEATURES - CXM CONTROLS

High pressure switch: When the high pressure switch opens due to high refrigerant pressures, the compressor relay is de-energized immediately since the high pressure switch is in series with the compressor contactor coil. The high pressure fault recognition is immediate (does not delay for 30 continuous seconds before de-energizing the compressor).

*High pressure lockout code = 2*

Example: 2 quick flashes, 10 sec pause, 2 quick flashes, 10 sec. pause, etc.

Low pressure switch: The low pressure switch must be open and remain open for 30 continuous seconds during “on” cycle to be recognized as a low pressure fault. If the low pressure switch is open for 30 seconds prior to compressor power up it will be considered a low pressure (loss of charge) fault. The low pressure switch input is bypassed for the initial 60 seconds of a compressor run cycle.

*Low pressure lockout code = 3*

Water coil low temperature (FP1): The FP1 thermistor temperature must be below the 30°F low temperature limit setting for 30 continuous seconds during a compressor run cycle to be recognized as a FP1 fault. The FP1 input is bypassed for the initial 60 seconds of a compressor run cycle. FP1 is set at the factory for one try. Therefore, the control will go into lockout mode once the FP1 fault has occurred.

*FP1 lockout code = 4*

Air coil low temperature (FP2): The FP2 thermistor temperature must be below the selected low temperature limit setting for 30 continuous seconds during a compressor run cycle to be recognized as a FP2 fault. The FP2 input is bypassed for the initial 60 seconds of a compressor run cycle. FP2 is set at the factory for one try. Therefore, the control will go into lockout mode once the FP2 fault has occurred.

*FP2 lockout code = 5*

Condensate overflow: The condensate overflow sensor must sense overflow level for 30 continuous seconds to be recognized as a CO fault. Condensate overflow will be monitored at all times.

*CO lockout code = 6*

Over/under voltage shutdown: An over/under voltage condition exists when the control voltage is outside the range of 19VAC to 30VAC. Over/under voltage shutdown is a self-resetting safety. If the voltage comes back within range for at least 0.5 seconds, normal operation is restored. This is not considered a fault or lockout. If the CXM is in over/under voltage shutdown for 15 minutes, the alarm relay will close.

*Over/under voltage shut down code = 7*

Unit Performance Sentinel-UPS (patent pending): The UPS feature indicates when the heat pump is operating inefficiently. A UPS condition exists when:

- a) In heating mode with compressor energized, FP2 is greater than 125°F [52°C] for 30 continuous seconds, or:
- b) In cooling mode with compressor energized, FP1 is greater than 125°F [52°C] for 30 continuous seconds, or:

- c) In cooling mode with compressor energized, FP2 is less than 40°F [4.5°C] for 30 continuous seconds.

If a UPS condition occurs, the control will immediately go to UPS warning. The status LED will remain on as if the control is in normal mode. Outputs of the control, excluding LED and alarm relay, will NOT be affected by UPS. The UPS condition cannot occur during a compressor off cycle. During UPS warning, the alarm relay will cycle on and off. The cycle rate will be “on” for 5 seconds, “off” for 25 seconds, “on” for 5 seconds, “off” for 25 seconds, etc.

*UPS warning code = 8*

Swapped FP1/FP2 thermistors: During test mode, the control monitors to see if the FP1 and FP2 thermistors are in the appropriate places. If the control is in test mode, the control will lockout with code 9 after 30 seconds if:

- a) The compressor is on in the cooling mode and the FP1 sensor is colder than the FP2 sensor, or:
- b) The compressor is on in the heating mode and the FP2 sensor is colder than the FP1 sensor.

*Swapped FP1/FP2 thermistor code = 9.*

## CXM CONTROL

### Diagnostic Features

The LED on the CXM board advises the technician of the current status of the CXM control. The LED can display either the current CXM mode or the last fault in memory if in test mode. If there is no fault in memory, the LED will flash Code 1 (when in test mode).

### Control Start-up Operation

The control will not operate until all inputs and safety controls are checked for normal conditions. The compressor will have a 5 minute anti-short cycle delay at power-up. The first time after power-up that there is a call for compressor, the compressor will follow a 5 to 80 second random start delay. After the random start delay and anti-short cycle delay, the compressor relay will be energized. On all subsequent compressor calls, the random start delay is omitted.



# UNIT STARTING AND OPERATING CONDITIONS

## Operating Limits

Environment – Units are designed for indoor installation only. Never install units in areas subject to freezing or where humidity levels could cause cabinet condensation (such as unconditioned spaces subject to 100% outside air).

Power Supply – A voltage variation of +/- 10% of nameplate utilization voltage is acceptable.

## Starting Conditions

Consult Table 7 for starting conditions. vary depending upon model number and are based upon the following notes:

### Notes:

1. Conditions in Table 7 are not normal or continuous operating conditions. Minimum/maximum limits are

start-up conditions to bring the building space up to occupancy temperatures. Units are not designed to operate under these conditions on a regular basis.

2. Voltage utilization range complies with ARI Standard 110.

Determination of operating limits is dependent primarily upon three factors: 1) return air temperature. 2) water temperature, and 3) ambient temperature. When any one of these factors is at minimum or maximum levels, the other two factors should be at normal levels to insure proper unit operation.

Extreme variations in temperature and humidity and/or corrosive water or air will adversely affect unit performance, reliability, and service life.

**Table 7: Operating Limits**

Operating Limits	HCH/HCV	
	Cooling	Heating
<b>Air Limits</b>		
Min. ambient air, DB	45°F [7°C]	39°F [4°C]
Rated ambient air, DB	80.6°F [27°C]	68°F [20°C]
Max. ambient air, DB	110°F [43°C]	85°F [29°C]
Min. entering air, DB/WB	70/61°F [21/16°C]	50°F [10°C]
Rated entering air, DB/WB	80.6/66.2°F [27/19°C]	68°F [20°C]
Max. entering air, DB/WB	95/76°F [35/24°C]	80°F [27°C]
<b>Water Limits</b>		
Min. entering water	50°F [10°C]	50°F [10°C]
Normal entering water	60-90°F [15-32°C]	60-70°F [15-21°C]
Max. entering water	110°F [43°C]	90°F [32°C]
<b>Normal Water Flow</b>	2.5 to 3.0 gpm / ton [3.2 to 3.9 l/m per kW]	

# PIPING SYSTEM CLEANING AND FLUSHING

## Piping System Cleaning and Flushing

Cleaning and flushing the WLHP piping system is the single most important step to insure proper start-up and continued efficient operation of the system.

Follow the instructions below to properly clean and flush the system:

1. Insure that electrical power to the unit is disconnected.
2. Install the system with the supply hose connected directly to the return riser valve. Use a single length of flexible hose.
3. Open all air vents. Fill the system with water. DO NOT allow system to overflow. Bleed all air from the system. Pressurize and check the system for leaks and repair as appropriate.
4. Verify that all strainers are in place (Heat Controller recommends a strainer with a #20 stainless steel wire mesh). Start the pumps, and systematically check each vent to ensure that all air is bled from the system.
5. Verify that make-up water is available. Adjust make-up water as required to replace the air which was bled from the system. Check and adjust the water/air level in the expansion tank.
6. Set the boiler to raise the loop temperature to

approximately 86°F [30°C]. Open a drain at the lowest point in the system. Adjust the make-up water replacement rate to equal the rate of bleed.

7. Refill the system and add trisodium phosphate in a proportion of approximately one pound per 150 gallons [1/2 kg per 750 l] of water (or other equivalent approved cleaning agent). Reset the boiler to raise the loop temperature to 100°F [38°C]. Circulate the solution for a minimum of 8 to 24 hours. At the end of this period, shut off the circulating pump and drain the solution. Repeat system cleaning if desired.
8. When the cleaning process is complete, remove the short-circuited hoses. Reconnect the hoses to the proper supply, and return the connections to each of the units. Refill the system and bleed off all air.
9. Test the system pH with litmus paper. The system water should be in the range of pH 6.0 - 8.5 (see table 3). Add chemicals, as appropriate to maintain neutral pH levels.
10. When the system is successfully cleaned, flushed, refilled and bled, check the main system panels, safety cutouts and alarms. Set the controls to properly maintain loop temperatures.

## UNIT STARTING AND OPERATING CONDITIONS

DO NOT use “Stop Leak” or similar chemical agent in this system. Addition of chemicals of this type to the loop water will foul the heat exchanger and inhibit unit operation.

### ⚠ CAUTION! ⚠

**CAUTION!** To avoid possible damage to a plastic (PVC) piping system, do not allow temperatures to exceed 113°F [45°C].

## UNIT AND SYSTEM CHECKOUT

### Unit and System Checkout

BEFORE POWERING SYSTEM, please check the following:

#### UNIT CHECKOUT

- ❑ Balancing/shutoff valves: Insure that all isolation valves are open and water control valves are wired.
- ❑ Line voltage and wiring: Verify that voltage is within an acceptable range for the unit and wiring and fuses/breakers are properly sized. Verify that low voltage wiring is complete.
- ❑ Unit control transformer: Insure that transformer has the properly selected voltage tap. Commercial 208-230V units are factory wired for 208V operation unless specified otherwise.
- ❑ Entering water and air: Insure that entering water and air temperatures are within operating limits of Table 7.
- ❑ Unit fan: Manually rotate fan to verify free rotation and insure that blower wheel is secured to the motor shaft. Be sure to remove any shipping supports if needed. DO NOT oil motors upon start-up. Fan motors are pre-oiled at the factory. Check unit fan speed selection and compare to design requirements.
- ❑ Condensate line: Verify that condensate line is open and properly pitched toward drain.
- ❑ Water flow balancing: Record inlet and outlet water temperatures for each heat pump upon startup. This check can eliminate nuisance trip outs and high velocity water flow that could erode heat exchangers.
- ❑ Unit air coil and filters: Insure that filter is clean and accessible. Clean air coil of all manufacturing oils.
- ❑ Unit controls: Verify that CXM field selection options are properly set.

#### SYSTEM CHECKOUT

- ❑ System water temperature: Check water temperature for proper range and also verify heating and cooling set points for proper operation.
- ❑ System pH: Check and adjust water pH if necessary to maintain a level between 6 and 8.5. Proper pH promotes longevity of hoses and fittings (see table 3).
- ❑ System flushing: Verify that all hoses are connected end to end when flushing to insure that debris bypasses the unit heat exchanger, water valves and other components. Water used in the system must be potable quality initially and clean of dirt, piping slag, and strong chemical cleaning agents. Verify that all

air is purged from the system. Air in the system can cause poor operation or system corrosion.

- ❑ Cooling tower/boiler: Check equipment for proper set points and operation.
- ❑ Standby pumps: Verify that the standby pump is properly installed and in operating condition.
- ❑ System controls: Verify that system controls function and operate in the proper sequence.
- ❑ Low water temperature cutout: Verify that low water temperature cut-out controls are provided for the outdoor portion of the loop. Otherwise, operating problems may occur.
- ❑ System control center: Verify that the control center and alarm panel have appropriate set points and are operating as designed.
- ❑ Miscellaneous: Note any questionable aspects of the installation.

### ⚠ CAUTION! ⚠

**CAUTION!** Verify that ALL water control valves are open and allow water flow prior to engaging the compressor. Freezing of the coax or water lines can permanently damage the heat pump.

### ⚠ CAUTION! ⚠

**CAUTION!** To avoid equipment damage, DO NOT leave system filled in a building without heat during the winter unless antifreeze is added to the water loop. Heat exchangers never fully drain by themselves and will freeze unless winterized with antifreeze.

## UNIT START-UP

### Unit Start-up Procedure

1. Turn the thermostat fan position to “ON.” Blower should start.
2. Balance air flow at registers.
3. Adjust all valves to their full open position. Turn on the line power to all heat pump units.
4. Room temperature should be within the minimum-maximum ranges of table 7. During start-up checks, loop water temperature entering the heat pump should be between 60°F [16°C] and 95°F [35°C].

## UNIT START-UP PROCEDURE

5. Two factors determine the operating limits of Heat Controller heat pumps, (a) return air temperature, and (b) water temperature. When any one of these factors is at a minimum or maximum level, the other factor must be at normal level to insure proper unit operation.
  - a. Adjust the unit thermostat to the warmest setting. Place the thermostat mode switch in the "COOL" position. Slowly reduce thermostat setting until the compressor activates.
  - b. Check for cool air delivery at the unit grille within a few minutes after the unit has begun to operate. Note: Units have a five minute time delay in the control circuit that can be eliminated on the CXM control board as shown below in Figure 27. See controls description for details.
  - c. Verify that the compressor is on and that the water flow rate is correct by measuring pressure drop through the heat exchanger using the P/T plugs and comparing to tables 8a through 8e.
  - d. Check the elevation and cleanliness of the condensate lines. Dripping may be a sign of a blocked line. Check that the condensate trap is filled to provide a water seal.
  - e. Refer to table 9. Check the temperature of both entering and leaving water. If temperature is within range, proceed with the test. If temperature is outside of the operating range, check refrigerant pressures and compare to table 13. Verify correct water flow by comparing unit pressure drop across the heat exchanger versus the data in tables 8a through 8e. Heat of rejection (HR) can be calculated and compared to submittal data capacity pages. The formula for HR for systems with water is as follows:  

$$HR = TD \times GPM \times 500$$
 where TD is the temperature difference between the entering and leaving water, and GPM is the flow rate in U.S. GPM, determined by comparing the pressure drop across the heat exchanger to table 8.
  - f. Check air temperature drop across the air coil when compressor is operating. Air temperature drop should be between 15°F and 25°F [8°C and 14°C].
  - g. Turn thermostat to "OFF" position. A hissing noise indicates proper functioning of the reversing valve.
6. Allow five (5) minutes between tests for pressure to equalize before beginning heating test.
  - a. Adjust the thermostat to the lowest setting. Place the thermostat mode switch in the "HEAT" position.
  - b. Slowly raise the thermostat to a higher temperature until the compressor activates.
  - c. Check for warm air delivery within a few minutes after the unit has begun to operate.
  - d. Refer to table 9. Check the temperature of both entering and leaving water. If temperature is within range, proceed with the test. If temperature is outside of the operating range, check refrigerant pressures and compare to table 13. Verify correct

water flow by comparing unit pressure drop across the heat exchanger versus the data in table 8. Heat of extraction (HE) can be calculated and compared to submittal data capacity pages. The formula for HE for systems with water is as follows:  

$$HE = TD \times GPM \times 500$$
 where TD is the temperature difference between the entering and leaving water, and GPM is the flow rate in U.S. GPM, determined by comparing the pressure drop across the heat exchanger to table 8.

- e. Check air temperature rise across the air coil when compressor is operating. Air temperature rise should be between 20°F and 30°F [11°C and 17°C].
- f. Check for vibration, noise, and water leaks.
7. If unit fails to operate, perform troubleshooting analysis (see troubleshooting section). If the check described fails to reveal the problem and the unit still does not operate, contact a trained service technician to insure proper diagnosis and repair of the equipment.
8. When testing is complete, set system to maintain desired comfort level.
9. BE CERTAIN TO FILL OUT AND FORWARD ALL WARRANTY REGISTRATION PAPERS TO HEAT CONTROLLER.

Note: If performance during any mode appears abnormal, refer to the CXM section or troubleshooting section of this manual. To obtain maximum performance, the air coil should be cleaned before start-up. A 10% solution of dishwasher detergent and water is recommended.


**⚠ WARNING! ⚠**

**WARNING!** When the disconnect switch is closed, high voltage is present in some areas of the electrical panel. Exercise caution when working with energized equipment.

**⚠ CAUTION! ⚠**

**CAUTION!** Verify that ALL water control valves are open and allow water flow prior to engaging the compressor. Freezing of the coax or water lines can permanently damage the heat pump.

**Figure 27: Test Mode Pins**



## UNIT OPERATING CONDITIONS

**Table 8e: HCH\_HCV Coax Water Pressure**

Model	GPM	Pressure Drop (psi)			
		60°F	70°F	80°F	90°F
H006	0.9	0.7	0.7	0.7	0.6
	1.1	1.2	1.2	1.2	1.1
	1.7	1.9	1.9	1.8	1.8
	2.0	2.9	2.8	2.7	2.6
H/V009	1.1	2.4	2.3	2.3	2.2
	1.7	3.1	3.0	2.9	2.8
	2.3	4.0	3.9	3.8	3.7
	3.0	5.4	5.3	5.1	4.9
H/V012	1.5	2.3	2.2	2.1	2.1
	2.3	4.4	4.3	4.2	4.0
	3.0	6.4	6.2	6.0	5.8
	4.0	13.3	12.9	12.6	12.2
H/V018	2.3	2.0	2.0	1.9	1.8
	3.5	3.1	3.0	2.9	2.8
	4.5	4.2	4.1	3.9	3.8
	6.0	5.9	5.7	5.6	5.4
H/V024	3.0	2.0	1.9	1.8	1.8
	4.5	3.9	3.7	3.6	3.5
	6.0	6.4	6.2	6.0	5.8
	8.0	10.6	10.3	10.0	9.7
H/V030	3.8	1.5	1.5	1.4	1.4
	5.5	2.7	2.6	2.5	2.4
	7.5	4.3	4.2	4.1	3.9
	10.0	6.9	6.7	6.5	6.3
H/V036	4.5	1.7	1.7	1.6	1.6
	6.8	3.2	3.1	3.0	2.9
	9.0	5.0	4.9	4.8	4.6
	12.0	8.2	7.9	7.7	7.5
H/V042	5.3	1.0	1.0	1.0	0.9
	8.0	2.6	2.6	2.5	2.4
	11.0	5.3	5.1	4.9	4.8
	14.0	8.7	8.5	8.2	8.0
H/V048	6.0	1.2	1.2	1.2	1.1
	9.0	2.9	2.8	2.7	2.6
	12.0	5.3	5.1	4.9	4.8
	16.0	9.5	9.2	8.9	8.6
H/V060	7.5	4.4	4.2	4.1	4.0
	11.3	7.6	7.3	7.1	6.9
	15.0	11.4	11.1	10.8	10.4
	20.0	17.6	17.1	16.6	16.1

Rev: 08/27/03 B

**Table 9: Water Temperature Change Through Heat Exchanger**

Water Flow, gpm (l/m)	Rise, Cooling °F (°C)	Drop, Heating °F (°C)
For Closed Loop Systems at 3 gpm per ton (3.9 l/m per kw)	9 - 12 (5 - 6.7)	4 - 8 (2.2 - 4.4)

## UNIT OPERATING CONDITIONS

NOTE: Table 13 include the following notes:

- Airflow is at nominal (rated) conditions;
- Entering air is based upon 70°F (21°C) DB in heating and 80/67°F (27/19°C) in cooling;
- Subcooling is based upon head pressure at compressor service port;
- HC series units have cap tube expansion devices;
- Cooling air and water values can vary greatly with changes in humidity level.

**Table 13: HC Series Typical Unit Operating Pressures and Temperatures**

Entering Water Temp °F	Water Flow GPM/ton	Cooling						Heating					
		Suction Pressure	Discharge Pressure	Super-heat	Sub-cooling	Water Temp Rise °F	Air Temp Drop °F DB	Suction Pressure	Discharge Pressure	Super-heat	Sub-cooling	Water Temp Drop °F DB	Air Temp Rise °F
		PSIG	PSIG					PSIG	PSIG				
60	1.5	66-75	160-190	10-20	6-16	20-23	20-25	60-70	205-230	10-18	1-5	12.1-14	23-29
	2.3	65-75	145-175	15-25	8-18	12-15	20-25	63-73	210-238	10-18	1-5	7.2-9.0	24-30
	3.0	64-74	130-160	20-30	10-20	8-12	20-25	65-75	215-242	10-18	1-5	5.8-6.9	25-31
70	1.5	71-82	200-230	10-20	6-16	19-22	19-24	66-72	205-230	15-25	2-8	14.0-15.2	28-34
	2.3	70-80	185-215	15-25	8-18	12-17	19-24	68-74	210-238	15-25	2-8	9.0-10.2	30-37
	3.0	69-79	175-205	20-30	10-20	7-12	19-24	70-76	215-242	15-25	2-8	6.7-7.9	31-38
80	1.5	75-85	230-260	10-16	5-12	19-22	18-23	68-74	205-230	20-35	2-10	14.2-15.9	32-39
	2.3	74-84	215-245	13-20	7-14	12-17	18-23	70-76	210-238	20-35	2-10	9.9-11.1	33-41
	3.0	72-82	200-230	15-25	8-15	7-12	18-23	72-76	215-242	20-35	2-10	6.9-8.1	35-42
90	1.5	79-90	260-290	2-8	1-8	18-21	17-23						
	2.3	77-88	245-275	5-12	2-9	10-14	17-23						
	3.0	75-87	230-260	8-16	3-10	6-11	17-23						

# PREVENTIVE MAINTENANCE

## Water Coil Maintenance

Generally water coil maintenance is not needed for closed loop systems. However, if the piping is known to have high dirt or debris content, it is best to establish a periodic maintenance schedule with the owner so the water coil can be checked regularly. Dirty installations are typically the result of deterioration of iron or galvanized piping or components in the system. Open cooling towers requiring heavy chemical treatment and mineral buildup through water use can also contribute to higher maintenance. Should periodic coil cleaning be necessary, use standard coil cleaning procedures, which are compatible with both the heat exchanger material and copper water lines. Generally, the more water flowing through the unit, the less chance for scaling. However, flow rates over 3 gpm per ton (3.9 l/m per kW) can produce water (or debris) velocities that can erode the heat exchanger wall and ultimately produce leaks.

## Filters

Filters must be clean to obtain maximum performance. Filters should be inspected every month under normal operating conditions and be replaced when necessary. Units should never be operated without a filter.

Washable, high efficiency, electrostatic filters, when dirty, can exhibit a very high pressure drop for the fan motor and reduce air flow, resulting in poor performance. It is especially important to provide consistent washing of these filters (in the opposite direction of the normal air flow) once per month using a high pressure wash similar to those found at self-serve car washes.

## Condensate Drain

In areas where airborne bacteria may produce a "slimy" substance in the drain pan, it may be necessary to treat the drain pan chemically with an algaecide approximately every three months to minimize the problem. The condensate pan may also need to be cleaned periodically to insure indoor air quality. The condensate drain can pick up lint and dirt, especially with dirty filters. Inspect the drain twice a year to avoid the possibility of plugging and eventual overflow.

## Compressor

Conduct annual amperage checks to insure that amp draw is no more than 10% greater than indicated on the serial plate data.

## Fan Motors

All units have lubricated fan motors. Fan motors should never be lubricated unless obvious, dry operation is suspected. Periodic maintenance oiling is not recommended, as it will result in dirt accumulating in the excess oil and cause eventual motor failure. Conduct annual dry operation check and amperage check to insure amp draw is no more than 10% greater than indicated on serial plate data.

## Air Coil

The air coil must be cleaned to obtain maximum performance. Check once a year under normal operating conditions and, if dirty, brush or vacuum clean. Care must be taken not to damage the aluminum fins while cleaning. CAUTION: Fin edges are sharp.

## Cabinet

Do not allow water to stay in contact with the cabinet for long periods of time to prevent corrosion of the cabinet sheet metal. Generally, vertical cabinets are set up from the floor a few inches [7 - 8 cm] to prevent water from entering the cabinet. The cabinet can be cleaned using a mild detergent.

## Refrigerant System

To maintain sealed circuit integrity, do not install service gauges unless unit operation appears abnormal. Reference the operating charts for pressures and temperatures. Verify that air and water flow rates are at proper levels before servicing the refrigerant circuit.

# FUNCTIONAL TROUBLESHOOTING

Fault	Htg	Clg	Possible Cause	Solution	
<b>Main power Problems</b>	X	X	Green Status LED Off	Check Line Voltage circuit breaker and disconnect Check for line voltage between L1 and L2 on the contactor Check for 24VAC between R and C on CXM Check primary/secondary voltage on transformer	
		X	Reduced or no water flow in cooling	Check pump operation or valve operation/setting Check water flow adjust to proper flow rate	
		X	Water Temperature out of range in cooling	Bring water temp within design parameters	
		X	Reduced or no Air flow in heating	Check for dirty air filter and clean or replace Check fan motor operation and airflow restrictions Dirty Air Coil- construction dust etc.  Too high of external static. Check static vs blower table	
<b>HP Fault-Code 2</b> High pressure	X		Air Temperature out of range in heating	Bring return air temp within design parameters	
	X	X	Overcharged with refrigerant	Check superheat/subcooling vs typical operating condition table	
	X	X	Bad HP Switch	Check switch continuity and operation. Replace	
	<b>LP/LOC Fault-Code 3</b> Low Pressure/Loss of Charge	X	X	Insufficient charge	Check for refrigerant leaks
		X		Compressor pump down at start-up	Check charge and start-up water flow
	<b>FP1 Fault - Code 4</b> Water Coil low temperature limit	X		Reduced or no water flow in heating	Check pump operation or water valve operation/setting Plugged strainer or filter. Clean or replace. Check water flow adjust to proper flow rate
X			Inadequate anti-freeze level	Check antifreeze density with hydrometer	
X			Water Temperature out of range	Bring water temp within design parameters	
X		X	Bad thermistor	Check temp and impedance correlation per chart	
<b>FP2 fault - Code 5</b> Air Coil low temperature limit		X	Reduced or no Air flow in cooling	Check for dirty air filter and clean or replace Check fan motor operation and airflow restrictions Too high of external static. Check static vs blower table	
		X	Air Temperature out of range	Too much cold vent air? Bring entering air temp within design parameters	
		X	Improper temperature limit setting (30°F vs 10°F)	Normal airside applications will require 30°F only	
	X	X	Bad thermistor	Check temp and impedance correlation per chart	
<b>Condensate Fault-Code 6</b>	X	X	Blocked Drain	Check for blockage and clean drain	
	X	X	Improper trap	Check trap dimensions and location ahead of vent	
		X	Poor Drainage	Check for piping slope away from unit Check slope of unit toward outlet Poor venting. Check vent location	
		X	Moisture on sensor	Check for moisture shorting to air coil	
<b>Over/Under Voltage-Code 7</b> (Auto resetting)	X	X	Under Voltage	Check power supply and 24VAC voltage before and during operation. Check power supply wire size Check compressor starting. Need hard start kit?  Check 24VAC and unit transformer tap for correct power supply voltage	
	X	X	Over Voltage	Check power supply voltage and 24VAC before and during operation.  Check 24VAC and unit transformer tap for correct power supply voltage	
<b>Unit Performance Sentinel-Code 8</b>	X		Heating mode FP2>125°F	Check for poor air flow or overcharged unit.	
		X	Cooling Mode FP1>125°F OR FP2< 40°F	Check for poor water flow, or air flow	
<b>No Fault Code Shown</b>	X	X	No compressor operation	See "Only fan operates"	
	X	X	Compressor Overload	Check and Replace if necessary	
	X	X	Control board	Reset power and check operation	
<b>Unit Short Cycles</b>	X	X	Dirty Air Filter	Check and Clean air filter	
	X	X	Unit in "Test Mode"	Reset power or wait 20 minutes for auto exit.	
	X	X	Unit selection	Unit may be oversized for space. Check sizing for actual load of space.	
	X	X	Compressor Overload	Check and Replace if necessary	
<b>Only Fan Runs</b>	X	X	Thermostat position	Insure thermostat set for heating or cooling operation	
	X	X	Unit locked out	Check for lockout codes. Reset power.	
	X	X	Compressor Overload	Check compressor overload. Replace if necessary.	
	X	X	Thermostat wiring	Check thermostat wiring at heat pump. Jumper Y and R for compressor operation in test mode.	

# FUNCTIONAL TROUBLESHOOTING

<b>Only Compressor Runs</b>	X	X	Thermostat wiring	Check G wiring at heat pump. Jumper G and R for fan operation.
	X	X	Fan motor relay	Jumper G and R for fan operation. Check for Line voltage across BR contacts. Check fan power enable relay operation (if present)
	X	X	Fan motor	Check for line voltage at motor. Check capacitor
	X	X	Thermostat wiring	Check thermostat wiring at heat pump. Jumper Y and R for compressor operation in test mode.
<b>Unit Doesn't Operate in Cooling</b>		X	Reversing Valve	Set for cooling demand and check 24VAC on RV coil and at CXM board. If RV is stuck, run high pressure up by reducing water flow and while operating engage and disengage RV coil voltage to push valve.
		X	Thermostat setup	Check for 'O' RV setup not 'B'
		X	Thermostat wiring	Check O wiring at heat pump. Jumper O and R for RV coil 'Click'.
		X	Thermostat wiring	Put thermostat in cooling mode. Check for 24VAC on O (check between C and O); check for 24VAC on W (check between W and C). There should be voltage on O, but not on W. If voltage is present on W, thermostat may be bad or wired incorrectly.


# PERFORMANCE TROUBLESHOOTING

Performance Troubleshooting	Htg	Clg	Possible Cause	Solution	
<b>Insufficient capacity/ Not cooling or heating properly</b>	X	X	Dirty Filter	Replace or clean	
	X		Reduced or no Air flow in heating	Check for dirty air filter and clean or replace Check fan motor operation and airflow restrictions Too high of external static. Check static vs blower table	
		X	Reduced or no Air flow in cooling	Check for dirty air filter and clean or replace Check fan motor operation and airflow restrictions Too high of external static. Check static vs blower table	
	X	X	Leaky duct work	Check supply and return air temperatures at the unit and at distant duct registers if significantly different, duct leaks are present	
	X	X	Low refrigerant charge	Check superheat and subcooling per chart	
	X	X	Restricted metering device	Check superheat and subcooling per chart. Replace.	
		X	Defective Reversing Valve	Perform RV touch test	
	X	X	Thermostat improperly located	Check location and for air drafts behind stat	
	X	X	Unit undersized	Recheck loads & sizing check sensible clg load and heat pump capacity	
	X	X	Scaling in water heat exchanger	Perform Scaling check and clean if necessary	
	X	X	Inlet Water too Hot or Cold	Check load, loop sizing, loop backfill, ground moisture.	
	<b>High Head Pressure</b>	X		Reduced or no Air flow in heating	Check for dirty air filter and clean or replace Check fan motor operation and airflow restrictions Too high of external static. Check static vs blower table
			X	Reduced or no water flow in cooling	Check pump operation or valve operation/setting Check water flow adjust to proper flow rate
		X	Inlet Water too Hot	Check load, loop sizing, loop backfill, ground moisture.	
X			Air Temperature out of range in heating	Bring return air temp within design parameters	
		X	Scaling in water heat exchanger	Perform Scaling check and clean if necessary	
X		X	Unit Overcharged	Check superheat and subcooling. Reweigh in charge	
X		X	Non-condensables insystem	Vacuum system and reweigh in charge	
X		X	Restricted metering device	Check superheat and subcooling per chart. Replace.	
<b>Low Suction Pressure</b>	X		Reduced water flow in heating	Check pump operation or water valve operation/setting Plugged strainer or filter. Clean or replace. Check water flow adjust to proper flow rate	
	X		Water Temperature out of range	Bring water temp within design parameters	
		X	Reduced Air flow in cooling	Check for dirty air filter and clean or replace Check fan motor operation and airflow restrictions Too high of external static. Check static vs blower table	
		X	Air Temperature out of range	Too much cold vent air? Bring entering air temp within design parameters	
	X	X	Insufficient charge	Check for refrigerant leaks	
<b>Low discharge air temperature in heating</b>	X		Too high of air flow	Check fan motor speed selection and airflow chart	
	X		Poor Performance	See 'Insufficient Capacity'	
<b>High humidity</b>		X	Too high of air flow	Check fan motor speed selection and airflow chart	
		X	Unit oversized	Recheck loads & sizing check sensible clg load and heat pump capacity	




# TROUBLESHOOTING FORM

## HEATING CYCLE ANALYSIS -



## COOLING CYCLE ANALYSIS -



Heat of Extraction (Absorption) or Heat of Rejection =

$$\text{_____ flow rate (gpm) x _____ temp.diff. (deg. F) x _____ fluid factor}^\dagger = \text{_____ (Btu/hr)}$$

Superheat = Suction temperature - suction saturation temp. = \_\_\_\_\_ (deg F)

Subcooling = Discharge saturation temp. - liquid line temp. = \_\_\_\_\_ (deg F)

<sup>†</sup>Use 500 for water, 485 for antifreeze.

Note: Never connect refrigerant gauges during startup procedures. Conduct water-side analysis using P/T ports to determine water flow and temperature difference. If water-side analysis shows poor performance, refrigerant troubleshooting may be required. Connect refrigerant gauges as a last resort.



**Specifications and performance data subject to change without notice.**

## HEAT CONTROLLER, INC.

1900 WELLWORTH AVENUE • JACKSON, MICHIGAN 49203

*THE QUALITY LEADER IN CONDITIONING AIR*

***visit us at [www.heatcontroller.com](http://www.heatcontroller.com)***



97B0016N01

JPC 11/05

7953-4006