

OUTDOOR UNIT

SERVICE MANUAL




No. OBHA733
REVISED EDITION-A

Models

**NAXSST09A112AA
NAXSST12A112AA
NAXSST15A112AA
NAXSST18A112AA
NAXSST24A112AA
NAYSST09A112AA
NAYSST12A112AA
NAYSST15A112AA
NAYSST18A112AA
NAYSST24A112AA**

**NAXSST09A112AB
NAXSST12A112AB
NAXSST15A112AB
NAYSST09A112AB
NAYSST12A112AB
NAYSST15A112AB**

Indoor unit service manual
NAXWST•A112AA, NAYWST•A112AA Series (OBHA732)



**NAXSST18A112AA
NAXSST24A112AA
NAYSST18A112AA
NAYSST24A112AA**

CONTENTS

1. TECHNICAL CHANGES	2
2. PART NAMES AND FUNCTIONS	3
3. SPECIFICATION	4
4. OUTLINES AND DIMENSIONS	8
5. WIRING DIAGRAM	10
6. REFRIGERANT SYSTEM DIAGRAM	16
7. DATA	19
8. ACTUATOR CONTROL	34
9. SERVICE FUNCTIONS	35
10. TROUBLESHOOTING	36
11. DISASSEMBLY INSTRUCTIONS	60

PARTS CATALOG (OBBA733)

Use the specified refrigerant only

Never use any refrigerant other than that specified.

Doing so may cause a burst, an explosion, or fire when the unit is being used, serviced, or disposed of.

Correct refrigerant is specified in the manuals and on the spec labels provided with our products.

We will not be held responsible for mechanical failure, system malfunction, unit breakdown or accidents caused by failure to follow the instructions.

Revision A:

- NAXSST09/12/15A112AB and NAYSST09/1215A112AB have been added.

1

TECHNICAL CHANGES

NAXSST09A112AA NAYSST09A112AA

NAXSST12A112AA NAYSST12A112AA

NAXSST15A112AA NAYSST15A112AA

NAXSST18A112AA NAYSST18A112AA

NAXSST24A112AA NAYSST24A112AA

1. New model

NAXSST09A112AA → NAXSST09A112AB

NAYSST09A112AA → NAYSST09A112AB

1. Fan motor has been changed.
2. INVERTER P.C. BOARD has been changed.
3. EXPANSION VALVE has been changed.
4. 4-WAY VALVE has been changed.
5. R.V. COIL has been changed.
6. Compressor has been changed.

NAXSST12A112AA → NAXSST12A112AB

NAYSST12A112AA → NAYSST12A112AB


1. Fan motor has been changed.
2. INVERTER P.C. BOARD has been changed.
3. EXPANSION VALVE has been changed.
4. 4-WAY VALVE has been changed.
5. R.V. COIL has been changed.

NAXSST15A112AA → NAXSST15A112AB


NAYSST15A112AA → NAYSST15A112AB

1. Fan motor has been changed.
2. INVERTER P.C. BOARD has been changed.
3. EXPANSION VALVE has been changed.

NAXSST09A112AA NAXSST09A112AB NAXSST12A112AA NAXSST12A112AB
NAXSST15A112AA NAXSST15A112AB NAYSST09A112AA NAYSST12A112AB
NAYSST15A112AA NAYSST15A112AB



NAXSST18A112AA NAXSST24A112AA
NAYSST18A112AA NAYSST24A112AA



Outdoor unit model			NAXSST09A112AA	NAYSST09A112AA	NAXSST09A112AB	NAYSST09A112AB
Capacity Rated (Minimum~Maximum)	Cooling *1	Btu/h	9,000 (3,600 - 12,200)	9,000 (3,600 - 12,200)	9,000 (3,600 - 12,200)	9,000 (3,600 - 12,200)
	Heating 47 *1 (NAXSST)	Btu/h	10,900 (4,500 - 15,900)	—	10,900 (4,500 - 15,900)	—
Capacity Rated (Maximum)	Heating 17 *2 (NAXSST)	Btu/h	6,700 (10,200)	—	6,700 (10,200)	—
Power consumption Rated (Minimum~Maximum)	Cooling *1	W	585 (240 - 1,050)	585 (240 - 1,050)	585 (240 - 1,050)	585 (240 - 1,050)
	Heating 47 *1 (NAXSST)	W	720 (230 - 1,250)	—	720 (230 - 1,250)	—
Power consumption Rated (Maximum)	Heating 17 *2 (NAXSST)	W	630 (1,060)	—	630 (1,060)	—
EER *1 [SEER] *3	Cooling		15.4 [24.6]	15.4 [24.6]	15.4 [24.6]	15.4 [24.6]
HSPF IV *4	Heating (NAXSST)		12.8	—	12.8	—
COP	Heating *1 (NAXSST)		4.44	—	4.44	—
Power factor	Cooling (208/230) %		86/86	87/87	86/86	86/86
	Heating (NAXSST) (208/230) %		90/90	—	90/90	—
Power supply	V , phase , Hz		208/230, 1 , 60	208/230, 1 , 60	208/230, 1 , 60	208/230, 1 , 60
Max. fuse size (time delay)	A		15	15	15	15
Min. circuit ampacity	A		9	7	9	7
Fan motor	F.L.A		0.50	0.50	0.50	0.50
Compressor	Model		KNB073FRVMC	KNB073FRVMC	KNB073FRXMC	KNB073FRXMC
	R.L.A	A	6.2	4.9	6.2	4.9
	L.R.A	A	7.7	6.1	7.7	6.1
	Refrigeration oil	oz. (L) (Model)	9.1 (0.27)/(FV50S)	9.1 (0.27)/(FV50S)	9.1 (0.27)/(FV50S)	9.1 (0.27)/(FV50S)
Refrigerant control			Linear expansion valve			
Sound level *1	Cooling	dB(A)	48	48	48	48
	Heating (NAXSST)	dB(A)	50	—	50	—
Airflow High - Med. - Low	Cooling	CFM	1,102 - 1,102 - 639	1,102 - 1,102 - 639	1,102 - 1,102 - 639	1,102 - 1,102 - 639
	Heating (NAXSST)	CFM	1,186 - 1,116 - 1,045	—	1,186 - 1,116 - 1,045	—
Fan speed High - Med. - Low	Cooling	rpm	810 - 810 - 490	810 - 810 - 490	810 - 810 - 490	810 - 810 - 490
	Heating (NAXSST)	rpm	870 - 820 - 770	—	870 - 820 - 770	—
Defrost method			Reverse cycle	—	Reverse cycle	—
Dimensions	W	in.	31-1/2			
	D	in.	11-1/4			
	H	in.	21-5/8			
Weight			81			
External finish			Munsell 3Y 7.8/1.1			
Remote controller			Wireless type			
Control voltage (by built-in transformer)		V DC	12 - 24			
Refrigerant piping			Not supplied			
Refrigerant pipe size (Min. wall thickness)	Liquid	in.	1/4 (0.0315)			
	Gas	in.	3/8 (0.0315)			
Connection method	Indoor		Flared			
	Outdoor		Flared			
Between the indoor & outdoor units	Height difference	ft.	40			
	Piping length	ft.	65			
Refrigerant charge (R410A)			2 lb. 5 oz.	2 lb. 9 oz.	2 lb. 5 oz.	2 lb. 5 oz.

NOTE: Test conditions are based on AHRI 210/240.

*1: Rating conditions (Cooling) — Indoor: 80°FDB, 67°FWB, Outdoor: 95°FDB, (75°FWB)
(Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 47°FDB, 43°FWB

*2: (Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 17°FDB, 15°FWB

*3: Test condition (Refer to 3-1.)

*4: Test condition (Refer to 3-1.)

--	--	--	--	--	--

Outdoor unit model			NAXSST12A112AA NAXSST12A112AB	NAYSST12A112AA NAYSST12A112AB	NAXSST15A112AA NAXSST15A112AB	NAYSST15A112AA NAYSST15A112AB
Capacity Rated (Minimum~Maximum)	Cooling *1	Btu/h	12,000 (1,500 - 13,600)	12,000 (1,500 - 13,600)	14,000 (3,100 - 18,200)	14,000 (3,100 - 18,200)
	Heating 47 *1 (NAXSST)	Btu/h	14,400 (2,000 - 18,100)	—	18,000 (4,800 - 20,900)	—
Capacity Rated (Maximum)	Heating 17 *2 (NAXSST)	Btu/h	9,200 (12,000)	—	12,200 (16,400)	—
Power consumption Rated (Minimum~Maximum)	Cooling *1	W	920 (100 - 1,300)	920 (100 - 1,300)	1,080 (210 - 2,000)	1,080 (210 - 2,000)
	Heating 47 *1 (NAXSST)	W	1,100 (110 - 1,620)	—	1,600 (200 ~ 2,010)	—
Power consumption Rated (Maximum)	Heating 17 *2 (NAXSST)	W	870 (1,240)	—	1,190 (1,850)	—
EER *1 [SEER] *3	Cooling		13.0 [23.1]	13.0 [23.1]	13.0 [21.6]	13.0 [21.6]
HSPF IV *4	Heating (NAXSST)		12.5	—	11.7	—
COP	Heating *1 (NAXSST)		3.84	—	3.30	—
Power factor	Cooling (208/230) %		95/95	95/95	97/97	97/97
	Heating (NAXSST) (208/230) %		96/96	96/96	98/98	98/98
Power supply	V , phase , Hz		208/230, 1 , 60	208/230, 1 , 60	208/230, 1 , 60	208/230, 1 , 60
Max. fuse size (time delay)	A		15	15	15	15
Min. circuit ampacity	A		9	7	10	9
Fan motor	F.L.A		0.50	0.50	0.50	0.50
Compressor	Model		SNB092FQAMT	SNB092FQAMT	SNB130FQBMT	SNB130FQBMT
	R.L.A	A	6.6	4.9	7.4	6.8
	L.R.A	A	8.2	6.1	9.3	8.5
	Refrigeration oil	fl.oz. (L) (Model)	11.8 (0.35)/(FV50S)		11.8 (0.35)/(FV50S)	
Refrigerant control			Linear expansion valve			
Sound level *1	Cooling	dB(A)	49	49	49	49
	Heating (NAXSST)	dB(A)	51	—	51	—
Airflow	Cooling	CFM	1,102 - 1,102 - 639	1,102 - 1,102 - 639	1,102 - 1,102 - 639	1,102 - 1,102 - 639
	Heating (NAXSST)	CFM	1,186 - 1,116 - 1,045	—	1,186 - 1,045 - 1,045	—
Fan speed	Cooling	rpm	810 - 810 - 490	810 - 810 - 490	810 - 810 - 490	810 - 810 - 490
	Heating (NAXSST)	rpm	870 - 820 - 770	—	870 - 770 - 770	—
Defrost method			Reverse cycle	—	Reverse cycle	—
Dimensions	W	in.		31-1/2		
	D	in.		11-1/4		
	H	in.		21-5/8		
Weight	lb.			81		
External finish				Munsell 3Y 7.8/1.1		
Remote controller				Wireless type		
Control voltage (by built-in transformer)	V DC			12 - 24		
Refrigerant piping				Not supplied		
Refrigerant pipe size (Min. wall thickness)	Liquid	in.		1/4 (0.0315)		
	Gas	in.		3/8 (0.0315)		
Connection method	Indoor			Flared		
	Outdoor			Flared		
Between the indoor & outdoor units	Height difference	ft.		40		
	Piping length	ft.		65		
Refrigerant charge (R410A)				2 lb. 9 oz.		

NOTE: Test conditions are based on AHRI 210/240.

*1: Rating conditions (Cooling) — Indoor: 80°FDB, 67°FWB, Outdoor: 95°FDB, (75°FWB)

(Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 47°FDB, 43°FWB

*2: (Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 17°FDB, 15°FWB

*3: Test condition (Refer to 3-1.)

*4: Test condition (Refer to 3-1.)



Outdoor unit model			NAXSST18A112AA	NAYSST18A112AA	NAXSST24A112AA	NAYSST24A112AA
Capacity Rated (Minimum~Maximum)	Cooling *1	Btu/h	18,000 (5,800 ~ 22,000)	18,000 (5,800 ~ 22,000)	22,500 (8,200 ~ 31,400)	22,500 (8,200 ~ 31,400)
	Heating 47 *1 (NAXSST)	Btu/h	21,600 (5,400 ~ 25,000)	—	27,600 (7,500 ~ 36,900)	—
Capacity Rated (Maximum)	Heating 17 *2 (NAXSST)	Btu/h	13,800 (18,200)	—	16,000 (24,600)	—
Power consumption Rated (Minimum~Maximum)	Cooling *1	W	1,340 (330 ~ 2,150)	1,340 (330 ~ 2,150)	1,800 (570 ~ 3,580)	1,800 (570 ~ 3,580)
	Heating 47 *1 (NAXSST)	W	1,680 (320 ~ 2,500)	1,680 (320 ~ 2,500)	2,340 (520 ~ 3,650)	2,340 (520 ~ 3,650)
Power consumption Rated (Maximum)	Heating 17 *2 (NAXSST)	W	1,480 (2,150)	—	1,770 (3,290)	—
EER *1 [SEER] *3	Cooling		13.4 [20.5]	13.4 [20.5]	12.5 [20.5]	12.5 [20.5]
HSPF IV *4	Heating (NAXSST)		11.2	—	10.0	—
COP	Heating *1 (NAXSST)		3.77	—	3.46	—
Power factor	Cooling (208/230) %		99/99	99/99	99/99	99/99
	Heating (NAXSST) (208/230) %		99/99	—	99/99	—
Power supply	V , phase , Hz		208/230, 1 , 60	208/230, 1 , 60	208/230, 1 , 60	208/230, 1 , 60
Max. fuse size (time delay)	A		15	15	20	20
Min. circuit ampacity	A		14	14	17.1	17.1
Fan motor	F.L.A		0.93	0.93	0.93	0.93
Compressor	Model		SNB130FQBMT	SNB130FQBMT	SNB172FQKMT	SNB172FQKMT
	R.L.A	A	10	10	12.9	12.9
	L.R.A	A	12.5	12.5	16.1	16.1
	Refrigeration oil	fl.oz. (L) (Model)	11.8 (0.35)/(FV50S)	11.8 (0.35)/(FV50S)	13.5 (0.40)/(FV50S)	13.5 (0.40)/(FV50S)
Refrigerant control			Linear expansion valve			
Sound level *1	Cooling	dB(A)	54	54	55	55
	Heating (NAXSST)	dB(A)	55	—	55	—
Airflow High - Med. - Low	Cooling	CFM	1,742 - 1,742 - 922	1,742 - 1,742 - 922	2,016 - 1,769 - 890	2,016 - 1,769 - 890
	Heating (NAXSST)	CFM	1,691 - 1,691 - 1,372	—	1,701 - 1,701 - 1,341	—
Fan speed High - Med. - Low	Cooling	rpm	840 - 840 - 450	840 - 840 - 450	950 - 840 - 450	950 - 840 - 450
	Heating (NAXSST)	rpm	810 - 810 - 650	—	810 - 810 - 650	—
Defrost method			Reverse cycle	—	Reverse cycle	—
Dimensions	W	in.	33-1/16			
	D	in.	13			
	H	in.	34-5/8			
Weight	lb.		121	121	119	119
External finish			Munsell 3Y 7.8/1.1			
Remote controller			Wireless type			
Control voltage (by built-in transformer)	V DC		12 - 24			
Refrigerant piping			Not supplied			
Refrigerant pipe size (Min. wall thickness)	Liquid	in.	1/4 (0.0315)	1/4 (0.0315)	3/8 (0.0315)	3/8 (0.0315)
	Gas	in.	1/2 (0.0315)	1/2 (0.0315)	5/8 (0.0315)	5/8 (0.0315)
Connection method	Indoor		Flared			
	Outdoor		Flared			
Between the indoor & outdoor units	Height difference	ft.	50			
	Piping length	ft.	100			
Refrigerant charge (R410A)			3 lb. 9 oz.	3 lb. 9 oz.	4 lb. 3 oz.	4 lb. 3 oz.

NOTE: Test conditions are based on AHRI 210/240.

*1: Rating conditions (Cooling) — Indoor: 80°FDB, 67°FWB, Outdoor: 95°FDB, (75°FWB)
(Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 47°FDB, 43°FWB

*2: (Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 17°FDB, 15°FWB

*3: Test condition (Refer to 3-1.)

*4: Test condition (Refer to 3-1.)

3-1. TEST CONDITION

*3,*4

ARI	Mode	Test	Indoor air condition (°F)		Outdoor air condition (°F)	
			Dry bulb	Wet bulb	Dry bulb	Wet bulb
SEER (Cooling)	HSPF (Heating)	"A-2" Cooling Steady State at rated compressor Speed	80	67	95	(75)
		"B-2" Cooling Steady State at rated compressor Speed	80	67	82	(65)
		"B-1" Cooling Steady State at minimum compressor Speed	80	67	82	(65)
		"F-1" Cooling Steady State at minimum compressor Speed	80	67	67	(53.5)
		"E-V" Cooling Steady State at intermediate compressor Speed *5	80	67	87	(69)
		"H1-2" Heating Steady State at rated compressor Speed	70	60	47	43
		"H3-2" Heating at rated compressor Speed	70	60	17	15
		"H0-1" Heating Steady State at minimum compressor Speed	70	60	62	56.5
		"H1-1" Heating Steady State at minimum compressor Speed	70	60	47	43
		"H2-V" Heating at intermediate compressor Speed *5	70	60	35	33

NOTE:

*5: At intermediate compressor Speed

= ("Rated compressor speed" - "minimum compressor speed") / 3 + "minimum compressor speed".

3-2. OPERATING RANGE

(1) POWER SUPPLY

	Rated voltage	Guaranteed voltage (V)
Outdoor unit	208/230 V 1 phase 60 Hz	Min. 187 208 230 Max. 253

(2) OPERATION


Mode	Condition	Intake air temperature (°F)			
		Indoor		Outdoor	
		DB	WB	DB	WB
Cooling	Standard temperature	80	67	95	—
	Maximum temperature	90	73	115	—
	Minimum temperature	67	57	14	—
	Maximum humidity	78 %		—	
Heating	Standard temperature	70	60	47	43
	Maximum temperature	80	67	75	65
	Minimum temperature	70	60	-4	-5

**NAXSST09A112AA NAXSST09A112AB NAXSST12A112AA NAXSST12A112AB
 NAXSST15A112AA NAXSST15A112AB
 NAYSST09A112AA NAYSST09A112AB NAYSST12A112AA NAYSST12A112AB
 NAYSST15A112AA NAYSST15A112AB**




Unit: inch

REQUIRED SPACE

*1 4 in. (100 mm) or more when front and sides of the unit are clear



*2 When any 2 sides of left, right and rear of the unit are clear







**NAXSST18A112AA NAXSST24A112AA
NAYSST18A112AA NAYSST24A112AA**


Unit: inch

REQUIRED SPACE

*1 20 in. (500 mm) or more when front and sides of the unit are clear




NAXSST09A112AA NAXSST12A112AA




SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CN61	CONNECTOR	LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR
C61,C62	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61	DIODE MODULE	MC	COMPRESSOR		
F701,F801,F901	FUSE (T3, 15AL250V)	MF	FAN MOTOR	TB	TERMINAL BLOCK
H	DEFROST HEATER(OPTION PARTS)	PTC64,PTC65	CIRCUIT PROTECTION	T801	TRANSFORMER
IC700,IC820,IC932	POWER MODULE	RT61	DEFROST THERMISTOR	X63, X64, X66	RELAY
IC802	POWER DEVICE	RT62	DISCHARGE TEMP. THERMISTOR	21S4	REVERSING VALVE COIL
LED	LED	RT64	FIN TEMP. THERMISTOR	26H	HEATER PROTECTOR(OPTION PARTS)

NAXSST09A112AB NAXSST12A112AB




SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CN61	CONNECTOR	LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR
C61,C62	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61,DB65	DIODE MODULE	MC	COMPRESSOR	TB	TERMINAL BLOCK
F701,F801,F901	FUSE (T3, 15AL250V)	MF	FAN MOTOR		
H	DEFROST HEATER(OPTION PARTS)	Q821	SWITCHING POWER TRANSISTOR	T801	TRANSFORMER
IC700,IC932	POWER MODULE	RT61	DEFROST THERMISTOR	X63, X64, X66	RELAY
IC802	POWER DEVICE	RT62	DISCHARGE TEMP. THERMISTOR	21S4	REVERSING VALVE COIL
LED	LED	RT64	FIN TEMP. THERMISTOR	26H	HEATER PROTECTOR(OPTION PARTS)

NAYSST09A112AA NAYSST12A112AA




SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CN61	CONNECTOR	LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR
C61,C62	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61	DIODE MODULE	MC	COMPRESSOR	RT69	
F801,F901	FUSE (T3. 15AL250V)	MF	FAN MOTOR	TB	TERMINAL BLOCK
IC700,IC820,IC932	POWER MODULE	IC802	POWER DEVICE	T801	TRANSFORMER
IC932		LED	LED	RT64	RELAY

NAYSST09A112AB NAYSST12A112AB




SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CN61	CONNECTOR	LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR
C61,C62	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61,DB65	DIODE MODULE	MC	COMPRESSOR	RT69	
F801,F901	FUSE (T3. 15AL250V)	MF	FAN MOTOR	TB	TERMINAL BLOCK
IC700,IC820,IC932	POWER MODULE	Q821	SWITCHING POWER TRANSISTOR	T801	TRANSFORMER
IC802	POWER DEVICE	RT62	DISCHARGE TEMP. THERMISTOR	X64	RELAY
LED	LED	RT64	FIN TEMP. THERMISTOR		

NAXSST15A112AA




SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CN61	CONNECTOR	LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR
C61,C62,C63	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61	DIODE MODULE	MC	COMPRESSOR		
F701,F801,F901	FUSE (T3, 15AL250V)	MF	FAN MOTOR	TB	TERMINAL BLOCK
H	DEFROST HEATER(OPTION PARTS)	PTC64, PTC65	CIRCUIT PROTECTION	T801	TRANSFORMER
IC700,IC820,IC932	POWER MODULE	RT61	DEFROST THERMISTOR	X63, X64, X66	RELAY
IC802	POWER DEVICE	RT62	DISCHARGE TEMP. THERMISTOR	21S4	REVERSING VALVE COIL
LED	LED	RT64	FIN TEMP. THERMISTOR	26H	HEATER PROTECTOR(OPTION PARTS)

NAXSST15A112AB




SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CN61	CONNECTOR	LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR
C61,C62,C63	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61,DB65	DIODE MODULE	MC	COMPRESSOR	TB	TERMINAL BLOCK
F701,F801,F901	FUSE (T3, 15AL250V)	MF	FAN MOTOR	T801	TRANSFORMER
H	DEFROST HEATER(OPTION PARTS)	Q821	SWITCHING POWER TRANSISTOR	X63, X64, X66	RELAY
IC700,IC932	POWER MODULE	RT61	DEFROST THERMISTOR	21S4	REVERSING VALVE COIL
IC802	POWER DEVICE	RT62	DISCHARGE TEMP. THERMISTOR	26H	HEATER PROTECTOR(OPTION PARTS)
LED	LED	RT64	FIN TEMP. THERMISTOR		

NAYSS15A112AA




SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CN61	CONNECTOR	LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR
C61,C62,C63	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61	DIODE MODULE	MC	COMPRESSOR	MF	FAN MOTOR
F801,F901	FUSE (T3, 15AL250V)	IC700,IC932	POWER MODULE	PTC64,PTC65	CIRCUIT PROTECTION
IC802	POWER DEVICE	LED	LED	RT62	DISCHARGE TEMP. THERMISTOR
RT64		RT64		RT64	FIN TEMP. THERMISTOR

NAYSS15A112AB




SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CN61	CONNECTOR	LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR
C61,C62,C63	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61,DB65	DIODE MODULE	MC	COMPRESSOR	MF	FAN MOTOR
F801,F901	FUSE (T3, 15AL250V)	IC700,IC932	POWER MODULE	Q821	SWITCHING POWER TRANSISTOR
IC802	POWER DEVICE	LED	LED	RT62	DISCHARGE TEMP. THERMISTOR
RT64		RT64		X64	RELAY

NAXSST18A112AA




NAYSST18A112AA



SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CN61	CONNECTOR	LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR
C61,C62,C63	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61	DIODE MODULE	MC	COMPRESSOR	TB	TERMINAL BLOCK
F801,F901	FUSE (T3.15AL250V)	MF	FAN MOTOR	T801	TRANSFORMER
IC700,IC820,IC932	POWER MODULE	PTC64,PTC65	CIRCUIT PROTECTION		
IC802	POWER DEVICE	RT62	DISCHARGE TEMP. THERMISTOR	X64	RELAY
LED	LED	RT64	FIN TEMP. THERMISTOR		

NAXSST24A112AA




SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CB1~3	SMOOTHING CAPACITOR	LED	LED	RT65	AMBIENT TEMP.THERMISTOR
F65, F66	FUSE (T6.3AL250V)	LEV	EXPANSION VALVE COIL	RT68	OUTDOOR HEAT EXCHANGER TEMP.THERMISTOR
F601	FUSE (T3.15AL250V)	MC	COMPRESSOR	TB1, TB2	TERMINAL BLOCK
F880	FUSE (T3.15AL250V)	MF	FAN MOTOR	T801	TRANSFORMER
F901	FUSE (T3.15AL250V)	PTC64	CIRCUIT PROTECTION	X601	RELAY
IC700	IGBT MODULE	PTC65	CIRCUIT PROTECTION	X602	RELAY
IC820	DIODE MODULE	RT61	DEFROST THERMISTOR	X64	RELAY
IC932	IGBT MODULE	RT62	DISCHARGE TEMP.THERMISTOR		
L	REACTOR	RT64	FIN TEMP.THERMISTOR	21S4	REVERSING VALVE COIL

NOTES
1. About the indoor side electric wiring, refer to the indoor unit electric wiring diagram for servicing.
2. Use copper supply wires.
3. Symbols indicate, : Terminal block : Connector

REMARQUES
1. Pour le câblage électrique côté intérieur, se reporter au schéma d'entretien du câblage électrique de l'appareil intérieur.
2. Utiliser des fils d'alimentation en cuivre.
3. Les symboles ont les significations suivantes, : Borne : Connecteur

NAYSST24A112AA



SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CB1~3	SMOOTHING CAPACITOR	LED	LED	RT64	FIN TEMP.THERMISTOR
F65, F66	FUSE (T6.3AL250V)	LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP.THERMISTOR
F880	FUSE (T3.15AL250V)	MC	COMPRESSOR	RT68	OUTDOOR HEAT EXCHANGER TEMP.THERMISTOR
F901	FUSE (T3.15AL250V)	MF	FAN MOTOR	TB1, TB2	TERMINAL BLOCK
IC700	IGBT MODULE	PTC64	CIRCUIT PROTECTION	T801	TRANSFORMER
IC820	DIODE MODULE	PTC65	CIRCUIT PROTECTION		
IC932	IGBT MODULE	RT62	DISCHARGE TEMP.THERMISTOR	X64	RELAY
L	REACTOR				


NOTES
1. About the indoor side electric wiring, refer to the indoor unit electric wiring diagram for servicing.
2. Use copper supply wires.
3. Symbols indicate, : Terminal block : Connector

REMARQUES
1. Pour le câblage électrique côté intérieur, se reporter au schéma d'entretien du câblage électrique de l'appareil intérieur.
2. Utiliser des fils d'alimentation en cuivre.
3. Les symboles ont les significations suivantes, : Borne : Connecteur


**NAXSST09A112AA NAXSST09A112AB NAXSST12A112AA NAXSST12A112AB
 NAXSST15A112AA NAXSST15A112AB
 NAYSST09A112AA NAYSST09A112AB NAYSST12A112AA NAYSST12A112AB
 NAYSST15A112AA NAYSST15A112AB**

Refrigerant pipe $\phi 3/8$ ($\phi 9.52$) (NAXSST09/12A112AA, NAYSST09/12A112AA
 NAXSST09/12A112AB, NAYSST09/12A112AB)
 $\phi 1/2$ ($\phi 12.7$) (NAXSST15A112AA, NAYSST15A112AA
 NAXSST15A112AB, NAYSST15A112AB)

Unit: Inch (mm)




NAXSST18A112AA NAYSST18A112AA




NAXSST24A112AA

Unit: Inch (mm)




NAYSST24A112AA



MAX. REFRIGERANT PIPING LENGTH and MAX. HEIGHT DIFFERENCE

Model	Refrigerant piping: ft.		Piping size O.D: in.	
	Max. Length A	Max. Height difference B	Gas	Liquid
NAXSST09A112AA	65	40	3/8	1/4
NAXSST09A112AB				
NAXSST12A112AA			1/2	
NAXSST12A112AB				
NAYSST09A112AA	100	50	5/8	3/8
NAYSST09A112AB				
NAYSST12A112AA			1/2	
NAYSST12A112AB				
NAXSST15A112AA			1/2	
NAXSST15A112AB				
NAYSST15A112AA			5/8	3/8
NAYSST15A112AB				
NAXSST18A112AA			5/8	3/8
NAYSST18A112AA				
NAXSST24A112AA			5/8	3/8
NAYSST24A112AA				



ADDITIONAL REFRIGERANT CHARGE (R410A: oz.)

NOTE: Refrigerant piping exceeding 25 ft. requires additional refrigerant charge according to the calculation.

Model	Outdoor unit precharged	Refrigerant piping length (one way): ft.					
		25	30	40	50	60	65
NAXSST09A112AA	2 lb. 5 oz.						
NAXSST09A112AB							
NAXSST12A112AA							
NAXSST12A112AB							
NAXSST15A112AA							
NAXSST15A112AB							
NAYSST09A112AA							
NAYSST09A112AB							
NAYSST12A112AA							
NAYSST12A112AB							
NAYSST15A112AA							
NAYSST15A112AB							
		0	1.08	3.24	5.40	7.56	8.64
	2 lb. 9 oz.						

Calculation: X oz. = 1.08/5 oz./ft. × (Refrigerant piping length (ft.) - 25)

NOTE: Refrigerant piping exceeding 25 ft. requires additional refrigerant charge according to the calculation.

Model	Outdoor unit precharged	Refrigerant piping length (one way): ft.								
		25	30	40	50	60	70	80	90	100
NAXSST18A112AA	3 lb. 9 oz.	0	1.08	3.24	5.40	7.56	9.72	11.88	14.04	16.20
NAYSST18A112AA										

Calculation: $X \text{ oz.} = 1.08/5 \text{ oz./ft.} \times (\text{Refrigerant piping length (ft.)} - 25)$

NOTE: Refrigerant piping exceeding 33 ft. requires additional refrigerant charge according to the calculation.

Model	Outdoor unit precharged	Refrigerant piping length (one way): ft.								
		33	40	50	60	70	80	90	100	
NAXSST24A112AA	4 lb. 3 oz.	0	4.14	10.06	15.98	21.90	27.82	33.74	39.66	
NAYSST24A112AA										

Calculation: $X \text{ oz.} = 2.96/5 \text{ oz./ft.} \times (\text{Refrigerant piping length (ft.)} - 33)$

7

DATA

**NAXSST09A112AA NAXSST09A112AB NAXSST12A112AA NAXSST12A112AB
NAXSST15A112AA NAXSST15A112AB NAXSST18A112AA NAXSST24A112AA
NAYSST09A112AA NAYSST09A112AB NAYSST12A112AA NAYSST12A112AB
NAYSST15A112AA NAYSST15A112AB NAYSST18A112AA NAYSST24A112AA**

7-1. PERFORMANCE DATA

1) COOLING CAPACITY

Model	Indoor air IWB (°F)	Outdoor intake air DB temperature (°F)											
		75			85			95			105		
		TC	SHC	TPC	TC	SHC	TPC	TC	SHC	TPC	TC	SHC	TPC
NAXSST09A112AA	71	11.0	7.6	0.52	10.3	7.1	0.57	9.7	6.6	0.61	9.0	6.2	0.65
NAXSST09A112AB	67	10.4	8.6	0.49	9.7	8.0	0.54	9.0	7.4	0.59	8.4	6.9	0.62
NAYSST09A112AA	63	9.8	9.4	0.47	9.1	8.7	0.52	8.5	8.1	0.56	7.7	7.3	0.60
NAXSST12A112AA	71	14.7	9.4	0.82	13.7	8.7	0.90	12.9	8.2	0.97	12.0	7.6	1.02
NAXSST12A112AB	67	13.9	10.7	0.77	13.0	10.0	0.85	12.0	9.2	0.92	11.2	8.6	0.98
NAYSST12A112AA	63	13.1	11.8	0.74	12.1	10.9	0.81	11.3	10.2	0.88	10.3	9.3	0.94
NAXSST15A112AA	71	17.2	9.7	0.96	16.0	9.1	1.05	15.1	8.5	1.13	14.0	7.9	1.19
NAXSST15A112AB	67	16.2	11.4	0.91	15.1	10.6	1.00	14.0	9.8	1.08	13.0	9.1	1.14
NAYSST15A112AA	63	15.3	12.7	0.86	14.1	11.8	0.96	13.2	11.0	1.03	12.0	10.0	1.10
NAXSST18A112AA	71	22.1	16.2	1.19	20.6	15.2	1.31	19.4	14.3	1.41	18.0	13.3	1.48
NAYSST18A112AA	67	20.9	18.2	1.13	19.4	16.9	1.24	18.0	15.7	1.34	16.7	14.6	1.42
NAXSST18A112AB	63	19.6	19.7	1.07	18.2	18.2	1.19	16.9	17.0	1.28	15.4	15.4	1.37
NAXSST24A112AA	71	27.6	17.0	1.60	25.8	15.9	1.76	24.2	14.9	1.89	22.5	13.9	1.99
NAYSST24A112AA	67	26.1	19.6	1.51	24.3	18.2	1.67	22.5	16.9	1.80	20.9	15.7	1.91
NAXSST24A112AB	63	24.5	21.7	1.44	22.7	20.1	1.59	21.2	18.7	1.72	19.2	17.0	1.84

NOTE: 1. IWB : Intake air wet-bulb temperature TC : Total Capacity ($\times 10^3 \text{ Btu/h}$)

SHC : Sensible Heat Capacity ($\times 10^3 \text{ Btu/h}$) TPC : Total Power Consumption (kW)

2. SHC is based on 80°F of indoor Intake air DB temperature.

2) COOLING CAPACITY CORRECTIONS

Model	Refrigerant piping length (one way: ft.)			
	25 (std.)	40	65	100
NAXSST09A112AA				
NAXSST09A112AB				
NAXSST12A112AA				
NAXSST12A112AB				
NAXSST15A112AA				
NAXSST15A112AB				
NAYSST09A112AA	1.0	0.988	0.967	-
NAYSST09A112AB				
NAYSST12A112AA				
NAYSST12A112AB				
NAYSST15A112AA				
NAYSST15A112AB				
NAXSST18A112AA	1.0	0.985	0.963	0.933
NAYSST18A112AA				
NAXSST24A112AA	1.0	0.983	0.956	0.921
NAYSST24A112AA				

3) HEATING CAPACITY CORRECTIONS

Model	Refrigerant piping length (one way: ft.)			
	25 (std.)	40	65	100
NAXSST09A112AA				
NAXSST09A112AB				
NAXSST12A112AA				
NAXSST12A112AB				
NAXSST15A112AA	1.0	0.997	0.993	-
NAXSST15A112AB				
NAXSST18A112AA	1.0	0.997	0.993	0.987
NAXSST24A112AA				

4) HEATING CAPACITY (NAXSST)

Model	Indoor air	Outdoor intake air WB temperature (°F)													
		5		15		25		35		43		45		55	
	IDB (°F)	TC	TPC	TC	TPC	TC	TPC	TC	TPC	TC	TPC	TC	TPC	TC	TPC
NAXSST09A112AA NAXSST09A112AB	75	4.8	0.42	6.3	0.54	7.9	0.63	9.4	0.70	10.6	0.74	11.0	0.75	12.4	0.78
	70	5.2	0.41	6.7	0.52	8.2	0.62	9.6	0.68	10.9	0.72	11.2	0.73	12.7	0.76
	65	5.5	0.39	6.9	0.50	8.6	0.59	10.0	0.67	11.2	0.70	11.6	0.71	13.0	0.75
NAXSST12A112AA NAXSST12A112AB	75	6.3	0.65	8.4	0.82	10.4	0.96	12.5	1.07	14.0	1.13	14.5	1.14	16.4	1.19
	70	6.8	0.62	8.9	0.79	10.8	0.94	12.7	1.05	14.4	1.10	14.8	1.12	16.8	1.17
	65	7.2	0.59	9.1	0.76	11.3	0.91	13.2	1.02	14.8	1.07	15.3	1.09	17.1	1.14
NAXSST15A112AA NAXSST15A112AB	75	7.9	0.94	10.4	1.19	13.1	1.40	15.6	1.56	17.6	1.64	18.1	1.66	20.5	1.73
	70	8.6	0.90	11.1	1.15	13.5	1.37	15.9	1.52	18.0	1.60	18.5	1.63	21.0	1.70
	65	9.0	0.86	11.3	1.10	14.1	1.32	16.5	1.48	18.5	1.56	19.1	1.58	21.4	1.66
NAXSST18A112AA	75	9.5	0.99	12.5	1.25	15.7	1.47	18.7	1.64	21.1	1.72	21.7	1.75	24.6	1.81
	70	10.3	0.95	13.3	1.21	16.2	1.44	19.1	1.60	21.6	1.68	22.2	1.71	25.2	1.78
	65	10.8	0.91	13.6	1.16	17.0	1.39	19.8	1.55	22.2	1.64	22.9	1.66	25.7	1.75
NAXSST24A112AA	75	12.1	1.38	16.0	1.74	20.0	2.05	23.9	2.28	26.9	2.40	27.7	2.43	31.5	2.53
	70	13.1	1.32	17.0	1.68	20.7	2.00	24.4	2.22	27.6	2.34	28.4	2.39	32.2	2.48
	65	13.8	1.26	17.4	1.61	21.7	1.93	25.3	2.16	28.4	2.28	29.3	2.32	32.8	2.43

NOTE: 1. IDB : Intake air dry-bulb temperature

TC : Total Capacity (x10³ Btu/h) TPC : Total Power Consumption (kW)


2. Above data is for heating operation without any frost.

How to operate with fixed operational frequency of the compressor.


1. Press the EMERGENCY OPERATION switch on the front of the indoor unit, and select either EMERGENCY COOL mode or EMERGENCY HEAT mode before starting to operate the air conditioner.
2. The compressor starts with operational frequency.
3. The fan speed of the indoor unit is High.
4. This operation continues for 30 minutes.
5. In order to release this operation, press the EMERGENCY OPERATION switch or press any button on the remote controller.

7-2. PERFORMANCE CURVE


Cooling




**NAXSST09A112AA NAXSST09A112AB
NAYSST09A112AA NAYSST09A112AB**




**NAXSST12A112AA NAXSST12A112AB
NAYSST12A112AA NAYSST12A112AB**




NAXSST18A112AA NAYSST18A112AA



**NAXSST15A112AA NAXSST15A112AB
NAYSST15A112AA NAYSST15A112AB**




NAXSST24A112AA NAYSST24A112AA




This value of frequency is not the same as the actual frequency in operating. Refer to 7-5 and 7-6 for the relationships between frequency and capacity.


Heating




NAXSST09A112AA
NAXSST09A112AB



NAXSST12A112AA
NAXSST12A112AB




NAXSST15A112AA
NAXSST15A112AB






NAXSST18A112AA



NAXSST24A112AA




This value of frequency is not the same as the actual frequency in operating. Refer to 7-5 and 7-6 for the relationships between frequency and capacity.

7-3. CONDENSING PRESSURE


Cooling

Data are based on the condition of indoor humidity 50 %.
Airflow should be set to High speed.


**NAXSST09A112AA NAXSST09A112AB
NAYSST09A112AA NAYSST09A112AB**



**NAXSST12A112AA NAXSST12A112AB
NAYSST12A112AA NAYSST12A112AB**





**NAXSST15A112AA NAXSST15A112AB
NAYSST15A112AA NAYSST15A112AB**







NAXSST18A112AA NAYSST18A112AA



NAXSST24A112AA NAYSST24A112AA




Heating

Data are based on the condition of outdoor humidity 75%.


Airflow should be set to High speed.

Data are for heating operation without any frost.

NAXSST09A112AA NAXSST09A112AB




NAXSST12A112AA NAXSST12A112AB







NAXSST15A112AA NAXSST15A112AB



NAXSST18A112AA



NAXSST24A112AA



7-4. STANDARD OPERATION DATA

Model		NAXWST09A112AA NAXWST09A112AB		NAYWST09A112AA NAYWST09A112AB	
Item		Unit	Cooling	Heating	Cooling
Total	Capacity	Btu/h	9,000	10,900	9,000
	SHF	—	0.82	—	0.82
	Input	kW	0.585	0.72	0.585
	Rated frequency	Hz	59	73	59.5
Electrical circuit	Indoor unit		NAXWST09A112AA NAXWST09A112AB		NAYWST09A112AA NAYWST09A112AB
	Power supply		V, phase, Hz		
	Input		kW	0.022	0.023
	Fan motor current		A	0.24/0.22	0.25/0.23
	Outdoor unit		NAXSST09A112AA NAXSST09A112AB		NAYSST09A112AA NAYSST09A112AB
	Power supply		V, phase, Hz		
	Input		kW	0.563	0.697
	Comp. current		A	2.67/2.41	3.25/2.94
	Fan motor current		A	0.36/0.33	0.34/0.31
Refrigerant circuit	Condensing pressure		PSIG	357	345
	Suction pressure		PSIG	151	107
	Discharge temperature		°F	146	156
	Condensing temperature		°F	108	102
	Suction temperature		°F	61	44
	Comp. shell bottom temperature		°F	144	154
	Ref. pipe length		ft.	25	
	Refrigerant charge (R410A)		2 lb 5 oz.		2 lb 9 oz.
Indoor unit	Intake air temperature	DB	°F	80	70
		WB	°F	67	60
	Discharge air temperature	DB	°F	59	99
		WB	°F	56	—
	Fan speed (High)		rpm	1,020	1,040
Outdoor unit	Airflow (High)		CFM	367 (Wet)	413
	Intake air temperature	DB	°F	95	47
		WB	°F	—	—
	Fan speed		rpm	900	860
	Airflow		CFM	1,229	1,172




Model			NAXWST12A112AA NAXWST12A112AB NAYWST12A112AA NAYWST12A112AB		NAXWST15A112AA NAXWST15A112AB NAYWST15A112AA NAYWST15A112AB		
Total	Item		Unit	Cooling	Heating	Cooling	Heating
	Capacity		Btu/h	12,000	14,400	14,000	18,000
	SHF		—	0.77	—	0.78	—
	Input		kW	0.920	1.10	1.080	1.60
Electrical circuit	Rated frequency		Hz	70	77	56.5	74
	Indoor unit			NAXWST12A112AA NAXWST12A112AB NAYWST12A112AA NAYWST12A112AB		NAXWST15A112AA NAXWST15A112AB NAYWST15A112AA NAYWST15A112AB	
	Power supply		V, phase, Hz	208/230, 1, 60			
	Input		kW	0.022	0.023	0.043	0.030
	Fan motor current		A	0.24/0.22	0.25/0.23	0.43/0.39	0.34/0.31
	Outdoor unit			NAXWST12A112AA NAXWST12A112AB NAYWST12A112AA NAYWST12A112AB		NAXWST15A112AA NAXWST15A112AB NAYWST15A112AA NAYWST15A112AB	
	Power supply		V, phase, Hz	208/230, 1, 60			
	Input		kW	0.898	1.077	1.037	1.570
	Comp. current		A	4.01/3.62	4.86/4.39	4.51/4.08	7.11/6.43
	Fan motor current		A	0.41/0.37	0.40/0.36	0.41/0.37	0.40/0.36
Refrigerant circuit	Condensing pressure		PSIG	380	402	396	427
	Suction pressure		PSIG	133	106	138	98
	Discharge temperature		°F	166	167	168	178
	Condensing temperature		°F	112	115	115	120
	Suction temperature		°F	60	35	61	31
	Comp. shell bottom temperature		°F	152	150	152	158
	Ref. pipe length		ft.	25			
	Refrigerant charge (R410A)			2 lb 9 oz.			
Indoor unit	Intake air temperature	DB	°F	80	70	80	70
		WB	°F	67	60	67	60
	Discharge air temperature	DB	°F	57	110	58	114
		WB	°F	55	—	56	—
	Fan speed (High)		rpm	1,020	1,040	1,280	1,140
Outdoor unit	Airflow (High)		CFM	367 (Wet)	413	498 (Wet)	463
	Intake air temperature	DB	°F	95	47	95	47
		WB	°F	—	43	—	43
	Fan speed		rpm	900	860	910	900
	Airflow		CFM	1,229	1,172	1,243	1,229

--	--	--	--	--	--	--


Model			NAXWST18A112AA NAYWST18A112AA		NAXWST24A112AA NAYWST24A112AA	
Item		Unit	Cooling	Heating	Cooling	Heating
Total	Capacity	Btu/h	18,000	21,600	22,500	27,600
	SHF	—	0.87	—	0.75	—
	Input	kW	1.34	1.68	1.80	2.34
	Rated frequency	Hz	69	81	67.5	82.0
Electrical circuit	Indoor unit		NAXWST18A112AA NAYWST18A112AA		NAXWST24A112AA NAYWST24A112AA	
	Power supply		V, phase, Hz		208/230, 1, 60	
	Input	kW	0.045		0.058	
	Fan motor current	A	0.46/0.42		0.56/0.51	
	Outdoor unit		NAXSST18A112AA NAYSST18A112AA		NAXSST24A112AA NAYSST24A112AA	
	Power supply		V, phase, Hz		208/230, 1, 60	
	Input	kW	1.295	1.635	1.742	2.282
	Comp. current	A	5.01/4.53	6.67/6.03	7.01/6.34	9.59/8.67
	Fan motor current	A	1.05/0.95	1.05/0.95	1.16/1.05	1.13/1.02
Refrigerant circuit	Condensing pressure		PSIG	377	391	395
	Suction pressure		PSIG	144	103	141
	Discharge temperature		°F	149	178	158
	Condensing temperature		°F	111	111	115
	Suction temperature		°F	51	43	52
	Comp. shell bottom temperature		°F	134	160	140
	Ref. pipe length		ft.	25		
	Refrigerant charge (R410A)			3 lb 9 oz.		4 lb 3 oz.
Indoor unit	Intake air temperature	DB	°F	80	70	80
		WB	°F	67	60	67
	Discharge air temperature	DB	°F	52	111	56
		WB	°F	51	—	53
	Fan speed (High)		rpm	1,170	1,170	1,300
Outdoor unit	Airflow (High)		CFM	581 (Wet)	646	634 (Wet)
	Intake air temperature	DB	°F	95	47	95
		WB	°F	—	43	—
	Fan speed		rpm	810	810	840
	Airflow		CFM	1,691	1,691	1,769

7-5. CAPACITY AND INPUT CORRECTION BY INVERTER OUTPUT FREQUENCY


NAXSST09A112AA NAXSST09A112AB




NAYSST09A112AA NAYSST09A112AB




NAXSST12A112AA NAYSST12A112AA NAXSST12A112AB NAYSST12A112AB




NAXSST15A112AA NAYSST15A112AA NAXSST15A112AB NAYSST15A112AB



NAXSST18A112AA NAYSST18A112AA



NAXSST24A112AA NAYSST24A112AA



7-6. HOW TO OPERATE FIXED-FREQUENCY OPERATION (Test run operation)

1. Press EMERGENCY OPERATION switch to start COOL or HEAT mode (COOL: Press once, HEAT: Press twice).
2. Test run operation starts and continues to operate for 30 minutes.
3. Compressor operates at rated frequency in COOL mode or 58 Hz in HEAT mode.
4. Indoor fan operates at High speed.
5. After 30 minutes, test run operation finishes and EMERGENCY OPERATION starts (operation frequency of compressor varies).
6. To cancel test run operation (EMERGENCY OPERATION), press EMERGENCY OPERATION switch or any button on the remote controller.


**NAXSST09A112AA NAXSST09A112AB NAXSST12A112AA NAXSST12A112AB
 NAXSST15A112AA NAXSST15A112AB NAXSST18A112AA NAXSST24A112AA
 NAYSST09A112AA NAYSST09A112AB NAYSST12A112AA NAYSST12A112AB
 NAYSST15A112AA NAYSST15A112AB NAYSST18A112AA NAYSST24A112AA**

8-1. OUTDOOR FAN MOTOR CONTROL

The fan motor turns ON/OFF, interlocking with the compressor.

[ON] The fan motor turns ON 5 seconds before the compressor starts up.

[OFF] The fan motor turns OFF 15 seconds after the compressor has stopped running.




8-2. R.V. COIL CONTROL (NAXSST)

Heating ON

Cooling OFF

Dry OFF

NOTE: The 4-way valve reverses for 5 seconds right before startup of the compressor.



8-3. RELATION BETWEEN MAIN SENSOR AND ACTUATOR

Sensor	Purpose	Actuator				
		Compressor	LEV	Outdoor fan motor	R.V.coil	Indoor fan motor
Discharge temperature thermistor	Protection	○	○			
Indoor coil temperature thermistor	Cooling: Coil frost prevention	○				
	Heating: High pressure protection	○	○			
Defrost thermistor (NAXSST)	Heating: Defrosting	○	○	○	○	○
Fin temperature thermistor	Protection	○		○		
Ambient temperature thermistor	Cooling: Low ambient temperature operation	○	○	○		
	Heating: Defrosting (Heater)					
Outdoor heat exchanger temperature thermistor	Cooling: Low ambient temperature operation	○	○	○		
	Cooling: High pressure protection	○	○	○		

**NAXSST09A112AA NAXSST09A112AB NAXSST12A112AA NAXSST12A112AB
 NAXSST15A112AA NAXSST15A112AB NAXSST18A112AA NAXSST24A112AA
 NAYSST09A112AA NAYSST09A112AB NAYSST12A112AA NAYSST12A112AB
 NAYSST15A112AA NAYSST15A112AB NAYSST18A112AA NAYSST24A112AA**

9-1. CHANGE IN DEFROST SETTING (NAXSST)

Changing defrost finish temperature

<JS> To change the defrost finish temperature, cut/solder the JS wire of the outdoor inverter P.C. board (Refer to 10-6.1.).

Jumper		Defrost finish temperature	
		NAXSST09/12/15A112AA NAXSST09/12/15A112AB	NAXSST18/24A112AA
JS	Soldered (Initial setting)	41°F (5°C)	50°F (10°C)
	None (Cut)	50°F (10°C)	64°F (18°C)

9-2. PRE-HEAT CONTROL SETTING (NAXSST)

NAXSST09/12/15/18A112AA, NAXSST09/12/15A112AB

When moisture gets into the refrigerant cycle, it may interfere with the startup of the compressor at low outside temperature. The pre-heat control prevents this interference. The pre-heat control turns ON when the discharge temperature thermistor is 68°F (20°C) or below. When the pre-heat control turns ON, the compressor is energized. (About 50 W)

NAXSST24A112AA

Prolonged low load operation, in which the thermostat is OFF for a long time, at low outside temperature [32°F (0°C) or less] may cause the following troubles. The pre-heat control prevents those troubles.

- 1) If moisture gets into the refrigerant cycle and freezes, it may interfere the startup of the compressor.
- 2) If liquid refrigerant collects in the compressor, a failure in the compressor may occur.

The pre-heat control turns ON when the compressor temperature is 68°F (20°C) or below. When the pre-heat control turns ON, the compressor is energized. (About 70 W)

Pre-heat control setting

<JK>

ON: To activate the pre-heat control, cut JK wire of the inverter P.C. board.

OFF: To deactivate the pre-heat control, solder JK wire of the inverter P.C. board.

(Refer to 10-6.1)

Jumper		Pre-heat control setting	
		NAXSST09/12/15/18A112AA NAXSST09/12/15A112AB	NAXSST24A112AA
JK	Soldered	Deactivated (Initial setting)	Deactivated
	Cut	Activated	Activated (Initial setting)

NOTE: When the inverter P.C. board is replaced, check the jumper wires, and cut/solder them if necessary.

NAXSST09A112AA NAXSST09A112AB NAXSST12A112AA NAXSST12A112AB
NAXSST15A112AA NAXSST15A112AB NAXSST18A112AA NAXSST24A112AA
NAYSST09A112AA NAYSST09A112AB NAYSST12A112AA NAYSST12A112AB
NAYSST15A112AA NAYSST15A112AB NAYSST18A112AA NAYSST24A112AA


10-1. CAUTIONS ON TROUBLESHOOTING

1. Before troubleshooting, check the following

- 1) Check the power supply voltage.
- 2) Check the indoor/outdoor connecting wire for miswiring.

2. Take care of the following during servicing

- 1) Before servicing the air conditioner, be sure to turn OFF the main unit first with the remote controller, then after confirming the horizontal vane is closed, turn off the breaker and/or disconnect the power plug.
- 2) Be sure to turn OFF the power supply before removing the front panel, the cabinet, the top panel, and the electronic control P.C. board.
- 3) When removing the electrical parts, be careful of the residual voltage of smoothing capacitor.
- 4) When removing the electronic control P.C. board, hold the edge of the board with care NOT to apply stress on the components.
- 5) When connecting or disconnecting the connectors, hold the connector housing. DO NOT pull the lead wires.



3. Troubleshooting procedure

- 1) Check if the OPERATION INDICATOR lamp on the indoor unit is blinking on and off to indicate an abnormality. To make sure, check how many times the OPERATION INDICATOR lamp is blinking on and off before starting service work. (See the service manual of the indoor unit for a description of those failure codes.)
- 2) Before servicing, check that the connector and terminal are connected properly.
- 3) When the electronic control P.C. board seems to be defective, check the copper foil pattern for disconnection and the components for bursting and discoloration.
- 4) Refer to 10-2 and 10-3.

10-2. FAILURE MODE RECALL FUNCTION

Outline of the function


This air conditioner can memorize the abnormal condition which has occurred once.

Even though LED indication listed on the troubleshooting check table (10-3.) disappears, the memorized failure details can be recalled.

1. Flow chart of failure mode recall function for the indoor/outdoor unit


NAXWST06/09/12/15A112AA NAXWST18A112AA NAXWST24A112AA
NAYWST09/12/15A112AA NAYWST18A112AA NAYWST24A112AA

Operational procedure




NOTE: 1. Make sure to release the failure mode recall function after it is set up, otherwise the unit cannot operate properly.
2. If the abnormal condition is not deleted from the memory, the last abnormal condition is kept memorized.

※2. Blinking pattern when the indoor unit is abnormal:




※3. Blinking pattern when the outdoor unit is abnormal:



2. Flow chart of the detailed outdoor unit failure mode recall function


Operational procedure



NOTE: 1. Make sure to release the failure mode recall function after it is set up, otherwise the unit cannot operate properly.

2. If the abnormal condition is not deleted from the memory, the last abnormal condition is kept memorized.

※2. Blinking pattern when outdoor unit is abnormal:



NOTE: Blinking patterns of this mode differ from the ones of
TROUBLESHOOTING CHECK TABLE (10-3.).

3. Outdoor unit failure recall mode table

The upper lamp of the OPERATION INDICATOR lamp (Indoor unit)	Abnormal point (Failure mode/protection)	LED indication (Outdoor P.C. board)	Condition	Remedy	Indoor/ outdoor unit failure mode recall function	Outdoor unit failure mode recall function
OFF	None (Normal)	—	—	—	—	—
1-time blink 2.5 seconds OFF	Indoor/outdoor communication, receiving error	—	Any signals from the inverter P.C. board cannot be received normally for 3 minutes.	•Refer to 10-5. ⑩ How to check miswiring and serial signal error.	○	○
	Indoor/outdoor communication, receiving error	—	Although the inverter P.C. board sends signal "0", signal "1" has been received 30 consecutive times.	•Refer to 10-5. ⑩ How to check miswiring and serial signal error.		
2-time blink 2.5 seconds OFF	Outdoor power system	—	Overcurrent protection cut-out operates 3 consecutive times within 1 minute after the compressor gets started.	•Reconnect connectors. •Refer to 10-5. ⑩ How to check inverter/ compressor". •Check stop valve.	○	○
3-time blink 2.5 seconds OFF	Discharge temperature thermistor	1-time blink every 2.5 seconds	Thermistor shorts or opens during compressor running.	•Refer to 10-5. ⑩ "Check of outdoor thermistors". Defective outdoor thermistors can be identified by checking the blinking pattern of LED.	○	○
	Defrost thermistor	—				
	Fin temperature thermistor	3-time blink 2.5 seconds OFF				
	P.C. board temperature thermistor	4-time blink 2.5 seconds OFF				
	Ambient temperature thermistor	2-time blink 2.5 seconds OFF				
	Outdoor heat exchanger temperature thermistor	—				
4-time blink 2.5 seconds OFF	Overcurrent	11-time blink 2.5 seconds OFF	Large current flows into the power module (IC700)/IGBT module (IC700). *1	•Reconnect compressor connector. •Refer to 10-5. ⑩ How to check inverter/ compressor". •Check stop valve.	—	○
	Compressor synchronous abnormality (Compressor startup failure protection)	12-time blink 2.5 seconds OFF	Waveform of compressor current is distorted.	•Reconnect compressor connector. •Refer to 10-5. ⑩ How to check inverter/ compressor".	—	○
5-time blink 2.5 seconds OFF	Discharge temperature	—	Temperature of discharge temperature thermistor exceeds 241°F (116°C), compressor stops. Compressor can restart if discharge temperature thermistor reads 212°F (100°C) or less 3 minutes later.	•Check refrigerant circuit and refrigerant amount. •Refer to 10-5. ⑩ "Check of LEV".	—	○
6-time blink 2.5 seconds OFF	High pressure	—	Temperature indoor coil thermistor exceeds 158°F (70°C) in HEAT mode. Temperature defrost thermistor exceeds 158°F (70°C) in COOL mode.	•Check refrigerant circuit and refrigerant amount. •Check stop valve.	—	○
7-time blink 2.5 seconds OFF	Fin temperature/ P.C. board temperature	7-time blink 2.5 seconds OFF	Temperature of the fin temperature thermistor on the inverter P.C. board exceeds 167 - 187°F (75 - 86°C)/167 - 176°F (75 - 80°C), or temperature of P.C. board temperature thermistor on the inverter P.C. board exceeds 162 - 185°F (72 - 85°C)/158 - 167°F (70 - 75°C).*2	•Check around outdoor unit. •Check outdoor unit air passage. •Refer to 10-5. ⑩ "Check of outdoor fan motor".	—	○
8-time blink 2.5 seconds OFF	Outdoor fan motor	—	Outdoor fan has stopped 3 times in a row within 30 seconds after outdoor fan startup.	•Refer to 10-5. ⑩ "Check of outdoor fan motor". Refer to 10-5. ⑩ "Check of inverter P.C. board".	—	○
9-time blink 2.5 seconds OFF	Non-volatile memory data	5-time blink 2.5 seconds OFF	Non-volatile memory data cannot be read properly.	•Replace the inverter P.C. board.	○	○
	Power module (IC700), IGBT module (IC700) *1	6-time blink 2.5 seconds OFF	The interface short circuit occurs in the output of the power module (IC700)/IGBT module (IC700).*1 The compressor winding shorts circuit.	•Refer to 10-5. ⑩ How to check inverter/ compressor".	—	

NOTE: Blinking patterns of this mode differ from the ones of TROUBLESHOOTING CHECK TABLE (10-3.).

The upper lamp of the OPERATION INDICATOR lamp (Indoor unit)	Abnormal point (Failure mode/protection)	LED indication (Outdoor P.C. board)	Condition	Remedy	Indoor/outdoor unit failure mode recall function	Outdoor unit failure mode recall function
10-time blink 2.5 seconds OFF	Discharge temperature	—	Temperature of discharge temperature thermistor has been 122°F (50°C) or less for 20 minutes.	•Refer to 10-5.®"Check of LEV". •Check refrigerant circuit and refrigerant amount.	—	○
11-time blink 2.5 seconds OFF	Bus-bar voltage (DC)	8-time blink 2.5 seconds OFF	Bus-bar voltage of inverter cannot be detected normally.	•Refer to 10-5.®"How to check inverter/compressor".	—	○
	Each phase current of compressor	9-time blink 2.5 seconds OFF	Each phase current of compressor cannot be detected normally.			
14-time blink 2.5 seconds OFF	Stop valve (Closed valve)	14-time blink 2.5 seconds OFF	Closed valve is detected by compressor current.	•Check stop valve.	○	○
	4-way valve/ Pipe temperature	16-time blink 2.5 seconds OFF	The 4-way valve does not work properly. The indoor coil thermistor detects an abnormal temperature.	•Check the 4-way valve. •Replace the inverter P.C. board.		
16-time blink 2.5 seconds OFF	Outdoor refrigerant system abnormality	1-time blink 2.5 seconds OFF	A closed valve and air trapped in the refrigerant circuit are detected based on the temperature sensed by the indoor and outdoor thermistors and the current of the compressor.	•Check for a gas leak in a connecting piping etc. •Check the stop valve. •Refer to 10-5.® "Check of outdoor refrigerant circuit".	○	○

*Module

Power module (IC700)	NAXSST09/12/15/18A112AA, NAXSST09/12/15A112AB, NAYSST09/12/15/18A112AA, NAYSST09/12/15A112AB
IGBT module (IC700)	NAXSST24A112AA, NAYSST24A112AA

*2

Fin temperature thermistor


167 - 187°F (75 - 86°C)	NAXSST09/12/15/18A112AA, NAXSST09/12/15A112AB, NAYSST09/12/15/18A112AA, NAYSST09/12/15A112AB
167 - 176°F (75 - 80°C)	NAXSST24A112AA, NAYSST24A112AA

P.C. board temperature thermistor

162 - 185°F (72 - 85°C)	NAXSST09/12/15/18A112AA, NAXSST09/12/15A112AB, NAYSST09/12/15/18A112AA, NAYSST09/12/15A112AB
158 - 167°F (70 - 75°C)	NAXSST24A112AA, NAYSST24A112AA

10-3. TROUBLESHOOTING CHECK TABLE

No.	Symptom	LED indication	Abnormal point/Condition	Condition	Remedy
1	Outdoor unit does not operate. 'Outdoor unit stops and restarts 3 minutes later' is repeated.	1-time blink every 2.5 seconds 6-time blink 2.5 seconds OFF 11-time blink 2.5 seconds OFF 16-time blink 2.5 seconds OFF 17-time blink 2.5 seconds OFF 2-time blink 2.5 seconds OFF 3-time blink 2.5 seconds OFF 4-time blink 2.5 seconds OFF 5-time blink 2.5 seconds OFF 8-time blink 2.5 seconds OFF 10-time blink 2.5 seconds OFF 12-time blink 2.5 seconds OFF	Outdoor power system	Overcurrent protection cut-out operates 3 consecutive times within 1 minute after the compressor gets started.	<ul style="list-style-type: none"> •Reconnect connector of compressor. •Refer to 10-5.Ⓐ "How to check inverter/compressor". •Check stop valve.
2			Outdoor thermistors	Discharge temperature thermistor, fin temperature thermistor, defrost thermistor, P.C. board temperature thermistor, outdoor heat exchanger temperature thermistor or ambient temperature thermistor shorts or opens during compressor running.	<ul style="list-style-type: none"> •Refer to 10-5.Ⓑ "Check of outdoor thermistors".
3			Outdoor control system	Nonvolatile memory data cannot be read properly. (The upper lamp of the OPERATION INDICATOR lamp on the indoor unit lights up or blinks 7-time.)	<ul style="list-style-type: none"> •Replace inverter P.C. board.
4			Serial signal	The communication fails between the indoor and outdoor unit for 3 minutes.	<ul style="list-style-type: none"> •Refer to 10-5.⓪ "How to check miswiring and serial signal error".
5			Stop valve/ Closed valve	Closed valve is detected by compressor current.	<ul style="list-style-type: none"> •Check stop valve.
6			4-way valve/ Pipe temperature	The 4-way valve does not work properly. The indoor coil thermistor detects an abnormal temperature.	<ul style="list-style-type: none"> •Refer to 10-5.Ⓓ "Check of R.V. coil". •Replace the inverter P.C. board.
7			Outdoor refrigerant system abnormality	A closed valve and air trapped in the refrigerant circuit are detected based on the temperature sensed by the indoor and outdoor thermistors and the current of the compressor.	<ul style="list-style-type: none"> •Check for a gas leak in a connecting piping etc. •Check the stop valve. •Refer to 10-5.Ⓔ "Check of outdoor refrigerant circuit".
8			Overcurrent protection	Large current flows into the power module (IC700)/IGBT module (IC700).*1	<ul style="list-style-type: none"> •Reconnect connector of compressor. •Refer to 10-5.Ⓐ "How to check inverter/compressor". •Check stop valve.
9			Discharge temperature overheat protection	Temperature of discharge temperature thermistor exceeds 241°F (116°C), compressor stops. Compressor can restart if discharge temperature thermistor reads 212°F (100°C) or less 3 minutes later.	<ul style="list-style-type: none"> •Check refrigerant circuit and refrigerant amount. •Refer to 10-5.⓪ "Check of LEV".
10			Fin temperature / P.C. board temperature thermistor overheat protection	Temperature of the fin temperature thermistor on the heat sink exceeds 167 - 187°F (75 - 86°C)/167 - 176°F (75 - 80°C) or temperature of P.C. board temperature thermistor on the inverter P.C. board exceeds 162 - 185°F (72 - 85°C)/158 - 167°F (70 - 75°C). *2	<ul style="list-style-type: none"> •Check around outdoor unit. •Check outdoor unit air passage. •Refer to 10-5.① "Check of outdoor fan motor".
11			High pressure protection	Indoor coil thermistor exceeds 158°F (70°C) in HEAT mode. Defrost thermistor exceeds 158°F (70°C) in COOL mode.	<ul style="list-style-type: none"> •Check refrigerant circuit and refrigerant amount. •Check stop valve.
12			Compressor synchronous abnormality	The waveform of compressor current is distorted.	<ul style="list-style-type: none"> •Reconnect connector of compressor. •Refer to 10-5.Ⓐ "How to check inverter/compressor".
13			Outdoor fan motor	Outdoor fan has stopped 3 times in a row within 30 seconds after outdoor fan startup.	<ul style="list-style-type: none"> •Refer to 10-5.① "Check of outdoor fan motor". •Refer to 10-5.② "Check of inverter P.C. board".
14			Each phase current of compressor	Each phase current of compressor cannot be detected normally.	<ul style="list-style-type: none"> •Refer to 10-5.Ⓐ "How to check inverter/compressor".



*1
Module

Power module (IC700)	NAXSST09/12/15/18A112AA, NAXSST09/12/15A112AB, NAYSST09/12/15/18A112AA, NAYSST09/12/15A112AB
IGBT module (IC700)	NAXSST24A112AA, NAYSST24A112AA

*2
Fin temperature thermistor

167 - 187°F (75 - 86°C)	NAXSST09/12/15/18A112AA, NAXSST09/12/15A112AB, NAYSST09/12/15/18A112AA, NAYSST09/12/15A112AB
167 - 176°F (75 - 80°C)	NAXSST24A112AA, NAYSST24A112AA

P.C. board temperature thermistor

162 - 185°F (72 - 85°C)	NAXSST09/12/15/18A112AA, NAXSST09/12/15A112AB, NAYSST09/12/15/18A112AA, NAYSST09/12/15A112AB
158 - 167°F (70 - 75°C)	NAXSST24A112AA, NAYSST24A112AA


No.	Symptom	LED indication	Abnormal point/ Condition	Condition	Remedy
15	'Outdoor unit stops and restarts 3 minutes later' is repeated.	13-time blink 2.5 seconds OFF	Bus-bar voltage (DC)	Bus-bar voltage of inverter cannot be detected normally.	<ul style="list-style-type: none"> It occurs with following case. Instantaneous power voltage drop. (Short time power failure) (NAXSST24A112AA, NAYSST24A112AA) Refer to 10-5. ① "Check of power supply". (NAXSST24A112AA, NAYSST24A112AA) Refer to 10-5. ④ "How to check inverter/compressor".
16	Outdoor unit operates.	1-time blink 2.5 seconds OFF	Frequency drop by current protection	When the input current exceeds approximately 10.5A, compressor frequency lowers.	<p>The unit is normal, but check the following.</p> <ul style="list-style-type: none"> Check if indoor filters are clogged. Check if refrigerant is short. Check if indoor/outdoor unit air circulation is short cycled.
17		3-time blink 2.5 seconds OFF	Frequency drop by high pressure protection	Temperature of indoor coil thermistor exceeds 131 °F (55°C) in HEAT mode, compressor frequency lowers.	
18			Frequency drop by defrosting in COOL mode	Indoor coil thermistor reads 46°F (8°C) or less in COOL mode, compressor frequency lowers.	
19		4-time blink 2.5 seconds OFF	Frequency drop by discharge temperature protection	Temperature of discharge temperature thermistor exceeds 232°F (111°C), compressor frequency lowers.	<ul style="list-style-type: none"> Check refrigerant circuit and refrigerant amount. Refer to 10-5. ④ "Check of LEV". Refer to 10-5. ④ "Check of outdoor thermistors".
20		5-time blink 2.5 seconds OFF	Outside temperature thermistor protection	When the outside temperature thermistor shorts or opens, protective operation without that thermistors is performed.	<ul style="list-style-type: none"> Refer to 10-5. ④ Check of outdoor thermistors.
21		7-time blink 2.5 seconds OFF	Low discharge temperature protection	Temperature of discharge temperature thermistor has been 122°F (50°C) or less for 20 minutes.	<ul style="list-style-type: none"> Refer to 10-5. ④ "Check of LEV". Check refrigerant circuit and refrigerant amount.
22		8-time blink 2.5 seconds OFF	NAXSST09/12/15/18A112AA NAXSST09/12/15A112AB NAYSST09/12/15/18A112AA NAYSST09/12/15A112AB PAM protection PAM: Pulse Amplitude Modulation	The overcurrent flows into PFC (Power factor correction :IC820) or the bus-bar voltage reaches 394 V or more, PAM stops and restarts.	<p>This is not malfunction. PAM protection will be activated in the following cases:</p> <ol style="list-style-type: none"> Instantaneous power voltage drop. (Short time power failure) When the power supply voltage is high.
			NAXSST24A112AA NAYSST24A112AA Zero cross detecting circuit	Zero cross signal cannot be detected.	<ul style="list-style-type: none"> It occurs with following cases. Instantaneous power voltage drop. (Short time power failure) Distortion of primary voltage <p>Refer to 10-5. ① "Check of power supply".</p>
		9-time blink 2.5 seconds OFF	Inverter check mode	The connector of compressor is disconnected, inverter check mode starts.	<ul style="list-style-type: none"> Check if the connector of the compressor is correctly connected. Refer to 10-5. ④ "How to check inverter/compressor".

NOTE: 1. The location of LED is illustrated at the right figure. Refer to 10-6.1.

2. LED is lighted during normal operation.

3. Blinking patterns of this mode differ from the ones of the failure recall mode.



The blinking frequency shows the number of times the LED blinks after every 2.5-second OFF.
(Example) When the blinking frequency is "2".




Inverter P.C. board
NAXSST09/12/15/18A112AA NAXSST24A112AA
NAXSST09/12/15A112AB NAYSST24A112AA
NAYSST09/12/15/18A112AA
NAYSST09/12/15A112AB

10-4. TROUBLE CRITERION OF MAIN PARTS

**NAXSST09A112AA NAXSST09A112AB NAXSST12A112AA NAXSST12A112AB
 NAXSST15A112AA NAXSST15A112AB NAXSST18A112AA NAXSST24A112AA
 NAYSST09A112AA NAYSST09A112AB NAYSST12A112AA NAYSST12A112AB
 NAYSST15A112AA NAYSST15A112AB NAYSST18A112AA NAYSST24A112AA**

Part name	Check method and criterion						Figure																																																								
Defrost thermistor (RT61) (NAXSST)	Measure the resistance with a tester.																																																														
Fin temperature thermistor (RT64)	Refer to 10-6. "TEST POINT DIAGRAM AND VOLTAGE", 1. "Inverter P.C. board", for the chart of thermistor.																																																														
Ambient temperature thermistor (RT65)																																																															
Outdoor heat exchanger temperature thermistor (RT68)																																																															
Discharge temperature thermistor (RT62)	Measure the resistance with a tester. Before measurement, hold the thermistor with your hands to warm it up.																																																														
	Refer to 10-6. "TEST POINT DIAGRAM AND VOLTAGE", 1. "Inverter P.C. board", for the chart of thermistor.																																																														
Compressor	Measure the resistance between terminals using a tester. [Temperature: 14 - 104°F (-10 - 40°C)]																																																														
	<table border="1"> <thead> <tr> <th colspan="6">Normal (Ω)</th> </tr> <tr> <th></th> <th>NAXSST09A112AA</th> <th>NAXSST09A112AB</th> <th>NAXSST12A112AA</th> <th>NAXSST15A112AB</th> <th>NAXSST24A112AA</th> </tr> </thead> <tbody> <tr> <td>NAXSST09A112AA</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>NAXSST09A112AB</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>NAXSST12A112AA</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>NAXSST15A112AB</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>NAXSST24A112AA</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th>Color of lead wire</th> <th>Normal (Ω)</th> </tr> </thead> <tbody> <tr> <td>U-V</td> <td>1.26 - 1.72</td> </tr> <tr> <td>U-W</td> <td>1.59 - 2.16</td> </tr> <tr> <td>V-W</td> <td>1.60 - 2.17</td> </tr> <tr> <td>U-V</td> <td>0.82 - 1.11</td> </tr> <tr> <td>U-W</td> <td>0.87 - 1.18</td> </tr> <tr> <td>V-W</td> <td></td> </tr> </tbody> </table>	Normal (Ω)							NAXSST09A112AA	NAXSST09A112AB	NAXSST12A112AA	NAXSST15A112AB	NAXSST24A112AA	NAXSST09A112AA						NAXSST09A112AB						NAXSST12A112AA						NAXSST15A112AB						NAXSST24A112AA						Color of lead wire	Normal (Ω)	U-V	1.26 - 1.72	U-W	1.59 - 2.16	V-W	1.60 - 2.17	U-V	0.82 - 1.11	U-W	0.87 - 1.18	V-W							
Normal (Ω)																																																															
	NAXSST09A112AA	NAXSST09A112AB	NAXSST12A112AA	NAXSST15A112AB	NAXSST24A112AA																																																										
NAXSST09A112AA																																																															
NAXSST09A112AB																																																															
NAXSST12A112AA																																																															
NAXSST15A112AB																																																															
NAXSST24A112AA																																																															
Color of lead wire	Normal (Ω)																																																														
U-V	1.26 - 1.72																																																														
U-W	1.59 - 2.16																																																														
V-W	1.60 - 2.17																																																														
U-V	0.82 - 1.11																																																														
U-W	0.87 - 1.18																																																														
V-W																																																															
Outdoor fan motor	Measure the resistance between lead wires using a tester. [Temperature: 14 - 104°F (-10 - 40°C)]																																																														
	<table border="1"> <thead> <tr> <th colspan="4">Normal (Ω)</th> </tr> <tr> <th>Color of lead wire</th> <th>NAXSST09/12/15A112AA</th> <th>NAXSST09/12/15A112AB</th> <th>NAXSST18/24A112AA</th> </tr> </thead> <tbody> <tr> <td>NAXSST09/12/15A112AA</td> <td></td> <td></td> <td></td> </tr> <tr> <td>NAXSST09/12/15A112AB</td> <td></td> <td></td> <td></td> </tr> <tr> <td>NAXSST18/24A112AA</td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th>Color of lead wire</th> <th>Normal (Ω)</th> </tr> </thead> <tbody> <tr> <td>RED - BLK</td> <td>29 - 40</td> </tr> <tr> <td>BLK - WHT</td> <td>28 - 39</td> </tr> <tr> <td>WHT - RED</td> <td>12 - 16</td> </tr> </tbody> </table>	Normal (Ω)				Color of lead wire	NAXSST09/12/15A112AA	NAXSST09/12/15A112AB	NAXSST18/24A112AA	NAXSST09/12/15A112AA				NAXSST09/12/15A112AB				NAXSST18/24A112AA				Color of lead wire	Normal (Ω)	RED - BLK	29 - 40	BLK - WHT	28 - 39	WHT - RED	12 - 16																																		
Normal (Ω)																																																															
Color of lead wire	NAXSST09/12/15A112AA	NAXSST09/12/15A112AB	NAXSST18/24A112AA																																																												
NAXSST09/12/15A112AA																																																															
NAXSST09/12/15A112AB																																																															
NAXSST18/24A112AA																																																															
Color of lead wire	Normal (Ω)																																																														
RED - BLK	29 - 40																																																														
BLK - WHT	28 - 39																																																														
WHT - RED	12 - 16																																																														
R. V. coil (21S4)	Measure the resistance using a tester. [Temperature: 14 - 104°F (-10 - 40°C)]																																																														
	<table border="1"> <thead> <tr> <th colspan="2">Normal (kΩ)</th> </tr> </thead> <tbody> <tr> <td>NAXSST09/12/15A112AA</td> <td>NAXSST09/12/15A112AB</td> </tr> <tr> <td>NAXSST15A112AB</td> <td>NAXSST15A112AB</td> </tr> <tr> <td>NAXSST18/24A112AA</td> <td>NAXSST18/24A112AB</td> </tr> <tr> <td>0.97 - 1.38</td> <td>1.65 - 2.48</td> </tr> </tbody> </table>						Normal (kΩ)		NAXSST09/12/15A112AA	NAXSST09/12/15A112AB	NAXSST15A112AB	NAXSST15A112AB	NAXSST18/24A112AA	NAXSST18/24A112AB	0.97 - 1.38	1.65 - 2.48																																															
Normal (kΩ)																																																															
NAXSST09/12/15A112AA	NAXSST09/12/15A112AB																																																														
NAXSST15A112AB	NAXSST15A112AB																																																														
NAXSST18/24A112AA	NAXSST18/24A112AB																																																														
0.97 - 1.38	1.65 - 2.48																																																														

Expansion valve coil (LEV)	Measure the resistance using a tester. [Temperature: 14 - 104°F (-10 - 40°C)]	<table border="1"> <thead> <tr> <th>Color of lead wire</th><th>Normal (Ω)</th></tr> </thead> <tbody> <tr> <td>RED - ORN</td><td rowspan="4">37 - 54</td></tr> <tr> <td>RED - WHT</td></tr> <tr> <td>RED - BLU</td></tr> <tr> <td>RED - YLW</td></tr> </tbody> </table> 	Color of lead wire	Normal (Ω)	RED - ORN	37 - 54	RED - WHT	RED - BLU	RED - YLW
Color of lead wire	Normal (Ω)								
RED - ORN	37 - 54								
RED - WHT									
RED - BLU									
RED - YLW									
Defrost heater (Optional parts)	Measure the resistance using a tester. [Temperature: 14 - 104°F (-10 - 40°C)]	<table border="1"> <thead> <tr> <th colspan="2">Normal (Ω)</th> </tr> </thead> <tbody> <tr> <td>NAXSST09/12/15/18A112AA NAXSST09/12/15A112AB</td><td>NAXSST24A112AA</td></tr> <tr> <td>349 - 428</td><td>376 - 461</td></tr> </tbody> </table>	Normal (Ω)		NAXSST09/12/15/18A112AA NAXSST09/12/15A112AB	NAXSST24A112AA	349 - 428	376 - 461	
Normal (Ω)									
NAXSST09/12/15/18A112AA NAXSST09/12/15A112AB	NAXSST24A112AA								
349 - 428	376 - 461								

10-5. TROUBLESHOOTING FLOW

A How to check inverter/compressor

Disconnect the connector between the compressor and the power module (IC700)/IGBT module (IC700).*

Check the voltage between terminals. See 10-5.⑤ "Check of open phase".

Are the voltages balanced? No → Replace the inverter P.C. board.

Yes → Check the compressor. See 10-5.⑥ "Check of compressor".

*Module

Power module (IC700)	NAXSST09/12/15/18A112AA, NAXSST09/12/15A112AB, NAXSST09/12/15/18A112AA, NAXSST09/12/15A112AB
IGBT module (IC700)	NAXSST24A112AA, NAXSST24A112AB

B Check of open phase

- With the connector between the compressor and the module* disconnected, activate the inverter and check if the inverter is normal by measuring the **voltage balance** between the terminals.

Output voltage is 50 - 130 V. (The voltage may differ according to the tester.)

<< Operation method>>

Start cooling or heating operation by pressing EMERGENCY OPERATION switch on the indoor unit. (TEST RUN OPERATION: Refer to 7-6.)

<<Measurement point>>

At 3 points

BLK (U)-WHT (V)

BLK (U)-RED (W)

WHT(V)-RED (W)


※ Measure AC voltage between the lead wires at 3 points.

NOTE: 1. Output voltage varies according to power supply voltage.

2. Measure the voltage by analog type tester.

3. During this check, LED of the inverter P.C. board blinks 9 times. (Refer to 10-6.1.)

C Check of compressor



D Check of compressor winding

- Disconnect the connector between the compressor and the module*, and measure the resistance between the compressor terminals.

<<Measurement point>>

At 3 points

BLK-WHT

※ Measure the resistance between the lead wires at 3 points.

BLK-RED

WHT-RED

<<Judgement>>

Refer to 10-4.

0 [Ω] Abnormal [short]

Infinite [Ω] Abnormal [open]

NOTE: Be sure to zero the ohmmeter before measurement.

*Module

Power module (IC700)	NAXSST09/12/15/18A112AA, NAXSST09/12/15A112AB, NAYSST09/12/15/18A112AA, NAYSST09/12/15A112AB
IGBT module (IC700)	NAXSST24A112AA, NAYSST24A112AA

E Check of compressor operation time

- Connect the compressor and activate the inverter. Then measure the time until the inverter stops due to overcurrent.


<<Operation method>>

Start heating or cooling operation by pressing EMERGENCY OPERATION switch on the indoor unit. (TEST RUN OPERATION: Refer to 7-6.)

<<Measurement>>

Measure the time from the start of compressor to the stop of compressor due to overcurrent.

<<Judgement>>





(F) Check of compressor start failure

Confirm that ①~④ is normal.

- Electrical circuit check
- ①. Contact of the compressor connector
- ②. Output voltage of inverter P.C. board and balance of them (See 10-5.⑧)
- ③. Direct current voltage between DB61(+) and (-)/JP715(+) and JP30(-) on the inverter P.C. board
- ④. Voltage between outdoor terminal block S1-S2

*Direct current voltage


Between DB61(+) and (-)	NAXSST09/12/15/18A112AA, NAXSST09/12/15A112AB, NAYSST09/12/15/18A112AA, NAYSST09/12/15A112AB
Between JP715(+) and JP30(-)	NAXSST24A112AA, NAYSST24A112AA




*1
Heat the compressor with a drier for about 20 minutes.
Do not recover refrigerant gas while heating.

(G) Check of outdoor thermistors

Disconnect the connector of thermistor in the inverter P.C. board (see below table), and measure the resistance of thermistor.



Reconnect the connector of thermistor.
Turn ON the power supply and press EMERGENCY OPERATION switch.



NAXSST09/12/15/18A112AA, NAXSST09/12/15A112AB

NAYSST09/12/15/18A112AA, NAYSST09/12/15A112AB

Thermistor	Symbol	Connector, Pin No.	Board
Defrost (NAXSST)	RT61	Between CN641 pin1 and pin2	Inverter P.C. board
Discharge temperature	RT62	Between CN641 pin3 and pin4	
Fin temperature	RT64	Between CN642 pin1 and pin2	
Ambient temperature	RT65	Between CN643 pin1 and pin2	
Outdoor heat exchanger temperature	RT68	Between CN644 pin1 and pin3	

NAXSST24A112AA, NAYSST24A112AA


Thermistor	Symbol	Connector, Pin No.	Board
Defrost (NAXSST)	RT61	Between CN671 pin1 and pin2	Inverter P.C. board
Discharge temperature	RT62	Between CN671 pin3 and pin4	
Fin temperature	RT64	Between CN673 pin1 and pin2	
Ambient temperature	RT65	Between CN672 pin1 and pin2	
Outdoor heat exchanger temperature	RT68	Between CN671 pin5 and pin6	

(H) Check of R.V. coil (NAXSST)


NAXSST09/12/15/18A112AA, NAXSST09/12/15A112AB

- ※ First of all, measure the resistance of R.V. coil to check if the coil is defective. Refer to 10-4.
- ※ In case CN721 is disconnected or R.V. coil is open, voltage is generated between the terminal pins of the connector although no signal is being transmitted to R.V. coil.
Check if CN721 is connected.

Unit operates in COOL mode even if it is set to HEAT mode.




Unit operates in HEAT mode even if it is set to COOL mode.




NAXSST24A112AA

- ※ First of all, measure the resistance of R.V. coil to check if the coil is defective. Refer to 10-4.
- ※ In case CN602 is disconnected or R.V. coil is open, voltage is generated between the terminal pins of the connector although no signal is being transmitted to R.V. coil.
Check if CN602 is connected.


Unit operates in COOL mode even if it is set to HEAT mode.



Unit operates in HEAT mode even if it is set to COOL mode.



① Check of outdoor fan motor



J Check of power supply

Disconnect the connector between the compressor and the power module (IC700) IGBT module (IC700).* Turn ON power supply and press EMERGENCY OPERATION switch.

*Module

Power module (IC700)	NAXSST09/12/15/18A112AA, NAXSST09/12/15A112AB, NAYSST09/12/15/18A112AA, NAYSST09/12/15A112AB
IGBT module (IC700)	NAXSST24A112AA, NAYSST24A112AA

Rectify indoor/outdoor connecting wire.

Does the upper lamp of the OPERATION INDICATOR lamp on the indoor unit light up? No

Is there voltage 208/230 V AC between the indoor terminal block S1 and S2?

Replace the indoor electronic control P.C. board.

Yes

Is there bus-bar voltage 260 - 370 V DC between DB61 (+) and DB61 (-)/294 - 370 V DC between JP715 (+) and JP30 (-) on the inverter P.C. board? (Refer to 10-6.1.)

Yes

Does LED on the inverter P.C. board light up or blink? (Refer to 10-6.1.)

Replace the inverter P.C. board.

No

If lights up, OK.
If blinks, refer to 10-3.

Check the electric parts in main circuit.


*2 Bus-bar voltage

260 - 370 V DC between DB61(+) and (-)

NAXSST09/12/15/18A112AA, NAXSST09/12/15A112AB, NAYSST09/12/15/18A112AA, NAYSST09/12/15A112AB

294 - 370 V DC between JP715(+) and JP30(-)

NAXSST24A112AA, NAYSST24A112AA




NAXSST09/12/15/18A112AA

NAXSST09/12/15A112AB

NAYSST09/12/15/18A112AA

NAYSST09/12/15A112AB



K Check of LEV (Expansion valve)


Turn ON the power supply.

<Preparation of the remote controller>



- ① While pressing both OPERATION SELECT button and TOO COOL button on the remote controller at the same time, press RESET button.
- ② First, release RESET button.
Hold down the other 2 buttons for another 3 seconds.
Make sure that the indicators on the LCD screen shown in the right figure are all displayed. Then release the buttons.

NAXWST06/09/12/15A112AA
NAYWST09/12/15A112AA

NAXWST18A112AA NAXWST24A112AA
NAYWST18A112AA NAYWST24A112AA





Press STOP/OPERATE (OFF/ON) button of the remote controller (the set temperature is displayed) with the remote controller headed towards the indoor unit. ※1



E.g.: NAXWST type

Expansion valve operates in full-opening direction.



※1. Regardless of normal or abnormal condition, a short beep is emitted once the signal is received.

Do you hear the expansion valve "click, click....."?
Do you feel the expansion valve vibrates when touching it ?

Is LEV coil properly fixed to the expansion valve?

No → Properly fix the LEV coil to the expansion valve.

Yes → Does the resistance of LEV coil have the characteristics? (Refer to 10-4.)

Yes → Measure each voltage between connector pins of CN724 on the inverter P.C. board.
1. Pin③(-) — Pin①(+)
2. Pin④(-) — Pin①(+)
3. Pin⑤(-) — Pin①(+)
4. Pin⑥(-) — Pin①(+)

Is there about 3 - 5 V AC between each?
NOTE: Measure the voltage by an analog tester.

No → Replace the inverter P.C. board.


No → Replace the LEV coil.

Yes → Replace the expansion valve.


NOTE: After check of LEV, take the following steps.

1. Turn OFF the power supply and turn it ON again.
2. Press RESET button on the remote controller.


⑥ Check of inverter P.C. board



**NAXSST18/24A112AA
NAYSST18/24A112AA**




(N) Check of outdoor refrigerant circuit



* CAUTION : Do not start the operation again to prevent hazards.





① Electromagnetic noise enters into TV sets or radios







10-6. TEST POINT DIAGRAM AND VOLTAGE

1. Inverter P.C. board





NAXSST09A112AA NAXSST12A112AA NAXSST15A112AA
NAYSST09A112AA NAYSST12A112AA NAYSST15A112AA




NAXSST09A112AB NAXSST12A112AB NAXSST15A112AB
NAYSST09A112AB NAYSST12A112AB NAYSST15A112AB






NAXSST18A112AA NAYSST18A112AA



NAXSST24A112AA NAYSST24A112AA



Defrost thermistor (RT61) (NAXSST)
Ambient temperature thermistor (RT65)
Outdoor heat exchanger temperature thermistor (RT68)



<Detaching method of the terminal with locking mechanism>


The terminal which has the locking mechanism can be detached as shown below.

There are 2 types of the terminals with locking mechanism.


The terminal without locking mechanism can be detached by pulling it out.

Check the shape of the terminal before detaching.

(1) Slide the sleeve and check if there is a locking lever or not.



(2) The terminal with this connector shown below has the locking mechanism.









**11-1. NAXSST09A112AA NAXSST09A112AB NAXSST12A112AA NAXSST12A112AB
NAXSST15A112AA NAXSST15A112AB NAYSST09A112AA NAYSST09A112AB
NAYSST12A112AA NAYSST12A112AB NAYSST15A112AA NAYSST15A112AB**





NOTE: Turn OFF the power supply before disassembly.



→: Indicates the visible parts in the photos/figures.
---: Indicates the invisible parts in the photos/figures.

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>1. Removing the cabinet</p> <p>(1) Remove the screw fixing the service panel. (2) Pull down the service panel and remove it. (3) Remove the screws fixing the conduit cover. (4) Remove the conduit cover. (Photo 4) (5) Remove the screw fixing the conduit plate. (Photo 5) (6) Remove the conduit plate. (7) Disconnect the power supply wire and indoor/outdoor connecting wire. (8) Remove the screws fixing the top panel. (9) Remove the top panel. (10) Remove the screws fixing the cabinet. (11) Remove the cabinet. (12) Remove the screws fixing the back panel. (13) Remove the back panel.</p>	<p>Photo 1</p> <p>External view of the air conditioner cabinet. Labels indicate the screws of the top panel, back panel, and cabinet.</p> <p>Photo 2</p> <p>Front view of the air conditioner cabinet. Labels indicate the screws of the top panel and cabinet.</p> <p>Photo 3</p> <p>Internal view of the air conditioner cabinet. Labels indicate the screw of the cabinet, screws of the terminal block support and the back panel, hooks, and the direction to remove.</p>

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>Photo 4</p>  <p>Screws of the conduit cover</p>	<p>Photo 5</p>  <p>Screw of the conduit plate</p>
<p>2. Removing the inverter assembly, inverter P.C. board</p> <ol style="list-style-type: none"> (1) Remove the cabinet and panels. (Refer to section 1.) (2) Disconnect the lead wire to the reactor and the following connectors: <ul style="list-style-type: none"> <Inverter P.C. board> CN721 (R.V. coil) (NAXSST) CN931, CN932 (Fan motor) CN641 (Defrost thermistor (NAXSST) and discharge temperature thermistor) CN643 (Ambient temperature thermistor) CN644 (Outdoor heat exchanger temperature thermistor) CN724 (LEV) (3) Remove the compressor connector (CN61). (4) Remove the screws fixing the heat sink support and the separator. (5) Remove the fixing screws of the terminal block support and the back panel. (6) Remove the inverter assembly. (7) Remove the screw of the ground wire and screw of the terminal block support. (8) Remove the heat sink support from the P.C. board support. (9) Remove the screw of the inverter P.C. board and remove the inverter P.C. board from the P.C. board support. 	<p>Photo 6 NAXSST09/12/15A112AA NAYSST09/12/15A112AA</p>  <p>Screws of the heat sink support and the separator</p> <p>Soundproof felt</p> <p>Screws of the terminal block support and the back panel</p> <p>Photo 7 NAXSST09/12/15A112AB NAYSST09/12/15A112AB</p>  <p>Screws of the heat sink support and the separator</p> <p>Soundproof felt</p> <p>Screws of the terminal block support and the back panel</p>

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>3. Removing R.V. coil</p> <p>(1) Remove the cabinet and panels. (Refer to section 1.)</p> <p>(2) Disconnect the following connectors: <Inverter P.C. board> CN721 (R.V. coil) (NAXSST)</p> <p>(3) Remove the R.V. coil.</p>	<p>Photo 8 NAXSST09/12/15A112AA NAYSST09/12/15A112AA</p>  <p>Heat sink Heat sink support P.C. board support Terminal block support Screw of the Terminal block support Screw of the inverter P.C. board Screw of the ground wire</p> <p>Photo 9 NAXSST09/12/15A112AB NAYSST09/12/15A112AB</p>  <p>Heat sink Heat sink support P.C. board support Terminal block support Screw of the terminal block support Screw of the inverter P.C. board Screw of the ground wire</p>




OPERATING PROCEDURE	PHOTOS/FIGURES
<p>4. Removing the discharge temperature thermistor, defrost thermistor, outdoor heat exchanger temperature thermistor and ambient temperature thermistor</p> <p>(1) Remove the cabinet and panels. (Refer to section 1.)</p> <p>(2) Disconnect the lead wire to the reactor and the following connectors:</p> <p><Inverter P.C. board></p> <p>CN641 (Defrost thermistor (NAXSST) and discharge temperature thermistor)</p> <p>CN643 (Ambient temperature thermistor)</p> <p>CN644 (Outdoor heat exchanger temperature thermistor)</p> <p>(3) Pull out the discharge temperature thermistor from its holder.</p> <p>(4) Pull out the defrost thermistor from its holder.</p> <p>(5) Pull out the outdoor heat exchanger temperature thermistor from its holder.</p> <p>(6) Pull out the ambient temperature thermistor from its holder.</p>	<p>Photo 8</p>  <p>Screw of the R.V. coil (NAXSST)</p> <p>Discharge temperature thermistor</p>
<p>Photo 12 NAXSST09/12A112AB NAYSST09/12A112AB</p>  <p>Ambient temperature thermistor</p> <p>Defrost thermistor</p> <p>Outdoor heat exchanger temperature thermistor</p>	<p>Photo 11 NAXSST09/12A112AA NAYSST09/12A112AA</p>  <p>Ambient temperature thermistor</p> <p>Outdoor heat exchanger temperature thermistor</p> <p>Defrost thermistor</p>
	<p>Photo 13 NAXSST15A112AA NAXSST15A112AB NAYSST15A112AA NAYSST15A112AB</p>  <p>Ambient temperature thermistor</p> <p>Outdoor heat exchanger temperature thermistor</p> <p>Defrost thermistor</p>




OPERATING PROCEDURE	PHOTOS/FIGURES
<p>5. Removing outdoor fan motor</p> <p>(1) Remove the cabinet and panels. (Refer to section 1.) (2) Disconnect the following connectors: <Inverter P.C. board> CN931, CN932 (Fan motor) (3) Remove the propeller fan nut. (4) Remove the propeller fan. (5) Remove the screws fixing the fan motor. (6) Remove the fan motor. NOTE: The propeller fan nut is a reverse thread.</p>	<p>Photo 10</p>  <p>Screws of the outdoor fan motor Propeller fan Propeller fan nut</p>
<p>6. Removing the compressor and 4-way valve</p> <p>(1) Remove the cabinet and panels. (Refer to section 1.) (2) Remove the inverter assembly. (Refer to section 2.) (3) Remove the screws fixing the reactor. (4) Remove the reactor. (5) Remove the soundproof felt. (6) Recover gas from the refrigerant circuit. NOTE: Recover gas from the pipes until the pressure gauge shows 0 PSIG. (7) Detach the brazed part of the suction and the discharge pipe connected with compressor. (8) Remove the nuts fixing the compressor. (9) Remove the compressor. (10) Detach the brazed part of pipes connected with 4-way valve.</p>	<p>Photo 11</p>  <p>Screws of the reactor Soundproof felt Suction pipe brazed part</p>
<p>Photo 12</p>  <p>Discharge pipe brazed part Brazed parts of 4-way valve</p>	

11-2. NAXSST18A112AA NAYSST18A112AA

NOTE: Turn OFF the power supply before disassembly.




OPERATING PROCEDURE	PHOTOS/FIGURES
<p>1. Removing the cabinet</p> <p>(1) Remove the screws of the service panel. (2) Remove the screws of the top panel. (3) Remove the screw of the valve cover. (4) Remove the service panel. (5) Remove the screws fixing the conduit cover. (6) Remove the conduit cover. (7) Remove the screw of fixing the conduit plate. (8) Remove the conduit plate. (9) Remove the top panel. (10) Remove the valve cover. (11) Disconnect the power supply and indoor/outdoor connecting wire. (12) Remove the screws of the cabinet. (13) Remove the cabinet. (14) Remove the screws of the back panel. (15) Remove the back panel.</p>	<p>Photo 1</p> <p>Screws of the top panel Screws of the cabinet Screws of the cabinet Screws of the cabinet</p>
<p>Photo 3</p> <p>Screws of the conduit cover</p>	<p>Photo 2</p> <p>Screws of the top panel Screw of the valve cover Screw of the back panel Screws of the cabinet Screws of the service panel</p>
<p>Photo 4</p> <p>Screw of the conduit plate</p>	



OPERATING PROCEDURE	PHOTOS/FIGURES
<p>2. Removing the inverter assembly, inverter P.C. board</p> <p>(1) Remove the cabinet and panels. (Refer to section 1.)</p> <p>(2) Disconnect the lead wire to the reactor and the following connectors: <Inverter P.C. board> CN721 (R.V. coil) (NAXSST) CN931, CN932 (Fan motor) CN641 (Defrost thermistor (NAXSST) and discharge temperature thermistor) CN643 (Ambient temperature thermistor) CN644 (Outdoor heat exchanger temperature thermistor) CN724 (LEV)</p> <p>(3) Remove the compressor connector.</p> <p>(4) Remove the screw fixing the heat sink support and the separator.</p> <p>(5) Remove the fixing screws of the terminal block support and the back panel.</p> <p>(6) Remove the inverter assembly.</p> <p>(7) Remove the screw of the ground wire, screw of the P.C. board cover and screws of the terminal block support.</p> <p>(8) Remove the heat sink support from the P.C. board support.</p> <p>(9) Remove the screw of the inverter P.C. board and the inverter P.C. board from the P.C. board support.</p>	<p>Photo 5 Screw of the heat sink support and the separator Screws of the terminal block support and the back panel</p> 
<p>3. Removing R.V. coil (NAXSST)</p> <p>(1) Remove the cabinet and panels. (Refer to section 1.)</p> <p>(2) Disconnect the following connector: <Inverter P.C. board> CN721 (R.V. coil) (NAXSST)</p> <p>(3) Remove the R.V. coil.</p>	<p>Photo 6</p> 
<p>Photo 7</p> 	

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>4. Removing the discharge temperature thermistor, defrost thermistor (NAXSST), outdoor heat exchanger temperature thermistor and ambient temperature thermistor</p> <p>(1) Remove the cabinet and panels. (Refer to section 1.) (2) Disconnect the lead wire to the reactor and the following connectors: <Inverter P.C. board> CN641 (Defrost thermistor (NAXSST) and discharge temperature thermistor) CN643 (Ambient temperature thermistor) CN644 (Outdoor heat exchanger temperature thermistor) (3) Pull out the discharge temperature thermistor from its holder. (4) Pull out the defrost thermistor from its holder. (5) Pull out the outdoor heat exchanger temperature thermistor from its holder. (6) Pull out the ambient temperature thermistor from its holder.</p>	<p>Photo 8</p> 
<p>5. Removing outdoor fan motor</p> <p>(1) Remove the top panel, cabinet and service panel. (Refer to section 1.) (2) Disconnect the following connectors: <Inverter P.C. board> CN931 and CN932 (Fan motor) (3) Remove the propeller fan nut. (4) Remove the propeller fan. (5) Remove the screws fixing the fan motor. (6) Remove the fan motor.</p> <p>NOTE: The propeller fan nut is a reverse thread.</p>	<p>Photo 9</p> 
<p>6. Removing the compressor and 4-way valve</p> <p>(1) Remove the top panel, cabinet and service panel. (Refer to section 1.) (2) Remove the back panel. (Refer to section 1.) (3) Remove the inverter assembly. (Refer to section 2.) (4) Recover gas from the refrigerant circuit.</p> <p>NOTE: Recover gas from the pipes until the pressure gauge shows 0 PSIG.</p> <p>(5) Detach the brazed part of the suction and the discharge pipe connected with compressor. (6) Remove the compressor nuts. (7) Remove the compressor. (8) Detach the brazed part of 4-way valve and pipe. (Photo 7)</p>	<p>Photo 10</p> 

11-3. NAXSST24A112AA NAYSST24A112AA

NOTE: Turn OFF the power supply before disassembly.

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>1. Removing the cabinet</p> <ol style="list-style-type: none"> (1) Remove the screws of the service panel. (2) Remove the screws of the top panel. (3) Remove the screw of the valve cover. (4) Remove the service panel. (5) Remove the screws fixing the conduit cover. (6) Remove the conduit cover. (7) Remove the top panel. (8) Remove the valve cover. (9) Disconnect the power supply and indoor/outdoor connecting wire. (10) Remove the screws of the cabinet. (11) Remove the cabinet. (12) Remove the screws of the back panel. (13) Remove the back panel. 	<p>Photo 1</p> 
<p>Photo 2</p> 	<p>Photo 3</p> 
	<p>Photo 4</p> 

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>2. Removing the inverter assembly, inverter P.C. board and relay P.C. board</p> <p>(1) Remove the cabinet and panels. (Refer to section 1.) (2) Disconnect the lead wire to the reactor and the following connectors: <Inverter P.C. board> CN602 (R.V. coil) (NAXSST) CN931, CN932 (Fan motor) CN671 (Defrost thermistor (NAXSST), discharge temperature thermistor and outdoor heat exchanger temperature thermistor) CN672 (Ambient temperature thermistor) CN724 (LEV) (3) Remove the compressor connector. (4) Remove the screws fixing the relay panel. (5) Remove the relay panel. (6) Remove the ground wires and the lead wires of the inverter P.C. board. (7) Remove the screws of the P.B. support. (8) Remove the inverter P.C. board from the P.B. support.</p>	<p>Photo 5</p>  <p>Labels for Photo 5:</p> <ul style="list-style-type: none"> Inverter P.C. board Ground wires Screws of the relay panel Screws of the P.B. support Screws of the P.B. support Screw of the relay panel Screw of the relay panel
<p>3. Removing R.V. coil (NAXSST)</p> <p>(1) Remove the cabinet and panels. (Refer to section 1.) (2) Disconnect the following connector: <Inverter P.C. board> CN602 (R.V. coil) (NAXSST) (3) Remove the R.V. coil.</p>	<p>Photo 6</p>  <p>Labels for Photo 6:</p> <ul style="list-style-type: none"> Screw of the R.V. coil (NAXSST) Brazed parts of 4-way valve

OPERATING PROCEDURE	PHOTOS/FIGURES
<p>4. Removing the discharge temperature thermistor, defrost thermistor (NAXSST), outdoor heat exchanger temperature thermistor and ambient temperature thermistor</p> <p>(1) Remove the cabinet and panels. (Refer to section 1.) (2) Disconnect the lead wire to the reactor and the following connectors: <Inverter P.C. board> CN671 (Defrost thermistor (NAXSST), discharge temperature thermistor and outdoor heat exchanger temperature thermistor) CN672 (Ambient temperature thermistor) (3) Pull out the discharge temperature thermistor from its holder. (4) Pull out the defrost thermistor from its holder. (5) Pull out the outdoor heat exchanger temperature thermistor from its holder. (6) Pull out the ambient temperature thermistor from its holder.</p>	<p>Photo 7</p>
<p>5. Removing outdoor fan motor</p> <p>(1) Remove the top panel, cabinet and service panel. (Refer to section 1.) (2) Disconnect the following connectors: <Inverter P.C. board> CN931 and CN932 (Fan motor) (3) Remove the propeller. (4) Remove the screws fixing the fan motor. (5) Remove the fan motor.</p> <p>NOTE: The propeller fan nut is a reverse thread.</p>	<p>Photo 8</p>
<p>6. Removing the compressor and 4-way valve</p> <p>(1) Remove the top panel, cabinet and service panel. (Refer to section 1.) (2) Remove the back panel. (Refer to section 1.) (3) Remove the inverter assembly. (Refer to section 2.) (4) Recover gas from the refrigerant circuit.</p> <p>NOTE: Recover gas from the pipes until the pressure gauge shows 0 PSIG.</p> <p>(5) Detach the brazed part of the suction and the discharge pipes connected with compressor. (6) Remove the compressor nuts. (7) Remove the compressor. (8) Detach the brazed parts of 4-way valve and pipes. (Photo 6)</p>	<p>Photo 9</p>

MITSUBISHI ELECTRIC TRANE HVAC US LLC

HEAD OFFICE: 1340 SATELLITE BOULEVARD, SUWANEE, GA 30024, USA

© Copyright 2018 MITSUBISHI ELECTRIC CORPORATION

Issued: Jan. 2020. No. OBHA733 REVISED EDITION-A

Published: Dec. 2018. No. OBHA733

Made in Japan

Specifications are subject to change without notice.