



# PARTS

## INDOOR UNIT




Ref.	Description	Part number
1	Remote Control	9332598001
2	Bracket Panel	9332556001
3	Air Filter	9332549003
4	Intake Grille (FUJITSU)	9332818017
5	Receiver Window	9332546019
6	Front Panel	9332545012
7	Wire Cover	9332544008
8	Wire Shield	9332555004
9	Louver with Shaft cover	9333342009
10	Panel Cover	9332559002

INDOOR UNIT  
Control box




Ref.	Description	Part number
11	Cover Shield	9332554007
12	Control Box	9332542004
13	Box Shield Assy	9332561005
14	Main PCB (07, 09)	9709170137
14	Main PCB (12)	9709170144
15	Terminal	9900720001
16	Earth Terminal	9332553024
17	Display Assy	9709173015
18	Room Thermistor Holder	9316895003
--	Thermistor Assy	9900714024




Ref.	Description	Part number
21	Fan Motor	9603180003
22	Crossflow Fan Assy	9316830004
23	Bearing C Assy	9306628017
24	Casing Assy	9332613018

INDOOR UNIT  
Casing assy



Ref.	Description	Part number	
31	Casing	9332534009	
32	Motor Cover	9316601000	
33	Motor Cover	9316568006	
34	Casing Cover F	9332558005	
35	Casing Cover B	9332557008	
36	R and L Louver	9332535006	
37	Step Motor	9900725006	
38	Fan Guard	9332551006	
39	Drain Cap	9316177017	
40	Drain Hose Assy	9316904002	

INDOOR UNIT  
Evaporator  
ASYG07LLCA  
ASYG09LLCA



ASYG12LLCA

Ref.	Description	Part number
41	Evaporator Total Assy (07, 09)	9316893085
42	Evaporator Total Assy (12)	9316893092
43	Earth Terminal	9316579002
44	Evaporator Holder R	9332538007
45	Evaporator Holder L	9332539004
46	Rear Bracket	9332540017
47	Filter Guide	9332541007