Communicating Upflow/Horizontal Left Downflow/Horizontal Right Direct/Non-Direct Vent Variable Speed, Modulating Condensing Gas Furnace

XC 95m

TUHMB060ACV3VA, TDHMB060BCV3VA
TUHMB080ACV3VA, TDHMB080ACV3VA
TUHMC100ACV4VA, TDHMC100ACV4VA
TUHMD120ACV5VA, TDHMD120BCV5VA
Direct or Non-Direct Vent with
Variable Speed Blower
Variable Speed Inducer



PUB. NO. 22-1840-06

General Features

MODULATING OPERATION
The modulating gas valves provides longer heating cycles for more consistent heating comfort. Modulates from 40% (45% for the TUHMD120) to 100% in less than 1% increments of the furnace's heating capacity saving energy, while at the same time maximizing homeowner comfort.

COMMUNICATING MODE
Furnace is shipped ready to be connected in communicating mode using three wire hook-up using TCONT900 comfort control.

ALTERNATE 24V MODE
Furnace is field configurable to 24V non-communicating mode.

COMFORT CONTROL
Comfortlink II™ Communicating furnace design, offers plug and play – walk away installation. Assures the entire heating and air conditioning system is set up in the proper modes to optimize the engineered performance of the matched system installed. The furnace can also be connected in conventional 24V mode.

NATURAL GAS MODELS
Central Heating furnace designs are certified by the American Gas Association for both natural and L.P. gas. Limit setting and rating data were established and approved under standard rating conditions using American National Standards Institute standards.

SAFE OPERATION
The Integrated System Control has solid state devices, which continuously monitor for presence of flame, when the system is in the heating mode of operation. Dual solenoid combination gas valve and regulator provide additional safety.

QUICK HEATING
Durable, cycle tested, heavy gauge **aluminized steel heat exchanger** quickly transfers heat to provide warm conditioned air to the structure. **Low energy power vent blower,** to increase efficiency and provide a positive discharge of gas fumes to the outside.

BURNERS
Multiport Inshot burners will give years of quiet and efficient service. All models can be converted to **L.P. gas** without changing burners.

INTEGRATED SYSTEM CONTROL
Exclusively designed operational program provides total control of furnace limit sensors, blowers, gas valve, flame control and includes self diagnostics for ease of service. Also contains connection points for EAC and Humidifier hookup.

AIR DELIVERY
The variable speed blower motor has sufficient airflow for most heating and cooling requirements and will switch from heating to cooling speeds on demand from room thermostat. The blower door safety switch will prevent or terminate furnace operation when the blower door is removed.

SECONDARY HEAT EXCHANGER
The XC95m has a special type 29-4C™ stainless steel secondary heat exchanger to reclaim heat from flue gases which would normally be lost.

STYLING
Heavy gauge steel and "wrap-around" cabinet construction is used in the cabinet with baked-on enamel finish for strength and beauty. The heat exchanger section of the cabinet is completely lined with foil faced fiberglass insulation. This results in quiet and efficient operation due to the excellent acoustical and insulating qualities of fiberglass. Built-in bottom pan and alternate bottom, left or right side return air connection provision.

FEATURES AND GENERAL OPERATION
The XC95m High Efficiency Gas Furnaces utilize an Adaptive Heat Up Silicon Nitride Hot Surface Ignition system, which eliminates the waste of a constant burning pilot. The integrated system control lights the main burners upon a demand for heat from the room thermostat. Complete front service access.

a. Low energy power venter
b. Vent proving pressure switch.

Pub. No. 22-1840-06

Contents

Features and Benefits

XC95m STANDARD EQUIPMENT

- **Comfortlink II™** Communication or 24 Volt control
- Factory default is communication mode
- Field configurable to 24 volt non-communicating mode
- Communication requires comfort control TCONT900AC43UA
- Plug and play installation in communication mode with communicating comfort control
- Three wire connections to comfort control when used with communicating comfort control (TCONT900AC43UA)
- Furnace modulates from 40% (45% for the TUHM1D120) to 100% of its heating capacity
- Upflow models convertible to Horizontal Left
- Downflow models convertible to Horizontal Right
- Power supply 115/1/60
- Modulating gas valve
- Variable speed ECM blower motor with Comfort R™
- Variable speed induced draft blower
- Silicon Nitride hot surface igniter with adaptive heat up
- PVC Venting - 1 or 2 pipe option
- Integrated solid state control with self-diagnostics
- Stored fault code history in microprocessor nonvolatile memory
- Insulated blower door
- Gasketed blower door
- Attractive color accents
- Heavy gauge aluminized steel heat exchanger
- Multi-port In-shot burners
- Complete front service access
- Slide out blower assembly
- Direct / Non-direct Vent Option
- Optional L.P conversion kit
- Improved **CleanEffects™** connections
- Left/right gas connection
- Accessory hook-up capability
- Manual reset flame roll out switches
- Cleanable high velocity filters
- Hinged blower door *
- Perfect fit door latches*
- **Optional extended warranties**

* (Upflow only)

Pub. No. 22-1840-06

Features and Benefits

XC95m OPTIONAL EQUIPMENT

Comfort Control XL900, Communicating	TCONT900AC43UA [ ]
Comfort Control XL802 Programmable 7 Day, 3-Ht, 2-Cl	TCONT802AS32DA [ ]
Comfort Control XL803 Programmable 7 Day, 3-Ht, 2-Cl with dehumidification	TCONT803AS32DA [ ]
Propane Conversion Kit	BAYLPKT220B [ ]
Propane Conversion Kit (with stainless steel burners)	BAYLPSS220B [ ]
5" Expandable High Efficiency Media Air Filter, “Perfect Fit” (17-1/2" Wide Gas Furnace)	TFM175A9FR0 [ ]
5" Expandable High Efficiency Media Air Filter, “Perfect Fit” (21" Wide Gas Furnace)	TFM210A9FR0 [ ]
5" Expandable High Efficiency Media Air Filter, “Perfect Fit” (24-1/2" Wide Gas Furnace)	TFM245A9FR0 [ ]
1" Expandable Standard Efficiency Media Air Filter, “Perfect Fit” (17-1/2" Wide Gas Furnace)	TFP175A9FR0 [ ]
1" Expandable Standard Efficiency Media Air Filter, “Perfect Fit” (21" Wide Gas Furnace)	TFP210A9FR0 [ ]
1" Expandable Standard Efficiency Media Air Filter, “Perfect Fit” (24-1/2" Wide Gas Furnace)	TFP245A9FR0 [ ]
Coil Enclosure (17-1/2" Wide Cabinets)	BAYCLE17A1722A [ ]
Coil Enclosure (21" Wide Cabinets)	BAYCLE21A2130A [ ]
Coil Enclosure (24-1/2" Wide Cabinets)	BAYCLE24A2430A [ ]
Downflow Subbase	BAYBASE205 [ ]
Side Filter Rack	BAYFLTR200 [ ]
Filter Rack Kit - Left & bottom return only for TUHMB060,080,C100. Left, right & bottom returns for TUHMD120	BAYRACK960 [ ]
Filter Kit/Horizontal Conversion TUHMB060,080	BAYFLTR203 [ ]
Filter Kit/Horizontal Conversion TUHMC100	BAYFLTR204 [ ]
Filter Kit/Horizontal Conversion TUHMD120	BAYFLTR205 [ ]
High Altitude Pressure Switch Kit TUHMB060	BAYSWT07AHALTA [ ]
High Altitude Pressure Switch Kit TUHMB080,C100	BAYSWT09AHALTA [ ]
High Altitude Pressure Switch Kit TUHMD120	BAYSWT08AHALTA [ ]
Concentric Vent Kit TUHM Furnaces	BAYAIR30AVENTA [ ]
Sidewall Vent Termination Kit All 2 Pipe Direct Vent Furnaces	BAYVENT200B [ ]
Cleanable Filter (14.5"/17.5" wide Upflow models)	BAYFLTR317 [ ]
Cleanable Filter (21" wide Upflow models)	BAYFLTR321 [ ]
Cleanable Filter (24.5" wide Upflow models)	BAYFLTR324 [ ]
CleanEffects™, Whole House Air Cleaner (Upflow 17-1/2" Wide Gas Furnace)	TFD175ALFR000B [ ]
CleanEffects™, Whole House Air Cleaner (Upflow 21" Wide Gas Furnace)	TFD210ALFR000B [ ]
CleanEffects™, Whole House Air Cleaner (Upflow 24-1/2" Wide Gas Furnace)	TFD245ALFR000B [ ]
CleanEffects™, Whole House Air Cleaner (Downflow 17-1/2" Wide Gas Furnace)	TFD17DALFR000B [ ]
CleanEffects™, Whole House Air Cleaner (Downflow 21" Wide Gas Furnace)	TFD21DALFR000B [ ]
CleanEffects™, Whole House Air Cleaner (Downflow 24-1/2" Wide Gas Furnace)	TFD24DALFR000B [ ]
CleanEffects™, Whole House Transformer Kit (120 to 24 Volt - all TFD Air Cleaners)	BAYTRANS12024 [ ]
CleanEffects™ Connection Kit for Modulating Furnace	BAYACCECOMM100 [ ]

General Data

TUHM PRODUCT SPECIFICATIONS①

MODEL	TUHMB060ACV3VA	TUHMB080ACV3VA	TUHMC100ACV4VA	TUHMD120ACV5VA
TYPE	Upflow/ Horizontal Left	Upflow/ Horizontal Left	Upflow/ Horizontal Left	Upflow/ Horizontal Left
RATINGS ②				
40% (low) heat Input BTUH	24,000	32,000	40,000	54,000
40% (low) heat Capacity BTUH (ICS) ③⑥	23,000	30,000	38,000	52,000
100% (high) heat Input BTUH	60,000	80,000	100,000	120,000
100% (high) heat Capacity BTUH (ICS) ③	57,000	75,000	95,000	114,000
Temp. rise (Min.-Max.) °F.	35 - 65	35 - 65	35 - 65	40 - 70
AFUE	95.0	95.0	95.0	95.0
BLOWER DRIVE	DIRECT	DIRECT	DIRECT	DIRECT
Diameter - Width (In.)	10 x 8	10 x 8	10 x 10	10 x 10
No. Used	1	1	1	1
Speeds (No.)	Variable	Variable	Variable	Variable
CFM vs. in. w.g.	See Fan Performance Table	See Fan Performance Table	See Fan Performance Table	See Fan Performance Table
Motor HP	1/2	1/2	1	1
RP.M.	Variable	Variable	Variable	Variable
Volts / Ph / Hz	115/1/60	115/1/60	115/1/60	115/1/60
COMBUSTION FAN - Type	Centrifugal	Centrifugal	Centrifugal	Centrifugal
Drive - No. Speeds	Direct - Variable	Direct - Variable	Direct - Variable	Direct - Variable
Motor HP - RPM	1/50 - 5000	1/50 - 5000	1/50 - 5000	1/50 - 5000
Volts / Ph / Hz	33 - 110/3/60 - 180	33 - 110/3/60 - 180	33 - 110/3/60 - 180	33 - 110/3/60 - 180
FLA	1.0	1.0	1.0	1.0
FILTER — Furnished?	Yes	Yes	Yes	Yes
Type Recommended	High Velocity	High Velocity	High Velocity	High Velocity
Hi Vel. (No.-Size-Thk.)	1 - 17x25 - 1 in.	1 - 17x25 - 1 in.	1 - 20x25 - 1 in.	1 - 24x25 - 1 in.
VENT — Size (in.)	2 Round	2 Round	3 Round	3 Round
HEAT EXCHANGER				
Type -Fired	Aluminized Steel - Type I	Aluminized Steel - Type I	Aluminized Steel - Type I	Aluminized Steel - Type I
-Unfired				
Gauge (Fired)	20	20	20	20
ORIFICES — Main				
Nat. Gas. Qty. — Drill Size	3 — 45	4 — 45	5 — 45	6 — 45
L.P. Gas Qty. — Drill Size ⑤	3 — 56	4 — 56	5 — 56	6 — 56
GAS VALVE	Redundant - Three Stage	Redundant - Three Stage	Redundant - Three Stage	Redundant - Three Stage
PILOT SAFETY DEVICE				
Type	Hot Surface Igniter	Hot Surface Igniter	Hot Surface Igniter	Hot Surface Igniter
BURNERS — Type	Multiport Inshot	Multiport Inshot	Multiport Inshot	Multiport Inshot
Number	3	4	5	6
POWER CONN. — V / Ph / Hz ④	115/1/60	115/1/60	115/1/60	115/1/60
Ampacity (In Amps)	11.1	11.1	13.5	15.2
Max. Overcurrent Protection (Amps)	15	15	20	20
PIPE CONN. SIZE (IN.)	1/2	1/2	1/2	1/2
DIMENSIONS	H x W x D	H x W x D	H x W x D	H x W x D
Crated (In.)	41-3/4 x 19-1/2 x 30-1/2	41-3/4 x 19-1/2 x 30-1/2	41-3/4 x 23 x 30-1/2	41-3/4 x 26-1/2 x 30-1/2
WEIGHT				
Shipping (Lbs.) / Net (Lbs)	158 / 146	168 / 156	197 / 185	206 / 193

① Central Furnace heating designs are certified to ANSI Z21.47 / CSA 2.3.
② For U.S. applications, above input ratings (BTUH) are up to 2,000 feet, derate 4% per 1,000 feet for elevations above 2,000 feet above sea level. For Canadian applications, above input ratings (BTUH) are up to 4,500 feet, derate 4% per 1,000 feet for elevations above 4,500 feet above sea level.
③ Based on U.S. government standard tests.
④ The above wiring specifications are in accordance with National Electrical Code; however, installations must comply with local codes.
⑤ Furnace ships in natural gas configuration. The LP conversion kit used with the modulating furnace is BAYLPSS220B or BAYLPKT220B.
⑥ 45% (low) heat for *UHM1D120ACV5VA.

Pub. No. 22-1840-06

General Data

TDHM PRODUCT SPECIFICATIONS

MODEL	TDHMB060BCV3VA	TDHMC080ACV3VA	TDHMC100ACV4VA	TDHMD120BCV5VA
TYPE	Downflow / Horizontal Right	Downflow / Horizontal Right	Downflow / Horizontal Right	Downflow / Horizontal Right
RATINGS ②				
40% (low) heat Input BTUH	24,000	32,000	40,000	48,000
40% (low) heat Capacity BTUH (ICS) ③	22,800	30,000	38,000	45,600
100% (high) heat Input BTUH	60,000	80,000	100,000	120,000
100% (high) heat Capacity BTUH (ICS) ③	57,000	74,000	95,000	114,000
Temp. rise (Min.-Max.) °F.	30 - 60	35 - 65	35 - 65	40 - 70
AFUE	95.0	95.0	95.0	95.0
BLOWER DRIVE	DIRECT	DIRECT	DIRECT	DIRECT
Diameter - Width (In.)	10 x 8	10 x 8	10 x 10	10 x 10
No. Used	1	1	1	1
Speeds (No.)	Variable	Variable	Variable	Variable
CFM vs. in. w.g.	See Fan Performance Table	See Fan Performance Table	See Fan Performance Table	See Fan Performance Table
Motor HP	1/2	1/2	3/4	1
R.P.M.	Variable	Variable	Variable	Variable
Volts / Ph / Hz	115/1/60	115/1/60	115/1/60	115/1/60
COMBUSTION FAN - Type	Centrifugal	Centrifugal	Centrifugal	Centrifugal
Drive - No. Speeds	Direct - Variable	Direct - Variable	Direct - Variable	Direct - Variable
Motor HP - RPM	1/50 - 5000	1/50 - 5000	1/50 - 5000	1/50 - 5000
Volts / Ph / Hz	33 - 110/3/60 - 180	33 - 110/3/60 - 180	33 - 110/3/60 - 180	33 - 110/3/60 - 180
FLA	1.0	1.0	1.0	1.0
FILTER — Furnished?	Yes	Yes	Yes	Yes
Type Recommended	High Velocity	High Velocity	High Velocity	High Velocity
Hi Vel. (No.-Size-Thk.)	2 - 14x20 - 1 in.	2 - 14x20 - 1 in.	2 - 16x20 - 1 in.	2 - 16x20 - 1 in.
VENT — Size (in.)	2 Round	2 Round	3 Round	3 Round
HEAT EXCHANGER				
Type -Fired -Unfired	Aluminized Steel - Type I	Aluminized Steel - Type I	Aluminized Steel - Type I	Aluminized Steel - Type I
Gauge (Fired)	20	20	20	20
ORIFICES — Main				
Nat. Gas. Qty. — Drill Size	3 — 45	4 — 45	5 — 45	6 — 45
L.P. Gas Qty. — Drill Size ⑤	3 — 56	4 — 56	5 — 56	6 — 56
GAS VALVE	Redundant - Three Stage	Redundant - Three Stage	Redundant - Three Stage	Redundant - Three Stage
PILOT SAFETY DEVICE				
Type	Hot Surface Igniter	Hot Surface Igniter	Hot Surface Igniter	Hot Surface Igniter
BURNERS — Type	Multiport Inshot	Multiport Inshot	Multiport Inshot	Multiport Inshot
Number	3	4	5	6
POWER CONN. — V / Ph / Hz ④	115/1/60	115/1/60	115/1/60	115/1/60
Ampacity (In Amps)	11.1	11.1	13.5	15.2
Max. Overcurrent Protection (Amps)	15	15	20	20
PIPE CONN. SIZE (IN.)	1/2	1/2	1/2	1/2
DIMENSIONS	H x W x D	H x W x D	H x W x D	H x W x D
Crated (In.)	41-3/4 x 19-1/2 x 30-1/2	41-3/4 x 19-1/2 x 30-1/2	41-3/4 x 23 x 30-1/2	41-3/4 x 26-1/2 x 30-1/2
WEIGHT				
Shipping (Lbs.) / Net (Lbs)	160/ 146	168 / 158	185 / 175	206 / 196

① Central Furnace heating designs are certified to ANSI Z21.47 / CSA 2.3.
② For U.S. applications, above input ratings (BTUH) are up to 2,000 feet, derate 4% per 1,000 feet for elevations above 2,000 feet above sea level.
For Canadian applications, above input ratings (BTUH) are up to 4,500 feet, derate 4% per 1,000 feet for elevations above 4,500 feet above sea level.
③ Based on U.S. government standard tests.
④ The above wiring specifications are in accordance with National Electrical Code; however, installations must comply with local codes.
⑤ Furnace ships in natural gas configuration. The LP conversion kit used with the modulating furnace is BAYLPSS220B or BAYLPKT220B.

TRANE®

TUHM AIRFLOW - HEATING

	***UHMB060ACV3VA^** Furnace Heating Airflow (CFM) and Power (watts) vs. External Static Pressure With Filter								
	Airflow Setting	Target Airflow (See Note 5)		External Static Pressure				
				0.1	0.3	0.5	0.7	0.9
Heating	40% (low) Heat	Low	465	CFM	393	504	512	546	560
				Temp. Rise	73	57	56	53	51
				Watts	43	81	112	142	140
		Medium Low	504	CFM	435	541	549	580	593
				Temp. Rise	66	53	52	50	49
				Watts	46	86	119	150	148
		Medium**	538	CFM	472	573	580	609	621
				Temp. Rise	61	50	50	47	46
				Watts	50	90	125	159	155
		High	605	CFM	545	636	644	667	676
				Temp. Rise	53	45	45	43	43
				Watts	60	103	141	177	169
	65% (medium) Heat	Low	623	CFM	565	653	660	682	691
				Temp. Rise	68	59	58	57	56
				Watts	64	107	145	182	172
		Medium Low	675	CFM	622	703	710	727	734
				Temp. Rise	62	55	54	53	53
				Watts	75	120	161	199	183
		Medium**	720	CFM	671	745	752	766	771
				Temp. Rise	58	52	51	50	50
				Watts	86	133	175	215	192
		High	810	CFM	769	831	837	843	846
				Temp. Rise	50	46	46	46	46
				Watts	114	164	210	250	211
	100% (high) Heat	Low	830	CFM	791	849	856	861	862
				Temp. Rise	65	61	60	60	60
				Watts	121	171	219	258	215
		Medium Low	900	CFM	867	916	922	921	920
				Temp. Rise	59	56	56	56	56
				Watts	148	201	251	290	230
		Medium**	960	CFM	932	972	979	973	970
				Temp. Rise	55	53	53	53	53
				Watts	174	229	282	319	243
		High	1080	CFM	1063	1086	1092	1076	1069
				Temp. Rise	48	47	47	48	48
				Watts	236	295	353	384	268

	***UHMB080ACV3VA^** Furnace Heating Airflow (CFM) and Power (Watts) vs. External Static Pressure With Filter								
	Airflow Setting	Target Airflow (See Note 5)		External Static Pressure				
				0.1	0.3	0.5	0.7	0.9
Heating	40% (low) Heat	Low	571	CFM	512	564	581	538	572
				Temp. Rise	70	63	62	66	62
				Watts	45	77	112	109	146
		Medium Low	643	CFM	586	634	649	606	634
				Temp. Rise	61	56	55	59	56
				Watts	57	90	129	127	177
		Medium**	714	CFM	661	704	717	673	696
				Temp. Rise	54	51	50	53	51
				Watts	71	106	148	146	207
		High	821	CFM	772	809	819	774	789
				Temp. Rise	46	44	44	46	45
				Watts	99	136	184	176	253
	65% (medium) Heat	Low	806	CFM	757	794	805	760	776
				Temp. Rise	67	63	63	66	65
				Watts	95	132	179	172	246
		Medium Low	907	CFM	862	893	901	855	864
				Temp. Rise	59	56	56	59	58
				Watts	127	165	217	202	289
		Medium**	1008	CFM	967	992	997	951	951
				Temp. Rise	52	51	51	53	53
				Watts	165	205	262	235	332
		High	1159	CFM	1125	1139	1141	1093	1083
				Temp. Rise	45	44	44	46	47
				Watts	233	276	341	288	395
	100% (high) Heat	Low	1120	CFM	1084	1101	1104	1056	1048
				Temp. Rise	65	64	63	66	67
				Watts	214	256	319	273	379
		Medium Low	1260	CFM	1230	1238	1237	1188	1170
				Temp. Rise	57	57	57	59	60
				Watts	286	331	401	325	437
		Medium**	1400	CFM	1376	1375	1370	1320	1292
				Temp. Rise	51	51	51	53	54
				Watts	369	418	495	381	496
		High	1610	CFM	1595	1580	1570	1519	1474
				Temp. Rise	44	44	45	46	48
				Watts	398	470	522	522	529

Notes:
1. * First letter may be "A" or "T".
2. ^ Letter may be "A" through "Z".
3. ** Factory setting.
4. Continuous Fan Setting: Heating or cooling airflow is approximately 50% of selected cooling value.
5. LOW 350 cfm/ton is recommended for variable speed application for COMFORT & HUMID CLIMATE setting; NORMAL is 400 cfm/ton; HIGH 450 cfm/ton is for DRY CLIMATE setting.
6. Target airflow is field selectable for high (100%) heat. Target airflow for low and medium heat are percentages of high heat and are not field selectable.

TUHM AIRFLOW - HEATING

	*UHMC100ACV4VA^ Furnace Heating Airflow (CFM) and Power (Watts) vs. External Static Pressure With Filter								
		Airflow Setting	Target Airflow (See Note 5)		External Static Pressure				
					0.1	0.3	0.5	0.7	0.9
Heating	40% (low) Heat	Low	606	CFM	592	617	623	617	606
				Temp. Rise	61	59	58	59	60
				Watts	78	109	141	173	233
		Medium Low	639	CFM	626	651	655	649	639
				Temp. Rise	58	56	55	56	57
				Watts	79	110	142	175	236
		Medium**	672	CFM	660	684	688	682	671
				Temp. Rise	55	53	53	53	54
				Watts	81	111	144	177	241
		High	743	CFM	732	755	757	751	739
				Temp. Rise	50	48	48	48	49
				Watts	87	115	149	185	254
	65% (medium) Heat	Low	1051	CFM	1048	1065	1060	1052	1038
				Temp. Rise	60	59	59	60	61
				Watts	149	169	208	252	358
		Medium Low	1109	CFM	1107	1123	1116	1108	1094
				Temp. Rise	57	56	56	57	58
				Watts	167	186	226	271	386
		Medium**	1166	CFM	1165	1181	1173	1165	1150
				Temp. Rise	54	53	54	54	55
				Watts	187	204	245	292	417
		High	1289	CFM	1291	1304	1293	1284	1269
				Temp. Rise	49	48	49	49	50
				Watts	236	250	293	343	490
	100% (high) Heat	Low	1460	CFM	1466	1476	1461	1451	1435
				Temp. Rise	60	59	60	60	61
				Watts	319	330	374	430	613
		Medium Low	1540	CFM	1548	1556	1540	1529	1512
				Temp. Rise	57	56	57	57	58
				Watts	364	373	419	476	679
		Medium**	1620	CFM	1629	1637	1618	1608	1590
				Temp. Rise	54	54	54	54	55
				Watts	413	419	467	527	750
		High	1790	CFM	1803	1807	1785	1774	1755
				Temp. Rise	49	48	49	49	50
				Watts	529	532	582	646	864

	*UHMD120ACV5VA^ Furnace Heating Airflow (CFM) and Power (Watts) vs. External Static Pressure With Filter								
		Airflow Setting	Target Airflow (See Note 5)		External Static Pressure				
					0.1	0.3	0.5	0.7	0.9
Heating	45% (low) Heat	Low	748	CFM	728	758	785	805	819
				Temp. Rise	62	59	57	56	55
				Watts	119	107	102	94	108
		Medium Low	788	CFM	769	797	822	840	853
				Temp. Rise	58	56	54	53	53
				Watts	113	107	111	113	133
		Medium**	832	CFM	813	841	864	880	890
				Temp. Rise	55	53	52	51	50
				Watts	108	107	122	135	160
		High	880	CFM	863	889	910	923	930
				Temp. Rise	52	50	49	49	48
				Watts	104	108	135	160	191
	65% (medium) Heat	Low	1224	CFM	1213	1232	1237	1232	1220
				Temp. Rise	60	60	59	60	60
				Watts	131	160	253	345	405
		Medium Low	1289	CFM	1279	1297	1299	1290	1274
				Temp. Rise	57	57	56	57	58
				Watts	147	178	281	382	445
		Medium**	1361	CFM	1353	1369	1367	1355	1335
				Temp. Rise	54	54	54	54	55
				Watts	168	201	313	423	489
		High	1440	CFM	1434	1448	1443	1426	1402
				Temp. Rise	51	51	51	51	52
				Watts	197	229	352	469	538
	100% (high) Heat	Low	1700	CFM	1699	1707	1690	1659	1621
				Temp. Rise	60	60	60	61	63
				Watts	325	349	495	628	698
		Medium Low	1790	CFM	1790	1797	1775	1740	1696
				Temp. Rise	57	57	57	59	60
				Watts	382	400	551	685	752
		Medium**	1890	CFM	1892	1896	1870	1830	1781
				Temp. Rise	54	54	54	56	57
				Watts	453	462	616	750	813
		High	2000	CFM	2004	2006	1975	1929	1873
				Temp. Rise	51	51	52	53	54
				Watts	540	538	694	822	880

Notes:
1. * First letter may be "A" or "T".
2. ^ Letter may be "A" through "Z".
3. ** Factory setting.
4. Continuous Fan Setting: Heating or cooling airflow is approximately 50% of selected cooling value.
5. LOW 350 cfm/ton is recommended for variable speed application for COMFORT & HUMID CLIMATE setting; NORMAL is 400 cfm/ton; HIGH 450 cfm/ton is for DRY CLIMATE setting.
6. Target airflow is field selectable for high (100%) heat. Target airflow for low and medium heat are percentages of high heat and are not field selectable.

TUHM AIRFLOW - COOLING

***UHMB060ACV3VA^** Furnace Cooling Airflow (CFM) and Power (Watts) vs. External Static Pressure With Filter

	Unit Outdoor	Airflow Setting		External Static Pressure 0.1	0.3	0.5	0.7	0.9
Cooling	1.5	290 CFM/ton	CFM	356	476	488	511	519
			Watts	29	67	97	132	167
		310 CFM/ton	CFM	389	504	516	538	545
			Watts	32	71	102	138	174
		330 CFM/ton	CFM	422	533	544	565	572
			Watts	36	75	107	144	181
		350 CFM/ton	CFM	455	561	566	589	592
			Watts	39	79	111	150	187
		370 CFM/ton	CFM	487	589	600	619	624
			Watts	43	84	119	158	197
		400 CFM/ton	CFM	537	631	655	669	673
			Watts	50	92	130	171	212
		430 CFM/ton	CFM	586	674	684	700	702
			Watts	57	101	139	182	223
		450 CFM/ton	CFM	619	695	717	727	733
			Watts	63	106	150	193	236
	2	290 CFM/ton	CFM	515	613	623	641	646
			Watts	47	88	124	164	204
		310 CFM/ton	CFM	559	650	660	677	681
			Watts	53	96	133	175	215
		330 CFM/ton	CFM	602	688	698	713	716
			Watts	60	104	143	186	228
		350 CFM/ton	CFM	646	707	737	748	752
			Watts	68	112	156	200	243
		370 CFM/ton	CFM	690	763	772	785	785
			Watts	76	123	165	211	255
		400 CFM/ton	CFM	764	816	778	847	844
			Watts	86	137	180	231	275
		430 CFM/ton	CFM	821	876	884	892	890
			Watts	108	159	206	256	303
		450 CFM/ton	CFM	937	968	977	985	984
			Watts	136	193	241	295	343
	2.5	290 CFM/ton	CFM	673	749	758	771	772
			Watts	73	119	161	206	250
		310 CFM/ton	CFM	732	791	756	766	818
			Watts	79	129	160	203	268
		330 CFM/ton	CFM	783	843	852	861	860
			Watts	98	147	193	242	288
		350 CFM/ton	CFM	848	894	908	917	917
			Watts	110	163	212	262	308
		370 CFM/ton	CFM	892	937	945	951	947
			Watts	129	182	232	284	333
		400 CFM/ton	CFM	972	1015	972	957	1036
			Watts	160	213	262	312	374
		430 CFM/ton	CFM	1057	1078	1085	1085	1078
			Watts	191	249	306	360	415
		450 CFM/ton	CFM	1115	1137	1142	1140	1139
			Watts	214	275	333	388	447
	3	290 CFM/ton	CFM	832	885	894	901	899
			Watts	111	162	210	260	308
		310 CFM/ton	CFM	898	942	950	955	951
			Watts	131	184	234	286	336
		330 CFM/ton	CFM	964	998	1006	1009	1004
			Watts	154	209	262	314	366
		350 CFM/ton	CFM	1039	1065	1073	1074	1075
			Watts	181	237	292	344	402
		370 CFM/ton	CFM	1095	1111	1118	1116	1108
			Watts	208	268	326	380	436
		400 CFM/ton	CFM	1189	1212	1214	1149	1207
			Watts	257	320	380	435	500
		430 CFM/ton	CFM	1292	1280	1285	1278	1201
			Watts	317	383	448	501	508
		450 CFM/ton	CFM	1326	1317	1361	1242	1166
			Watts	366	433	495	510	509

Notes:
1. * First letter may be "A" or "T".
2. ^ Letter may be "A" through "Z"
3. ** Factory setting.
4. Continuous Fan Setting: Heating or cooling airflow is approximately 50% of selected cooling value.
5. LOW 350 cfm/ton is recommended for variable speed application for COMFORT & HUMID CLIMATE setting; NORMAL is 400 cfm/ton; HIGH 450 cfm/ton is for DRY CLIMATE setting.

NOTE:
CONTINUOUS fan mode during COOLING operation may not be appropriate in humid climates. If the indoor air exceeds 60% relative humidity or simply feels uncomfortably humid, it is recommended that the fan only be used in the AUTO mode.

Pub. No. 22-1840-06

TUHM AIRFLOW - COOLING

***UHMB080ACV3VA^** Furnace Cooling Airflow (CFM) and Power (Watts) vs. External Static Pressure With Filter

	Unit Outdoor	Airflow Setting		External Static Pressure 0.1	0.3	0.5	0.7	0.9
Cooling	2	290 CFM/ton	CFM	504	565	586	521	540
			Watts	34	70	104	138	172
		310 CFM/ton	CFM	547	604	624	559	579
			Watts	40	77	112	147	182
		330 CFM/ton	CFM	590	644	663	597	617
			Watts	47	85	121	157	193
		350 CFM/ton	CFM	656	695	701	703	694
			Watts	54	93	130	167	204
		370 CFM/ton	CFM	676	724	740	674	694
			Watts	62	102	140	179	217
		400 CFM/ton	CFM	764	792	801	795	789
			Watts	75	116	157	197	238
		430 CFM/ton	CFM	806	844	856	788	810
			Watts	89	133	175	216	259
		450 CFM/ton	CFM	877	899	901	895	886
			Watts	102	145	188	230	275
	2.5	290 CFM/ton	CFM	660	709	726	659	680
			Watts	59	99	136	174	212
		310 CFM/ton	CFM	740	768	772	769	764
			Watts	70	109	149	189	229
		330 CFM/ton	CFM	768	809	822	755	776
			Watts	81	123	164	205	246
		350 CFM/ton	CFM	848	869	871	868	858
			Watts	94	138	179	220	265
		370 CFM/ton	CFM	875	909	918	850	872
			Watts	107	153	197	240	284
		400 CFM/ton	CFM	978	994	992	989	980
			Watts	130	179	224	270	316
		430 CFM/ton	CFM	1037	1058	1063	994	1017
			Watts	157	209	258	305	354
		450 CFM/ton	CFM	1093	1096	1082	1065	1051
			Watts	174	227	276	324	378
	3	290 CFM/ton	CFM	816	854	865	798	819
			Watts	92	136	178	220	262
		310 CFM/ton	CFM	881	914	923	855	877
			Watts	108	155	199	242	286
		330 CFM/ton	CFM	945	974	981	912	935
			Watts	127	176	222	266	313
		350 CFM/ton	CFM	1029	1043	1043	1035	1028
			Watts	148	199	246	292	340
		370 CFM/ton	CFM	1074	1093	1097	1027	1050
			Watts	170	224	274	322	372
		400 CFM/ton	CFM	1170	1181	1184	1180	1174
			Watts	206	262	317	370	423
		430 CFM/ton	CFM	1268	1276	1270	1199	1224
			Watts	254	314	372	430	484
		450 CFM/ton	CFM	1321	1321	1306	1295	1251
			Watts	287	351	415	477	518
	3.5	290 CFM/ton	CFM	972	998	1005	936	959
			Watts	135	185	232	277	324
		310 CFM/ton	CFM	1047	1068	1073	1003	1026
			Watts	161	213	262	310	359
		330 CFM/ton	CFM	1123	1138	1140	1070	1094
			Watts	189	244	296	347	398
		350 CFM/ton	CFM	1195	1204	1208	1205	1195
			Watts	215	275	329	383	437
		370 CFM/ton	CFM	1273	1278	1275	1204	1228
			Watts	257	317	376	433	488
		400 CFM/ton	CFM	1375	1385	1384	1383	1305
			Watts	316	383	444	513	513
		430 CFM/ton	CFM	1499	1487	1491	1392	1303
			Watts	389	457	513	513	513
		450 CFM/ton	CFM	1513	1512	1508	1418	1341
			Watts	398	470	529	524	522

Notes:
1. * First letter may be "A" or "T".
2. ^ Letter may be "A" through "Z"
3. ** Factory setting.
4. Continuous Fan Setting: Heating or cooling airflow is approximately 50% of selected cooling value.
5. LOW 350 cfm/ton is recommended for variable speed application for COMFORT & HUMID CLIMATE setting; NORMAL is 400 cfm/ton; HIGH 450 cfm/ton is for DRY CLIMATE setting.

NOTE:
CONTINUOUS fan mode during COOLING operation may not be appropriate in humid climates. If the indoor air exceeds 60% relative humidity or simply feels uncomfortably humid, it is recommended that the fan only be used in the AUTO mode.

TUHM AIRFLOW - COOLING

***UHMC100ACV4VA^** Furnace Cooling Airflow (CFM) and Power (Watts) vs. External Static Pressure With Filter

	Unit Outdoor	Airflow Setting		External Static Pressure				
				0.1	0.3	0.5	0.7	0.9
Cooling	2.5	290 CFM/ton	CFM	714	734	739	733	722
			Watts	79	118	157	194	231
		310 CFM/ton	CFM	765	784	789	782	770
			Watts	88	128	168	206	244
		330 CFM/ton	CFM	816	834	838	831	819
			Watts	96	138	179	220	258
		350 CFM/ton	CFM	868	884	887	880	867
			Watts	103	149	192	234	273
		370 CFM/ton	CFM	919	934	936	929	916
			Watts	117	161	205	249	290
		400 CFM/ton	CFM	995	1009	1009	1002	989
			Watts	135	181	227	274	316
		430 CFM/ton	CFM	1072	1084	1083	1075	1061
			Watts	156	204	253	302	346
		450 CFM/ton	CFM	1123	1134	1132	1124	1110
			Watts	171	220	271	322	368
	3	290 CFM/ton	CFM	862	879	882	875	863
			Watts	105	148	190	232	272
		310 CFM/ton	CFM	924	939	941	934	921
			Watts	118	162	207	250	291
		330 CFM/ton	CFM	985	999	1000	992	979
			Watts	133	178	224	270	313
		350 CFM/ton	CFM	1046	1059	1059	1051	1037
			Watts	149	196	244	292	336
		370 CFM/ton	CFM	1108	1119	1117	1109	1095
			Watts	167	215	265	316	362
		400 CFM/ton	CFM	1200	1209	1206	1197	1183
			Watts	197	248	301	355	404
		430 CFM/ton	CFM	1292	1299	1294	1285	1270
			Watts	232	286	343	400	453
		450 CFM/ton	CFM	1353	1359	1353	1344	1328
			Watts	258	314	373	432	488
	3.5	290 CFM/ton	CFM	1011	1024	1024	1017	1003
			Watts	139	185	232	279	322
		310 CFM/ton	CFM	1082	1094	1093	1085	1071
			Watts	159	207	256	306	351
		330 CFM/ton	CFM	1154	1164	1162	1153	1139
			Watts	181	231	283	335	382
		350 CFM/ton	CFM	1225	1234	1230	1222	1207
			Watts	206	258	312	367	417
		370 CFM/ton	CFM	1297	1304	1299	1290	1275
			Watts	234	288	345	402	455
		400 CFM/ton	CFM	1404	1409	1402	1393	1377
			Watts	281	340	400	462	520
		430 CFM/ton	CFM	1512	1514	1505	1495	1478
			Watts	336	399	464	530	595
		450 CFM/ton	CFM	1583	1584	1574	1564	1546
			Watts	377	444	512	580	650
	4	290 CFM/ton	CFM	1159	1169	1167	1158	1144
			Watts	183	233	285	337	385
		310 CFM/ton	CFM	1241	1249	1245	1236	1221
			Watts	212	264	319	374	425
		330 CFM/ton	CFM	1323	1329	1324	1315	1299
			Watts	244	300	358	416	470
		350 CFM/ton	CFM	1404	1409	1402	1393	1377
			Watts	281	340	400	462	520
		370 CFM/ton	CFM	1486	1489	1481	1471	1454
			Watts	322	384	448	513	576
		400 CFM/ton	CFM	1609	1609	1599	1588	1571
			Watts	393	461	530	599	671
		430 CFM/ton	CFM	1732	1730	1716	1705	1687
			Watts	475	550	624	698	781
		450 CFM/ton	CFM	1813	1810	1795	1783	1765
			Watts	536	617	694	772	864

Notes:
1. * First letter may be "A" or "T".
2. ^ Letter may be "A" through "Z"
3. ** Factory setting.
4. Continuous Fan Setting: Heating or cooling airflow is approximately 50% of selected cooling value.
5. LOW 350 cfm/ton is recommended for variable speed application for COMFORT & HUMID CLIMATE setting; NORMAL is 400 cfm/ton; HIGH 450 cfm/ton is for DRY CLIMATE setting.

NOTE:
CONTINUOUS fan mode during COOLING operation may not be appropriate in humid climates. If the indoor air exceeds 60% relative humidity or simply feels uncomfortably humid, it is recommended that the fan only be used in the AUTO mode.

Pub. No. 22-1840-06

TUHM AIRFLOW - COOLING

***UHMD120ACV5VA^** Furnace Cooling Airflow (CFM) and Power (Watts) vs. External Static Pressure With Filter

	Unit Outdoor	Airflow Setting		External Static Pressure 0.1	0.3	0.5	0.7	0.9
Cooling	3.5	290 CFM/ton	CFM	1000	1024	1028	1022	1011
			Watts	122	168	209	251	300
		310 CFM/ton	CFM	1072	1094	1097	1089	1076
			Watts	140	188	234	281	331
		330 CFM/ton	CFM	1143	1164	1165	1157	1141
			Watts	160	211	261	313	364
		350 CFM/ton	CFM	1214	1233	1234	1224	1207
			Watts	182	236	291	347	400
		370 CFM/ton	CFM	1286	1303	1302	1291	1272
			Watts	207	264	323	384	438
		400 CFM/ton	CFM	1393	1408	1405	1392	1370
			Watts	250	311	377	444	500
		430 CFM/ton	CFM	1500	1513	1508	1492	1468
			Watts	300	365	437	509	565
		450 CFM/ton	CFM	1571	1582	1576	1559	1533
			Watts	337	406	481	555	611
	4	290 CFM/ton	CFM	1148	1169	1170	1161	1146
			Watts	161	213	263	315	367
		310 CFM/ton	CFM	1230	1248	1248	1238	1221
			Watts	187	242	297	355	408
		330 CFM/ton	CFM	1311	1328	1327	1315	1295
			Watts	217	274	335	398	452
		350 CFM/ton	CFM	1393	1408	1405	1392	1370
			Watts	250	311	377	444	500
		370 CFM/ton	CFM	1474	1488	1483	1468	1445
			Watts	287	352	422	493	549
		400 CFM/ton	CFM	1597	1607	1601	1583	1556
			Watts	352	421	497	572	628
		430 CFM/ton	CFM	1719	1727	1718	1699	1668
			Watts	427	503	581	655	711
		450 CFM/ton	CFM	1801	1807	1797	1775	1743
			Watts	483	563	642	712	768
	5	290 CFM/ton	CFM	1444	1458	1454	1440	1417
			Watts	273	336	405	475	530
		310 CFM/ton	CFM	1546	1557	1552	1535	1510
			Watts	324	391	465	538	594
		330 CFM/ton	CFM	1648	1657	1650	1631	1603
			Watts	381	454	531	606	662
		350 CFM/ton	CFM	1750	1757	1748	1727	1696
			Watts	447	525	603	676	732
		370 CFM/ton	CFM	1852	1857	1845	1823	1790
			Watts	522	604	682	749	804
		400 CFM/ton	CFM	2004	2006	1992	1967	1947
			Watts	651	742	811	863	966
		430 CFM/ton	CFM	2157	2156	2140	2050	1947
			Watts	803	902	966	966	966
		450 CFM/ton	CFM	2259	2255	2140	2050	1947
			Watts	966	966	966	966	966

Notes:
1. * First letter may be "A" or "T".
2. ^ Letter may be "A" through "Z"
2. ** Factory setting.
3. Continuous Fan Setting: Heating or cooling airflow is approximately 50% of selected cooling value.
4. LOW 350 cfm/ton is recommended for variable speed application for COMFORT & HUMID CLIMATE setting; NORMAL is 400 cfm/ton; HIGH 450 cfm/ton is for DRY CLIMATE setting.

NOTE:
CONTINUOUS fan mode during COOLING operation may not be appropriate in humid climates. If the indoor air exceeds 60% relative humidity or simply feels uncomfortably humid, it is recommended that the fan only be used in the AUTO mode.

TDHM AIRFLOW - HEATING

	***DHMB060BCV3VA^** Furnace Heating Airflow (CFM) and Power (Watts) vs. External Static Pressure With Filter								
		Airflow Setting	Target Airflow (See Note 5)		External Static Pressure				
					0.1	0.3	0.5	0.7	0.9
Heating	40% (low) Heat	Low	414	CFM	438	436	458	462	474
				Temp. Rise	48	48	46	46	45
				Watts	26	49	70	90	115
		Medium Low	437	CFM	460	458	479	483	493
				Temp. Rise	46	46	44	44	43
				Watts	28	52	73	92	118
		Medium**	478	CFM	499	497	516	518	526
				Temp. Rise	42	42	41	41	40
				Watts	33	58	79	100	127
		High	534	CFM	553	551	567	567	571
				Temp. Rise	38	38	37	37	37
				Watts	42	68	90	114	144
	65% (medium) Heat	Low	702	CFM	715	713	720	714	708
				Temp. Rise	48	48	48	48	48
				Watts	76	106	140	176	217
		Medium Low	741	CFM	753	751	755	749	740
				Temp. Rise	46	46	45	46	46
				Watts	87	117	154	194	237
		Medium**	811	CFM	820	818	819	810	797
				Temp. Rise	42	42	42	42	43
				Watts	108	140	183	228	275
		High	905	CFM	911	909	904	892	873
				Temp. Rise	38	38	38	38	39
				Watts	142	177	226	276	326
	100% (high) Heat	Low	900	CFM	906	904	900	888	869
				Temp. Rise	58	58	59	59	61
				Watts	140	175	223	274	323
		Medium Low	950	CFM	954	952	945	931	910
				Temp. Rise	55	55	56	57	58
				Watts	160	197	248	300	350
		Medium**	1040	CFM	1041	1039	1027	1010	983
				Temp. Rise	51	51	51	52	54
				Watts	202	243	295	347	393
		High	1160	CFM	1157	1155	1136	1115	1080
				Temp. Rise	46	46	46	47	49
				Watts	269	317	361	405	439

	***DHMB080ACV3VA^** Furnace Heating Airflow (CFM) and Power (Watts) vs. External Static Pressure With Filter								
		Airflow Setting	Target Airflow (See Note 5)		External Static Pressure				
					0.1	0.3	0.5	0.7	0.9
Heating	40% (low) Heat	Low	683	CFM	648	670	681	685	687
				Temp. Rise	57	55	54	54	54
				Watts	79	79	148	155	219
		Medium Low	709	CFM	676	698	708	711	712
				Temp. Rise	54	53	52	52	52
				Watts	85	85	156	163	230
		Medium**	735	CFM	705	725	735	737	736
				Temp. Rise	52	51	50	50	50
				Watts	93	90	165	170	241
		High	845	CFM	824	841	849	846	838
				Temp. Rise	45	44	43	43	44
				Watts	129	119	207	206	291
	65% (medium) Heat	Low	936	CFM	923	937	943	936	923
				Temp. Rise	55	54	54	54	55
				Watts	166	148	249	241	336
		Medium Low	972	CFM	962	974	980	972	956
				Temp. Rise	52	52	51	52	53
				Watts	183	161	268	256	355
		Medium**	1008	CFM	1001	1012	1017	1008	990
				Temp. Rise	50	50	50	50	51
				Watts	201	174	288	272	374
		High	1159	CFM	1165	1171	1173	1158	1130
				Temp. Rise	43	43	43	44	45
				Watts	286	240	382	348	460
	100% (high) Heat	Low	1300	CFM	1318	1319	1319	1297	1261
				Temp. Rise	53	53	53	54	56
				Watts	382	314	485	431	549
		Medium Low	1350	CFM	1372	1372	1370	1347	1307
				Temp. Rise	51	51	51	52	54
				Watts	420	343	526	463	582
		Medium**	1400	CFM	1426	1424	1422	1396	1354
				Temp. Rise	49	49	49	50	52
				Watts	460	373	569	497	617
		High	1610	CFM	1654	1645	1639	1605	1549
				Temp. Rise	42	43	43	44	45
				Watts	650	518	770	655	772

Notes:
1. * First letter may be "A" or "T".
2. ^ Letter may be "A" through "Z".
3. ** Factory setting.
4. Continuous Fan Setting: Heating or cooling airflow is approximately 50% of selected cooling value.
5. LOW 350 cfm/ton is recommended for variable speed application for COMFORT & HUMID CLIMATE setting; NORMAL is 400 cfm/ton; HIGH 450 cfm/ton is for DRY CLIMATE setting.
6. Target airflow is field selectable for high (100%) heat. Target airflow for low and medium heat are percentages of high heat and are not field selectable.

Pub. No. 22-1840-06

TDHM AIRFLOW - HEATING

	***DHMC100ACV4VA^** Furnace Heating Airflow (CFM) and Power (Watts) vs. External Static Pressure With Filter								
		Airflow Setting	Target Airflow (See Note 5)		External Static Pressure				
					0.1	0.3	0.5	0.7	0.9
Heating	40% (low) Heat	Low	668	CFM	666	657	643	628	609
				Temp. Rise	59	59	61	62	64
				Watts	24	92	116	206	206
		Medium Low	712	CFM	710	701	686	670	650
				Temp. Rise	55	56	57	58	60
				Watts	32	105	128	220	227
		Medium**	734	CFM	732	723	708	690	670
				Temp. Rise	53	54	55	56	58
				Watts	36	111	134	227	237
		High	757	CFM	755	744	729	711	690
				Temp. Rise	52	52	53	55	56
				Watts	40	118	140	235	247
	65% (medium) Heat	Low	1080	CFM	1077	1063	1041	1016	985
				Temp. Rise	59	59	61	62	64
				Watts	128	237	237	368	398
		Medium Low	1152	CFM	1149	1134	1110	1083	1051
				Temp. Rise	55	56	57	58	60
				Watts	153	270	262	404	432
		Medium**	1188	CFM	1185	1169	1145	1117	1084
				Temp. Rise	53	54	55	56	58
				Watts	166	286	275	422	449
		High	1224	CFM	1221	1205	1180	1151	1117
				Temp. Rise	52	52	53	55	56
				Watts	180	304	288	441	466
	100% (high) Heat	Low	1500	CFM	1496	1476	1446	1410	1368
				Temp. Rise	59	59	61	62	64
				Watts	304	455	396	604	596
		Medium Low	1600	CFM	1596	1575	1542	1504	1460
				Temp. Rise	55	56	57	58	60
				Watts	356	517	438	670	643
		Medium**	1650	CFM	1646	1624	1590	1551	1505
				Temp. Rise	53	54	55	56	58
				Watts	384	550	461	705	667
		High	1700	CFM	1696	1673	1639	1598	1551
				Temp. Rise	52	52	53	55	56
				Watts	413	583	483	726	726

	***DHMD120BCV5VA^** Furnace Heating Airflow (CFM) and Power (Watts) vs. External Static Pressure With Filter								
		Airflow Setting	Target Airflow (See Note 5)		External Static Pressure				
					0.1	0.3	0.5	0.7	0.9
Heating	40% (low) Heat	Low	780	CFM	827	870	800	779	785
				Temp. Rise	57	55	59	61	60
				Watts	76	98	142	175	212
		Medium Low	827	CFM	871	917	846	827	834
				Temp. Rise	55	52	56	57	57
				Watts	85	108	153	188	226
		Medium**	870	CFM	911	959	889	872	878
				Temp. Rise	52	50	53	54	54
				Watts	94	117	165	201	240
		High	959	CFM	994	1047	977	964	969
				Temp. Rise	48	45	49	49	49
				Watts	116	140	191	230	272
	65% (medium) Heat	Low	1195	CFM	1214	1282	1211	1209	1212
				Temp. Rise	57	54	57	57	57
				Watts	193	223	285	334	385
		Medium Low	1267	CFM	1281	1353	1282	1283	1286
				Temp. Rise	54	51	54	53	53
				Watts	224	255	322	375	431
		Medium**	1469	CFM	1470	1553	1482	1493	1493
				Temp. Rise	47	44	46	46	46
				Watts	329	366	449	517	592
		High	1685	CFM	1671	1767	1696	1717	1715
				Temp. Rise	41	39	40	40	40
				Watts	479	519	633	722	831
	100% (high) Heat	Low	1660	CFM	1648	1743	1671	1691	1690
				Temp. Rise	64	61	63	62	62
				Watts	459	499	609	695	799
		Medium Low	1760	CFM	1741	1842	1770	1795	1792
				Temp. Rise	61	57	60	59	59
				Watts	541	582	709	808	932
		Medium**	1850	CFM	1825	1931	1859	1888	1885
				Temp. Rise	58	55	57	56	56
				Watts	624	663	811	922	1068
		High	2040	CFM	2002	1983	1977	1902	1853
				Temp. Rise	53	53	53	55	57
				Watts	827	925	925	925	925

Notes:
1. * First letter may be "A" or "T".
2. ^ Letter may be "A" through "Z".
3. ** Factory setting.
4. Continuous Fan Setting: Heating or cooling airflow is approximately 50% of selected cooling value.
5. LOW 350 cfm/ton is recommended for variable speed application for COMFORT & HUMID CLIMATE setting; NORMAL is 400 cfm/ton; HIGH 450 cfm/ton is for DRY CLIMATE setting.
6. Target airflow is field selectable for high (100%) heat. Target airflow for low and medium heat are percentages of high heat and are not field selectable.

TDHM AIRFLOW - COOLING

***DHMB060BCV3VA^** Furnace Cooling Airflow (CFM) and Power (Watts) vs. External Static Pressure With Filter

Cooling	Unit Outdoor Size (tons)	Airflow Setting		External Static Pressure 0.1	0.3	0.5	0.7	0.9
	1.5	290 CFM/ton	CFM	458	456	477	481	491
			Watts	28	52	73	92	118
		310 CFM/ton	CFM	487	485	504	507	515
			Watts	32	56	77	97	124
		330 CFM/ton	CFM	516	514	532	533	540
			Watts	36	61	82	104	132
		350 CFM/ton	CFM	545	543	559	560	564
			Watts	40	66	88	111	141
		370 CFM/ton	CFM	574	572	586	586	589
			Watts	45	72	95	120	151
		400 CFM/ton	CFM	617	615	627	625	625
			Watts	54	81	107	135	169
		430 CFM/ton	CFM	660	658	668	665	662
			Watts	63	91	120	152	189
		450 CFM/ton	CFM	689	687	695	691	686
			Watts	70	99	130	164	203
	2	290 CFM/ton	CFM	598	596	609	608	609
			Watts	50	77	101	128	161
		310 CFM/ton	CFM	636	634	645	643	641
			Watts	58	85	113	142	177
		330 CFM/ton	CFM	675	673	682	678	674
			Watts	66	95	125	158	196
		350 CFM/ton	CFM	713	711	718	713	706
			Watts	76	105	139	175	216
		370 CFM/ton	CFM	752	750	754	748	739
			Watts	87	117	154	193	236
		400 CFM/ton	CFM	810	808	809	800	788
			Watts	104	136	178	222	269
		430 CFM/ton	CFM	868	866	863	853	836
			Watts	125	159	205	253	301
		450 CFM/ton	CFM	906	904	900	888	869
			Watts	140	175	223	274	323
	2.5	290 CFM/ton	CFM	738	735	741	735	727
			Watts	82	113	148	186	228
		310 CFM/ton	CFM	786	784	786	778	767
			Watts	97	128	168	210	255
		330 CFM/ton	CFM	834	832	831	822	808
			Watts	112	145	189	235	282
		350 CFM/ton	CFM	882	880	877	866	849
			Watts	130	164	212	261	310
		370 CFM/ton	CFM	930	928	922	909	889
			Watts	150	186	236	287	337
		400 CFM/ton	CFM	1003	1000	990	975	950
			Watts	183	222	274	326	375
		430 CFM/ton	CFM	1075	1073	1059	1041	1011
			Watts	220	263	314	364	408
		450 CFM/ton	CFM	1123	1121	1104	1084	1052
			Watts	248	294	341	389	427
	3	290 CFM/ton	CFM	877	875	872	861	845
			Watts	128	162	209	258	307
		310 CFM/ton	CFM	935	933	927	914	893
			Watts	152	188	238	289	339
		330 CFM/ton	CFM	993	991	981	966	942
			Watts	178	217	268	321	370
		350 CFM/ton	CFM	1051	1049	1036	1019	991
			Watts	207	249	300	352	398
		370 CFM/ton	CFM	1109	1106	1090	1071	1040
			Watts	239	284	333	381	422
		400 CFM/ton	CFM	1195	1193	1172	1150	1113
			Watts	294	345	384	422	449
		430 CFM/ton	CFM	1282	1280	1254	1229	1186
			Watts	357	414	436	456	463
		450 CFM/ton	CFM	1334	1351	1272	1201	1125
			Watts	405	466	463	459	455

Notes:

1. * First letter may be "A" or "T".
2. ^ Letter may be "A through Z"
3. ** Factory setting.
4. Continuous Fan Setting: Heating or cooling airflow is approximately 50% of selected cooling value.
5. LOW 350 cfm/ton is recommended for variable speed application for COMFORT & HUMID CLIMATE setting; NORMAL is 400 cfm/ton; HIGH 450 cfm/ton is for DRY CLIMATE setting.

NOTE:
CONTINUOUS fan mode during COOLING operation may not be appropriate in humid climates. If the indoor air exceeds 60% relative humidity or simply feels uncomfortably humid, it is recommended that the fan only be used in the AUTO mode.

Pub. No. 22-1840-06

TDHM AIRFLOW - COOLING

***DHMB080ACV3VA^** Furnace Cooling Airflow (CFM) and Power (Watts) vs. External Static Pressure With Filter

	Unit Outdoor	Airflow Setting		External Static Pressure 0.1	0.3	0.5	0.7	0.9
Cooling	2	290 CFM/ton	CFM	535	558	572	580	580
			Watts	44	74	108	142	175
		310 CFM/ton	CFM	579	601	614	620	619
			Watts	51	82	118	152	187
		330 CFM/ton	CFM	622	643	655	660	659
			Watts	58	92	128	163	199
		350 CFM/ton	CFM	665	697	705	697	694
			Watts	67	104	141	175	214
		370 CFM/ton	CFM	709	728	738	741	737
			Watts	76	113	151	187	225
		400 CFM/ton	CFM	779	802	809	797	793
			Watts	90	131	169	207	250
		430 CFM/ton	CFM	839	854	863	862	855
			Watts	110	152	192	231	272
		450 CFM/ton	CFM	903	917	916	906	891
			Watts	125	168	208	248	287
	2.5	290 CFM/ton	CFM	692	712	723	726	722
			Watts	72	109	146	182	220
		310 CFM/ton	CFM	747	765	774	776	771
			Watts	85	123	162	199	238
		330 CFM/ton	CFM	801	817	826	827	820
			Watts	99	140	179	217	257
		350 CFM/ton	CFM	855	870	878	877	869
			Watts	115	157	198	237	278
		370 CFM/ton	CFM	909	923	930	927	918
			Watts	132	177	218	259	301
		400 CFM/ton	CFM	1005	1014	1014	1003	993
			Watts	164	211	252	295	337
		430 CFM/ton	CFM	1072	1082	1086	1078	1065
			Watts	196	246	291	336	381
		450 CFM/ton	CFM	1126	1134	1137	1129	1114
			Watts	221	272	319	366	411
	3	290 CFM/ton	CFM	849	865	873	872	864
			Watts	113	156	196	235	276
		310 CFM/ton	CFM	915	928	935	932	923
			Watts	134	179	221	261	303
		330 CFM/ton	CFM	980	992	997	993	982
			Watts	158	205	248	290	333
		350 CFM/ton	CFM	1045	1055	1060	1053	1041
			Watts	184	233	278	322	366
		370 CFM/ton	CFM	1110	1119	1122	1114	1100
			Watts	213	264	311	357	402
		400 CFM/ton	CFM	1211	1208	1209	1202	1195
			Watts	260	312	366	418	465
		430 CFM/ton	CFM	1305	1309	1309	1295	1242
			Watts	319	373	428	482	502
		450 CFM/ton	CFM	1370	1372	1371	1320	1242
			Watts	360	415	473	502	502

Notes:
1. * First letter may be "A" or "T".
2. ^ Letter may be "A" through "Z"
3. ** Factory setting.
4. Continuous Fan Setting: Heating or cooling airflow is approximately 50% of selected cooling value.
5. LOW 350 cfm/ton is recommended for variable speed application for COMFORT & HUMID CLIMATE setting; NORMAL is 400 cfm/ton; HIGH 450 cfm/ton is for DRY CLIMATE setting.

NOTE:
CONTINUOUS fan mode during COOLING operation may not be appropriate in humid climates. If the indoor air exceeds 60% relative humidity or simply feels uncomfortably humid, it is recommended that the fan only be used in the AUTO mode.

TDHM AIRFLOW - COOLING

***DHMC100ACV4VA^** Furnace Cooling Airflow (CFM) and Power (Watts) vs. External Static Pressure With Filter

	Unit Outdoor	Airflow Setting		External Static Pressure 0.1	0.3	0.5	0.7	0.9
Cooling	2.5	290 CFM/ton	CFM	723	713	699	682	661
			Watts	58	109	157	204	234
		310 CFM/ton	CFM	773	763	747	729	707
			Watts	72	125	174	222	256
		330 CFM/ton	CFM	823	812	795	776	753
			Watts	87	141	182	241	279
		350 CFM/ton	CFM	873	861	842	823	798
			Watts	103	158	210	260	302
		370 CFM/ton	CFM	923	910	892	870	844
			Watts	120	177	229	279	325
		400 CFM/ton	CFM	998	984	964	940	912
			Watts	148	206	258	309	360
		430 CFM/ton	CFM	1072	1058	1036	1011	981
			Watts	179	238	290	341	396
		450 CFM/ton	CFM	1122	1107	1084	1058	1026
			Watts	201	260	312	362	420
	3	290 CFM/ton	CFM	868	856	839	818	794
			Watts	101	157	208	258	299
		310 CFM/ton	CFM	928	915	896	874	849
			Watts	122	179	231	281	327
		330 CFM/ton	CFM	988	974	954	931	903
			Watts	144	202	254	305	356
		350 CFM/ton	CFM	1047	1033	1012	987	958
			Watts	169	227	279	330	384
		370 CFM/ton	CFM	1107	1092	1070	1044	1013
			Watts	195	253	305	356	413
		400 CFM/ton	CFM	1197	1181	1157	1128	1095
			Watts	237	296	346	395	455
		430 CFM/ton	CFM	1287	1269	1243	1213	1177
			Watts	284	341	390	436	498
		450 CFM/ton	CFM	1347	1329	1301	1269	1232
			Watts	317	373	420	465	526
	3.5	290 CFM/ton	CFM	1013	999	978	954	926
			Watts	154	212	265	315	367
		310 CFM/ton	CFM	1082	1068	1048	1020	990
			Watts	184	242	294	345	401
		330 CFM/ton	CFM	1152	1137	1113	1086	1054
			Watts	215	274	325	375	434
		350 CFM/ton	CFM	1222	1206	1181	1152	1118
			Watts	250	308	358	406	467
		370 CFM/ton	CFM	1292	1274	1248	1218	1182
			Watts	286	344	392	439	500
		400 CFM/ton	CFM	1397	1378	1349	1316	1277
			Watts	346	401	446	489	548
		430 CFM/ton	CFM	1501	1481	1451	1415	1373
			Watts	411	463	503	541	595
		450 CFM/ton	CFM	1571	1550	1518	1481	1437
			Watts	457	507	543	577	625
	4	290 CFM/ton	CFM	1157	1142	1118	1091	1058
			Watts	218	276	328	377	436
		310 CFM/ton	CFM	1237	1220	1195	1166	1131
			Watts	257	315	365	413	474
		330 CFM/ton	CFM	1317	1299	1272	1241	1204
			Watts	300	357	405	450	512
		350 CFM/ton	CFM	1397	1378	1349	1316	1277
			Watts	346	401	446	489	548
		370 CFM/ton	CFM	1476	1456	1426	1392	1350
			Watts	395	448	489	529	584
		400 CFM/ton	CFM	1596	1575	1542	1504	1460
			Watts	474	523	558	591	636
		430 CFM/ton	CFM	1716	1693	1658	1617	1569
			Watts	560	604	631	726	726
		450 CFM/ton	CFM	1796	1771	1735	1693	1642
			Watts	622	661	682	726	726

Notes:
1. * First letter may be "A" or "T".
2. ^ Letter may be "A" through "Z"
3. ** Factory setting.
4. Continuous Fan Setting: Heating or cooling airflow is approximately 50% of selected cooling value.
5. LOW 350 cfm/ton is recommended for variable speed application for COMFORT & HUMID CLIMATE setting; NORMAL is 400 cfm/ton; HIGH 450 cfm/ton is for DRY CLIMATE setting.

NOTE:
CONTINUOUS fan mode during COOLING operation may not be appropriate in humid climates. If the indoor air exceeds 60% relative humidity or simply feels uncomfortably humid, it is recommended that the fan only be used in the AUTO mode.

Pub. No. 22-1840-06

TDHM AIRFLOW - COOLING

Cooling

***DHMD120BCV5VA^** Furnace Cooling Airflow (CFM) and Power (Watts) vs. External Static Pressure With Filter							
Unit Outdoor Size (tons)	Airflow Setting		External Static Pressure				
			0.1	0.3	0.5	0.7	0.9
3.5	290 CFM/ton	CFM	1046	1103	1032	1027	1022
		Watts	131	157	210	251	295
	310 CFM/ton	CFM	1111	1172	1102	1099	1095
		Watts	153	180	237	280	326
	330 CFM/ton	CFM	1177	1242	1171	1171	1167
		Watts	178	207	266	313	363
	350 CFM/ton	CFM	1242	1311	1240	1243	1240
		Watts	205	236	300	350	404
	370 CFM/ton	CFM	1307	1381	1310	1315	1312
		Watts	236	269	337	392	450
	400 CFM/ton	CFM	1405	1485	1414	1422	1421
		Watts	289	325	401	464	531
	430 CFM/ton	CFM	1503	1589	1518	1530	1530
		Watts	351	389	476	547	627
	450 CFM/ton	CFM	1569	1658	1587	1602	1603
		Watts	397	436	533	610	700
4	290 CFM/ton	CFM	1181	1247	1176	1176	1172
		Watts	180	209	269	316	365
	310 CFM/ton	CFM	1256	1326	1255	1258	1255
		Watts	212	243	308	359	413
	330 CFM/ton	CFM	1331	1405	1335	1340	1338
		Watts	248	282	352	408	468
	350 CFM/ton	CFM	1405	1485	1414	1422	1421
		Watts	289	325	401	464	531
	370 CFM/ton	CFM	1480	1564	1493	1505	1504
		Watts	336	373	457	526	602
	400 CFM/ton	CFM	1592	1683	1612	1628	1629
		Watts	415	454	554	634	728
	430 CFM/ton	CFM	1704	1802	1731	1751	1753
		Watts	507	548	667	761	877
	450 CFM/ton	CFM	1778	1882	1810	1833	1836
		Watts	577	617	753	857	991
5	290 CFM/ton	CFM	1452	1534	1463	1474	1473
		Watts	318	354	436	502	574
	310 CFM/ton	CFM	1545	1634	1562	1577	1577
		Watts	380	419	512	587	673
	330 CFM/ton	CFM	1639	1733	1661	1679	1681
		Watts	452	492	599	685	787
	350 CFM/ton	CFM	1732	1832	1760	1782	1784
		Watts	533	573	699	796	918
	370 CFM/ton	CFM	1825	1931	1859	1885	1888
		Watts	624	663	811	922	925
	400 CFM/ton	CFM	1965	2080	1977	1902	1853
		Watts	781	925	925	925	925
	430 CFM/ton	CFM	2064	2229	1977	1902	1853
		Watts	925	925	925	925	925
	450 CFM/ton	CFM	2064	2250	1977	1902	1853
		Watts	925	925	925	925	925

Notes:

1. * First letter may be "A" or "T".
2. ^ Letter may be "A through Z"
3. ** Factory setting.
4. Continuous Fan Setting: Heating or cooling airflow is approximately 50% of selected cooling value.
5. LOW 350 cfm/ton is recommended for variable speed application for COMFORT & HUMID CLIMATE setting; NORMAL is 400 cfm/ton; HIGH 450 cfm/ton is for DRY CLIMATE setting.

NOTE:
CONTINUOUS fan mode during COOLING operation may not be appropriate in humid climates. If the indoor air exceeds 60% relative humidity or simply feels uncomfortably humid, it is recommended that the fan only be used in the AUTO mode.

Maximum Vent Length Table

VENT LENGTH TABLE - MODULATING FURNACE						
ALTITUDE	**MAXIMUM TOTAL EQUIVALENT LENGTH IN FEET FOR VENT AND INLET AIR (SEE NOTES)**					
0-7000 Feet	**2 INCH PIPE**		**2.5 INCH PIPE**		**3 or 4 INCH PIPE**	
	NATURAL GAS	**PROPANE**	**NATURAL GAS**	**PROPANE**	**NATURAL GAS**	**PROPANE**
UH/DHMB060ACV3V	200	Not Allowed	200	Not Allowed	200	150
UH/DHMB080ACV3V	50	Not Allowed	120	Not Allowed	200	150
UH/DHMC100ACV4V	Not Allowed	Not Allowed	60	Not Allowed	200	150
UHMD120ACV5V	Not Allowed	Not Allowed	Not Allowed	Not Allowed	200	150
DHMD120ACV5V	Not Allowed	Not Allowed	Not Allowed	Not Allowed	200	100
7000-9500 Feet	**2 INCH PIPE**		**2.5 INCH PIPE**		**3 or 4 INCH PIPE**	
	NATURAL GAS	**PROPANE**	**NATURAL GAS**	**PROPANE**	**NATURAL GAS**	**PROPANE**
UH/DHMB060ACV3V	100	Not Allowed	100	Not Allowed	100	100
UH/DHMB080ACV3V	25	Not Allowed	60	Not Allowed	100	100
UH/DHMC100ACV4V	Not Allowed	Not Allowed	30	Not Allowed	100	100
UHMD120ACV5V	Not Allowed	Not Allowed	Not Allowed	Not Allowed	100	100
DHMD120ACV5V	Not Allowed	Not Allowed	Not Allowed	Not Allowed	100	50
9500-12000 Feet	**2 INCH PIPE**		**2.5 INCH PIPE**		**3 or 4 INCH PIPE**	
	NATURAL GAS	**PROPANE**	**NATURAL GAS**	**PROPANE**	**NATURAL GAS**	**PROPANE**
UH/DHMB060ACV3V	50	Not Allowed	50	Not Allowed	50	38
UH/DHMB080ACV3V	Not Allowed	Not Allowed	30	Not Allowed	50	38
UH/DHMC100ACV4V	Not Allowed	Not Allowed	Not Allowed	Not Allowed	50	38
UHMD120ACV5V	Not Allowed	Not Allowed	Not Allowed	Not Allowed	50	38
DHMD120ACV5V	Not Allowed	Not Allowed	Not Allowed	Not Allowed	50	25

Notes: * - First letter may be "A" or "T", ** - Last two digits may be "A" thru "Z"

1. Minimum vent length for all models: 3' horizontal or 3' vertical
2. DO NOT MIX PIPE DIAMETERS IN THE SAME LENGTH OF PIPE OUTSIDE THE FURNACE CABINET, (Except adapters at the top of the furnace). If different inlet and vent pipe sizes are used, the vent pipe must adhere to the maximum length limit shown in the table above (See note 6 below for exception). The inlet pipe can be of a larger diameter, but never smaller than the vent pipe.
3. MAXIMUM PIPE LENGTHS MUST NOT BE EXCEEDED! THE LENGTH SHOWN IS NOT A COMBINED TOTAL, IT IS THE MAXIMUM LENGTH OF EACH (Vent or Inlet air pipes).
4. One SHORT radius 90° elbow is equivalent to 10' of 3" pipe and one LONG radius elbow is equivalent to 6' of 3" pipe. One 90° elbow is equivalent to 7½' of 2½" pipe or 5' of 2" pipe. Two 45° elbows equal one 90° elbow.
5. The termination tee or bend must be included in the total number of elbows. If the BAYAIR30AVENTA termination kit is used, the equivalent length of pipe is 5 feet. BAYVENT200B equivalent length is 0 feet.
6. Pipe adapters are field supplied. Downflow models, UHM 100 and UHM 120 models include the 2" x 3" adapter.
7. For Canadian applications ONLY, IPEX 196006 may be used for horizontal and vertical terminations. IPEX 081216, IPEX 081218, and IPEX 081219 may only be used for horizontal vent terminations. Equivalent lengths are IPEX 196009 = 5 feet, IPEX 081216 = 11 feet, IPEX 081218 = 16 feet, and IPEX 081219 = 21 feet

Pub. No. 22-1840-06

Electrical Data

TUHM Wiring Diagram



⚠ CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

Electrical Data

TUHM Schematic Diagram



DIAGNOSTIC CODES	
RED LED - FAULT Data - 1 Flash every 20 seconds	
2 FLASHES - SYSTEM LOCKOUT RETRIES OR RECYCLES EXCEEDED	6 FLASHES - 115 VOLT AC POWER REVERSED OR IGNITER FAULT
3 FLASHES - PRESSURE SWITCH FAULT	7 FLASHES - GAS VALVE CIRCUIT ERROR
	8 FLASHES - LOW FLAME SENSE SIGNAL
4 FLASHES - OPEN LIMIT SWITCH	9 FLASHES - OPEN INDUCER LIMIT
5 FLASHES - FLAME SENSED WHEN NO FLAME SHOULD BE PRESENT	10 FLASHES - COMMUNICATION FAULT
	CONTINUOUS ON - INTERNAL CONTROL FAILURE
GREEN LED - STATUS	
SLOW FLASH - NORMAL, NO CALL FOR HEAT	
FAST FLASH - NORMAL, CALL FOR HEAT PRESENT	
GREEN AND RED LED'S ON CONTINUOUS - INTERNAL CONTROL FAILURE	
GREEN AND RED LED'S OFF CONTINUOUS - FUSE OPEN	

WARNING ⚠	CAUTION ⚠
HAZARDOUS VOLTAGE DISCONNECT ALL ELECTRICAL POWER INCLUDING REMOTE DISCONNECTS BEFORE SERVICING. FAILURE TO DISCONNECT POWER BEFORE SERVICING CAN CAUSE SEVERE PERSONAL INJURY OR DEATH.	USE COPPER CONDUCTORS ONLY! UNIT TERMINALS ARE NOT DESIGNED TO ACCEPT OTHER TYPES OF CONDUCTORS. FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.

INTEGRATED FURNACE CONTROL

REPLACE WITH PART CNT 04829 OR EQUIVALENT
ELECTRICAL RATING
INPUT: 25 V.A.C., 60 HZ.
XFMR SEC. CURRENT: 450 MA. + MV LOAD
MV OUTPUT: 1.5 A @ 24 V.A.C.
IND OUTPUT: 3 PHASE OUTPUT
IGN OUTPUT: 2.0 A @ 120V.A.C.
CIRC. BLOWER OUTPUT: 14.5 FLA, 25 LRA @ 120 VAC
HUMIDIFER & AIR CLEANER MAX. LOAD: 1.0 A @ 120 VAC

TIMINGS
PREPURGE: 0 SEC.; INTERPURGE: 60 SEC.
POST PURGE: 5 SECONDS
IGNITOR WARMUP: 20 SECONDS
IAP: 3; TFI: 5 SECONDS
RETRIES: 2; RECYCLES: 10
HEAT ON DELAY: 45 SECONDS
COOL ON DELAY: 0 SECONDS
AUTO RESTART: 60 MINUTES
AUTO RESTART PURGE: 15 SECONDS

TCO THERMAL CUT OUT
PS PRESSURE SWITCH
FRS FLAME ROLLOUT SWITCH
FP FLAME SENSOR
CHASSIS GROUND
HSI HOT SURFACE IGNITER
DOOR SWITCH
FUSE
LC LINE CHOKE

LINE / 24 V — FACTORY WIRING
LINE / 24 V — FIELD WIRING

BK	BLACK	GR	GREEN
WH	WHITE	BR	BROWN
YL	YELLOW	RD	RED
OR	ORANGE	BL	BLUE

** INTERNAL THERMAL PROTECTION

CF CAPACITOR
COIL

WIRE COLOR
BK/1
NUMBER ID (IF ANY)

L	LINE	TH	24 VAC (HOT)
N	NEUTRAL	TR	24 VAC (COMMON)
GND	GROUND	MV	MAIN GAS VALVE
B/C	COMMON	TNS	TRANSFORMER
HLO	HIGH LIMIT OUTPUT	ILI	INDUCER LIMIT INPUT
HLI	HIGH LIMIT INPUT		

NOTES:

1. IF ANY OF THE ORIGINAL WIRING AS SUPPLIED WITH THIS FURNACE MUST BE REPLACED, IT, MUST BE WITH WIRE HAVING A TEMPERATURE RATING OF AT LEAST 105° C.
2. USER INTERFACE MUST BE INSTALLED FOR PROPER FURNACE INSTALLATION & SET-UP.
3. CORRECT PERSONALITY MODULE IS REQUIRED FOR PROPER FURNACE OPERATION. PERSONALITY MODULE IS SPECIFIC TO EACH MODEL & SERIAL NUMBER, AND IS TO REMAIN WITHIN IT'S ORIGINAL UNIT.
4. THESE LEADS PROVIDE 120V POWER CONNECTIONS FOR ELECTRONIC AIR CLEANER (EAC) AND HUMIDIFIER (HUM). MAX. LOAD: 1.0 AMPS EACH.
5. ON POWER-UP, LAST FOUR FAULTS, IF ANY, WILL BE FLASHED ON RED LED. GREEN LED WILL BE SOLID ON DURING LAST FAULT RECOVERY.
6. Y1 IS OUTPUT TO NON-COMMUNICATING OUTDOOR UNIT.
7. LINE CHOKE (LC) NOT USED ON ALL MODELS.
8. IN 24 VOLT MODE, AN OPTIONAL HUMIDISTAT CAN BE CONNECTED BETWEEN THE "R" AND "BK" TERMINALS. FACTORY INSTALLED "BK JUMPER" ON THE CIRCUIT BOARD MUST BE CUT. SEE FURNACE INSTALLERS GUIDE FOR DETAILS.
9. USED ON UHM/UXM MODELS ONLY.
10. THESE TWO MOTOR CONNECTIONS (E8 & E9) ARE INTERCHANGEABLE.

⚠ CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

Electrical Data

TDHM Wiring Diagram



IMPORTANT:
INTEGRATED CONTROL IS POLARITY SENSITIVE.
HOT LEG OF 120V POWER SUPPLY MUST BE CONNECTED TO THE BLACK POWER LEAD AS INDICATED ON WIRING DIAGRAM.

TABLE "A"	
MODELS	
*DHMB060ACV3V^^	*DHMB080ACV3V^^
*DHMC100ACV4V^^	*DHMD120ACV5V^^
*DHMB060BCV3V^^	*DHMD120BCV5V^^
* PREFIX MAY BE "A" OR "T" / ^^ SUFFIX MAY BE AA THROUGH ZZ	

⚠ CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

Electrical Data

TDHM Schematic Diagram



DIAGNOSTIC CODES	
RED LED - FAULT Data - 1 Flash every 20 seconds	
2 FLASHES - SYSTEM LOCKOUT RETRIES OR RECYCLES EXCEEDED	6 FLASHES - 115 VOLT AC POWER REVERSED OR IGNITER FAULT
3 FLASHES - PRESSURE SWITCH FAULT	7 FLASHES - GAS VALVE CIRCUIT ERROR
	8 FLASHES - LOW FLAME SENSE SIGNAL
4 FLASHES - OPEN LIMIT SWITCH	9 FLASHES - OPEN INDUCER LIMIT
5 FLASHES - FLAME SENSED WHEN NO FLAME SHOULD BE PRESENT	10 FLASHES - COMMUNICATION FAULT
	CONTINUOUS ON - INTERNAL CONTROL FAILURE
GREEN LED - STATUS	
SLOW FLASH - NORMAL, NO CALL FOR HEAT	
FAST FLASH - NORMAL, CALL FOR HEAT PRESENT	
GREEN AND RED LED'S ON CONTINUOUS - INTERNAL CONTROL FAILURE	
GREEN AND RED LED'S OFF CONTINUOUS - FUSE OPEN	

WARNING ⚠	CAUTION ⚠
HAZARDOUS VOLTAGE DISCONNECT ALL ELECTRICAL POWER INCLUDING REMOTE DISCONNECTS BEFORE SERVICING. FAILURE TO DISCONNECT POWER BEFORE SERVICING CAN CAUSE SEVERE PERSONAL INJURY OR DEATH.	USE COPPER CONDUCTORS ONLY! UNIT TERMINALS ARE NOT DESIGNED TO ACCEPT OTHER TYPES OF CONDUCTORS. FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.

INTEGRATED FURNACE CONTROL

REPLACE WITH PART CNT 04829 OR EQUIVALENT
ELECTRICAL RATING
INPUT: 25 V.A.C., 60 HZ.
XFMR SEC. CURRENT: 450 MA. + MV LOAD
MV OUTPUT: 1.5 A @ 24 V.A.C.
IND OUTPUT: 3 PHASE OUTPUT
IGN OUTPUT: 2.0 A @ 120V.A.C.
CIRC. BLOWER OUTPUT: 14.5 FLA, 25 LRA @ 120 VAC
HUMIDIFER & AIR CLEANER MAX. LOAD: 1.0 A @ 120 VAC

TIMINGS
PREPURGE: 0 SEC.; INTERPURGE: 60 SEC.
POST PURGE: 5 SECONDS
IGNITOR WARMUP: 20 SECONDS
IAP: 3; TFI: 5 SECONDS
RETRIES: 2; RECYCLES: 10
HEAT ON DELAY: 45 SECONDS
COOL ON DELAY: 0 SECONDS
AUTO RESTART: 60 MINUTES
AUTO RESTART PURGE: 15 SECONDS

TCO THERMAL CUT OUT
PS PRESSURE SWITCH
FRS FLAME ROLLOUT SWITCH
FP FLAME SENSOR
CHASSIS GROUND
HSI HOT SURFACE IGNITER
DOOR SWITCH
FUSE
LC LINE CHOKE

LINE, 24 V — FACTORY WIRING
LINE, -24 V — FIELD WIRING

** INTERNAL THERMAL PROTECTION

CF CAPACITOR
COIL

BK	BLACK	GR	GREEN
WH	WHITE	BR	BROWN
YL	YELLOW	RD	RED
OR	ORANGE	BL	BLUE

WIRE COLOR
BK/1
NUMBER ID (IF ANY)

L	LINE	TH	24 VAC (HOT)
N	NEUTRAL	TR	24 VAC (COMMON)
GND	GROUND	MV	MAIN GAS VALVE
B/C	COMMON	TNS	TRANSFORMER
HLO	HIGH LIMIT OUTPUT	ILI	INDUCER LIMIT INPUT
HLI	HIGH LIMIT INPUT		

NOTES:

1. IF ANY OF THE ORIGINAL WIRING AS SUPPLIED WITH THIS FURNACE MUST BE REPLACED, IT MUST BE WITH WIRE HAVING A TEMPERATURE RATING OF AT LEAST 105 C.
2. USER INTERFACE MUST BE INSTALLED FOR PROPER FURNACE INSTALLATION & SET-UP.
3. CORRECT PERSONALITY MODULE IS REQUIRED FOR PROPER FURNACE OPERATION. PERSONALITY MODULE IS SPECIFIC TO EACH MODEL & SERIAL NUMBER, AND IS TO REMAIN WITHIN IT'S ORIGINAL UNIT.
4. THESE LEADS PROVIDE 120V POWER CONNECTIONS FOR ELECTRONIC AIR CLEANER (EAC) AND HUMIDIFIER (HUM). MAX. LOAD: 1.0 AMPS EACH.
5. USED FOR DHM/DXM
6. ON POWER-UP, LAST FOUR FAULTS, IF ANY, WILL BE FLASHED ON RED LED. GREEN LED WILL BE SOLID ON DURING LAST FAULT RECOVERY.
7. Y1 IS OUTPUT TO NON-COMMUNICATING OUTDOOR UNIT.
8. LINE CHOKE (LC) NOT USED ON ALL MODELS.
9. IN 24 VOLT MODE, AN OPTIONAL HUMIDISTAT CAN BE CONNECTED BETWEEN THE "R" AND "BK" TERMINALS. FACTORY INSTALLED "BK JUMPER" ON THE CIRCUIT BOARD MUST BE CUT. SEE FURNACE INSTALLERS GUIDE FOR DETAILS.
10. THESE TWO MOTOR CONNECTIONS (E9 INDOOR FAN MOTOR AND E8 INDUCER MOTOR) ARE INTERCHANGEABLE.

⚠ CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

Pub. No. 22-1840-06

NOTE:
The maximum total cable length for the entire Comfort Control communicating system is 500 ft. 18 AWG. The maximum distance of any single cable from a transformer is 250 ft. 18 AWG.

NOTE:
When connecting a *FD whole house air cleaner with this furnace, order Kit #14974.

Communicating Indoor Unit with Communicating Comfort Control and Communicating Outdoor Unit



Communicating Indoor Unit with Communicating Comfort Control and 24VAC Single Stage Cooling



LEGEND

------ FACTORY WIRING

——— FIELD WIRING

[T] TERMINAL MAY OR MAY NOT BE PRESENT ON UNIT

NOTES:

1. SEE WIRING DIAGRAMS IN SERVICE FACTS FOR COMPLETE WIRING INFORMATION.
2. LOW VOLTAGE WIRING TO BE NO. 18 AWG MINIMUM CONDUCTOR.
3. BE SURE POWER SUPPLY AGREES WITH EQUIPMENT NAMEPLATE. POWER WIRING AND GROUNDING OF EQUIPMENT MUST COMPLY WITH LOCAL CODES.
4. IN COMMUNICATING MODE, UNUSED TERMINALS ARE NOT FUNCTIONAL. DO NOT USE.
5. "D" IS THE DATA LINE. INSTALLER TO SELECT A WIRE COLOR.
6. TO CONNECT OPTIONAL DEVICES (SUCH AS A FLOAT SWITCH) WIRE IN SERIES FROM INDOOR "R" TO COMFORT CONTROL "R".

PRINTED FROM D802614P02 REV01

24 VAC Mode Indoor Unit with 24 VAC Comfort Control and 24VAC Single Stage Cooling



LEGEND

------ FACTORY WIRING

——— FIELD WIRING

[T] TERMINAL MAY OR MAY NOT BE PRESENT ON UNIT

NOTES:

1. SEE WIRING DIAGRAMS IN SERVICE FACTS FOR COMPLETE WIRING INFORMATION.
2. LOW VOLTAGE WIRING TO BE NO. 18 AWG MINIMUM CONDUCTOR.
3. BE SURE POWER SUPPLY AGREES WITH EQUIPMENT NAMEPLATE. POWER WIRING AND GROUNDING OF EQUIPMENT MUST COMPLY WITH LOCAL CODES.
4. OPTIONAL FIELD WIRING. CONNECT ONLY IF THESE HEATING STAGES ARE USED.
5. CONNECTIONS TO "R" , "BK", AND "O" MUST BE MADE AS SHOWN FOR PROPER OPERATION WITH OPTIONAL HUMIDISTAT IN COOLING. FACTORY "R" TO "BK" JUMPER ON TERMINAL BLOCK MUST BE REMOVED ON AIR HANDLING UNITS. FACTORY "R" TO "BK" JUMPER ON FURNACE CONTROL MUST BE CUT ON FURNACES.

PRINTED FROM D802614P03 REV01

24 VAC Mode Indoor Unit with 24 VAC Comfort Control and 24VAC 2-Stage or 2-Step Cooling



LEGEND

------	FACTORY WIRING
———	FIELD WIRING
T	TERMINAL MAY OR MAY NOT BE PRESENT ON UNIT

NOTES:

1. SEE WIRING DIAGRAMS IN SERVICE FACTS FOR COMPLETE WIRING INFORMATION.
2. LOW VOLTAGE WIRING TO BE NO. 18 AWG MINIMUM CONDUCTOR.
3. BE SURE POWER SUPPLY AGREES WITH EQUIPMENT NAMEPLATE. POWER WIRING AND GROUNDING OF EQUIPMENT MUST COMPLY WITH LOCAL CODES.
4. OPTIONAL FIELD WIRING. CONNECT ONLY IF THESE HEATING STAGES ARE USED.
5. CONNECTIONS TO "R" , "BK", AND "O" MUST BE MADE AS SHOWN FOR PROPER OPERATION WITH OPTIONAL HUMIDISTAT IN COOLING. FACTORY "R" TO "BK" JUMPER ON TERMINAL BLOCK MUST BE REMOVED ON AIR HANDLING UNITS. FACTORY "R" TO "BK" JUMPER ON FURNACE CONTROL MUST BE CUT ON FURNACES.
6. SEE USER INTERFACE 24 VAC MODE SETUP MENU FOR 1ST STAGE CFM OPTIONS.
   2-STAGE = 39-64%
   2-STEP = 65-80%

PRINTED FROM D802614P04 REV01

24 VAC Mode Indoor Unit with 24 VAC Comfort Control and 24VAC Single Stage Heat Pump



LEGEND

------	FACTORY WIRING
———	FIELD WIRING
T	TERMINAL MAY OR MAY NOT BE PRESENT ON UNIT

NOTES:

1. SEE WIRING DIAGRAMS IN SERVICE FACTS FOR COMPLETE WIRING INFORMATION.
2. LOW VOLTAGE WIRING TO BE NO. 18 AWG MINIMUM CONDUCTOR.
3. BE SURE POWER SUPPLY AGREES WITH EQUIPMENT NAMEPLATE. POWER WIRING AND GROUNDING OF EQUIPMENT MUST COMPLY WITH LOCAL CODES.
4. OPTIONAL FIELD WIRING. CONNECT ONLY IF THESE HEATING STAGES ARE USED.
5. CONNECTIONS TO "R" , "BK", AND "O" MUST BE MADE AS SHOWN FOR PROPER OPERATION WITH OPTIONAL HUMIDISTAT IN COOLING. FACTORY "R" TO "BK" JUMPER ON TERMINAL BLOCK MUST BE REMOVED ON AIR HANDLING UNITS. FACTORY "R" TO "BK" JUMPER ON FURNACE CONTROL MUST BE CUT ON FURNACES.
6. ON FURNACE APPLICATIONS, COMFORT CONTROL MUST BE DUAL FUEL COMPATIBLE (SEE CONTROL INSTALLERS GUIDE) OR MUST USE TAYPLUS103.

PRINTED FROM D802614P05 REV01

24 VAC Mode Indoor Unit with 24 VAC Comfort Control and 24VAC 2-Stage or 2-Step Heat Pump



Humidistat Hookup - 24 V Mode ONLY



The factory installed jumper between "R" and "BK" on the circuit board must be cut if an optional humidistat is installed.

HUMIDISTAT HOOKUP - 24 V ONLY

If an optional humidistat for humidity control in cooling is used, the factory installed "BK Jumper" must be cut.

The BK Jumper must also be cut if a multi-zone controller is connected to *CONT402 is installed and using the BK enabled feature.

See the 24VAC field wiring diagrams for mor information.

TUHM-ACV Outline Drawing

(ALL DIMENSIONS ARE IN INCHES)





MODEL (SEE NOTE 1)	DIM "A"	DIM "B"	DIM "C"	DIM "D"	DIM "E"	DIM "F"
*UHMB060ACV3VA *UHMB080ACV3VA	17-1/2"	2-1/4"	16-1/4"	16"	7-1/2"	2"
*UHMC100ACV4VA	21"	2-1/2"	19-3/4"	19-1/2"	9"	3"
*UHMD120ACV5VA	24-1/2"	2-15/16"	23-1/4"	23"	10"	3"

NOTES:
1. DIAMETER OF VENT PIPE MAY BE LIMITED TO 2-1/2" OR 3" ON SOME MODELS AT DIFFERENT ALTITUDES. REFER TO THE VENT LENGTH TABLE FOR PROPER APPLICATION.

* PREFIX MAY BE "A" OR "T"

MINIMUM CLEARANCE TO COMBUSTIBLE MATERIALS

UPFLOW

SIDES	0 IN.
REAR	0 IN.
FRONT	3 IN.
TOP	1 IN.
FLUE	0 IN.

HORIZONTAL (FLUE DISCHARGE ON THE LEFT)

ALCOVE

SIDES	
RIGHT	0 IN.
LEFT	0 IN.
REAR	6 IN.
FRONT	18 IN.
TOP	1 IN.
FLUE	0 IN.

CLOSET

SIDES	
RIGHT	1 IN.
LEFT	1 IN.
REAR	3 IN.
FRONT	3 IN.
TOP	1 IN.
FLUE	0 IN.

TDHM-ACV DOWNFLOW/ HORIZONTAL OUTLINE DRAWING

(ALL DIMENSIONS ARE IN INCHES)



MODEL (SEE NOTE 1)	DIM "A"	DIM "B"	DIM "C"	DIM "D"
*DHMB060ACV3VB *DHMB060BCV3VA *DHMB080ACV3VA	17-1/2"	2-1/4"	16-1/4"	16"
*DHMC100ACV4VA	21"	2-1/2"	19-3/4"	19-1/2"
*DHMD120ACV5VB *DHMD120BCV5VA	24-1/2"	2-15/16"	23-1/4"	23"

NOTES:
1. DIAMETER OF VENT PIPE MAY BE LIMITED TO 2-1/2" OR 3" ON SOME MODELS AT DIFFERENT ALTITUDES. REFER TO THE VENT LENGTH TABLE FOR PROPER APPLICATION.

* PREFIX MAY BE "A" OR "T"

MINIMUM CLEARANCE TO COMBUSTIBLE MATERIALS

DOWNFLOW

SIDES	0 IN.
REAR	0 IN.
FRONT	3 IN.
TOP	1 IN.
FLUE	0 IN.

HORIZONTAL (FLUE DISCHARGE ON THE LEFT)

ALCOVE

SIDES	
RIGHT	0 IN.
LEFT	0 IN.
REAR	6 IN.
FRONT	18 IN.
TOP	1 IN.
FLUE	0 IN.

CLOSET

SIDES	
RIGHT	1 IN.
LEFT	1 IN.
REAR	3 IN.
FRONT	3 IN.
TOP	1 IN.
FLUE	0 IN.

Pub. No. 22-1840-06

Notes

TRANE®

Trane
6200 Troup Highway
Tyler, TX 75707
www.trane.com

Trane has a policy of continuous product and product data improvement and it reserves the right to change design and specifications without notice.